Razee USRA-1

Razee Kids Play Tent Instruction Manual

Model: USRA-1

Introduction

Thank you for choosing the Razee Kids Play Tent. This large playhouse is designed to provide a safe, comfortable, and imaginative space for children aged 36 months to 12 years. Crafted from durable, non-toxic fabric, it is suitable for both indoor and outdoor use, offering a versatile environment for play, reading, and relaxation. This manual provides essential information for the proper setup, operation, and maintenance of your play tent.

What's Included

Upon opening the package, please verify that all components are present and undamaged. The Razee Kids Play Tent package includes:

- Fabric Tent Cover (Natural color)
- Set of PVC Pipes for Frame Assembly
- Set of Connectors for Frame Assembly
- Gauze Curtains (pre-attached to tent cover)
- Assembly Guideline (Paper instructions)



Image: Overview of the Razee Kids Play Tent and its main components.

Setup Instructions

Assembly of the Razee Kids Play Tent is designed to be straightforward and quick. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay out the fabric tent cover, PVC pipes, and connectors on a clean, flat surface.
2. **Assemble the Base Frame:** Identify the base pipes and connectors. Connect them to form the rectangular base of the tent. Ensure all connections are secure.
3. **Construct Vertical Supports:** Attach the vertical pipes to the base frame using the appropriate connectors. These will form the corners and central supports of the tent structure.
4. **Form the Roof Structure:** Connect the remaining pipes and connectors to create the A-frame roof structure. This typically involves connecting two sets of angled pipes at the top to form the peak.
5. **Drape the Tent Cover:** Carefully drape the fabric tent cover over the assembled frame. Ensure the windows and

entrance align correctly with the frame structure. The cover is designed to fit snugly.

6. **Secure the Cover:** The tent cover features integrated ties or zippers to secure it to the frame. Fasten these points to ensure the cover is taut and stable.
7. **Final Adjustments:** Once the tent is fully assembled, gently adjust the frame and fabric to ensure it stands upright and is stable.



Image: The assembled play tent, highlighting its spacious dimensions (52" L x 35" W x 60" H).

Operating Your Play Tent

The Razee Kids Play Tent offers a versatile space for various activities:

- **Entrance and Curtains:** The tent features a main entrance with gauze curtains. These curtains can be tied back to keep the entrance open, or left down for a more private space.
- **Windows:** The tent includes breathable windows that allow for air circulation and light.
- **Customization:** Enhance the play experience by adding soft blankets, pillows, or a mattress for a cozy reading nook

or a comfortable sleeping area.

- **Indoor/Outdoor Use:** The tent is suitable for use in bedrooms, family rooms, playrooms, backyards, and parks. When used outdoors, ensure it is placed on a flat, stable surface and secured against strong winds.

Your browser does not support the video tag.

Video: A demonstration of the Razee Kids Play Tent's features and interior space.



Image: Detailed view of the tent's ethereal gauze curtains and breathable windows.

Care and Maintenance

To ensure the longevity and cleanliness of your Razee Kids Play Tent, please follow these maintenance guidelines:

- **Cleaning:** The fabric tent cover can be spot cleaned with a damp cloth and mild soap. For deeper cleaning, the fabric is machine washable. Use cold water on a gentle cycle and air dry. Do not bleach or tumble dry.
- **Frame Care:** Wipe down the PVC pipes with a damp cloth as needed. Avoid using abrasive cleaners.

- **Storage:** When not in use, or for extended outdoor periods, disassemble the tent and store it in a cool, dry place away from direct sunlight to prevent fading and material degradation. The easy assembly/disassembly allows for convenient storage.
- **Safety Check:** Periodically inspect all frame connections and fabric for any signs of wear or damage. Ensure all ties and zippers are functioning correctly.

Troubleshooting

If you encounter any issues with your Razee Kids Play Tent, please refer to the following common solutions:

Problem	Possible Cause	Solution
Tent is unstable or wobbly.	Loose frame connections or improperly secured fabric.	Ensure all PVC pipes are fully inserted into their connectors. Check that the fabric cover is taut and all ties/zippers are fastened.
Fabric does not fit correctly.	Incorrect frame assembly or fabric orientation.	Double-check the assembly instructions to ensure the frame is built correctly. Re-orient the fabric cover to match the frame's shape.
Pipes are difficult to connect/disconnect.	Tight fit or slight misalignment.	Apply gentle, even pressure when connecting. A slight twist can help. For disconnection, twist and pull. The plastic is designed to be slightly flexible.
Fading or discoloration of fabric.	Prolonged exposure to direct sunlight.	Store the tent in a cool, dry place away from direct sunlight when not in use, especially if used outdoors.

Product Specifications

Brand: Razee

Model Number: USRA-1

Product Dimensions: 52 inches (L) x 35 inches (W) x 60 inches (H)

Item Weight: 7.19 pounds

Material: Fabric (non-toxic, no smell) and PVC (frame)

Recommended Age: 36 months - 12 years

Country of Origin: China

Warranty and Support

For any questions, concerns, or support needs regarding your Razee Kids Play Tent, please contact Razee customer service. While specific warranty details are not provided in this manual, Razee is committed to customer satisfaction. Please retain your proof of purchase for any warranty claims.

Contact Information: Please refer to the contact details provided on the product packaging or the official Razee website for the most up-to-date support information.

© 2025 Razee. All rights reserved.
For more information, visit the Razee Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question