Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine VSX-42, VSX-321K-P, VSX-520, VSX-522-K, VSX-523, VSX-819H, VSX-823, VSX-921K

JustFine Replacement Remote Control Instruction Manual

Compatible with Pioneer AV Receiver Models: VSX-42, VSX-321K-P, VSX-520, VSX-522-K, VSX-523, VSX-819H, VSX-823, VSX-921K

Introduction

This manual provides instructions for the setup, operation, and maintenance of your JustFine replacement remote control. This remote is designed to be compatible with various Pioneer AV Receiver models, ensuring seamless control of your audio-visual system.

Package Contents

Please verify that all items are present in your package:

- 1 x JustFine Replacement Remote Control

Note: Batteries and a separate instruction manual are not included in the package.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image: Back of the remote control with the battery cover open, illustrating the battery insertion process.

2. Initial Use

This replacement remote control is pre-programmed for compatibility with the listed Pioneer AV Receiver models. No additional programming is required. Simply install the batteries, and the remote should be ready for immediate use with your compatible receiver.

Note: This remote cannot be reprogrammed for other devices.

Operating Instructions

The remote control features a standard layout for Pioneer AV Receivers. Refer to the image below for a visual guide to the buttons and their functions.





Image: Front view of the remote control, displaying all functional buttons.

Key Functions Overview:

- **RECEIVER / TV Power Buttons:** Turn the AV Receiver or TV on/off.
- **INPUT SELECT Buttons (BD, DVD, CD, TV, etc.):** Select the desired input source for your receiver.
- **VOLUME +/-:** Adjust the master volume level.
- **MUTE:** Mute or unmute the audio output.
- **Navigation Buttons (Up, Down, Left, Right, ENTER):** Navigate through menus and confirm selections.
- **AUDIO PARAMETER / TUNER EDIT / MASTER VOLUME:** Access specific settings and adjustments.
- **Number Pad (0-9):** Direct input for channels or menu options.
- **Playback Controls (Play, Pause, Stop, Skip):** Control media playback on connected devices.
- **Sound Mode Buttons (AUTO/DIRECT, STEREO, ADV SURR):** Select different audio processing modes.

For detailed functionality of each button, please refer to your Pioneer AV Receiver's original instruction manual.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Avoid Exposure:** Keep the remote away from direct sunlight, high temperatures, humidity, and strong impacts.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.

- Check for any obstructions between the remote and the AV receiver's infrared sensor.
- Ensure you are within the operating range and pointing the remote directly at the receiver.

- **Certain buttons not working:**
  - This remote is pre-programmed for specific Pioneer AV Receiver models. Verify your receiver model is listed as compatible.
  - Some buttons may correspond to functions not present on all compatible receiver models.

Specifications

Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.65 ounces
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Manufacturer	JustFine

Warranty and Support

This product is sold with a money-back guarantee and a 30-day quality warranty. For any issues or inquiries, please contact the seller directly.
For further assistance with your Pioneer AV Receiver's specific functions, please consult the original Pioneer user manual or Pioneer's official support resources.

© 2023 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08ZXVZS9M

More documents and user manuals: **https://manuals.plus/**