Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EMtronics EM19DVD12

EMtronics 19" HD Ready LED TV with Freeview and Built-in DVD Player

Model: EM19DVD12

1. Introduction

This manual provides essential information for the safe and efficient operation of your EMtronics 19" HD Ready LED TV with Freeview and Built-in DVD Player. Please read this manual thoroughly before using the television and retain it for future reference.

Key features of your television include:

- 19" Inch LED Widescreen Display
- HD Ready 720p Resolution
- Integrated Freeview for access to over 50 TV channels
- Built-in DVD Player for convenient movie playback
- Multiple connectivity options including HDMI, USB, and SCART

2. Safety Information

Always observe the following safety precautions when operating this television:

- Do not expose the television to rain or moisture to prevent fire or electric shock.
- Ensure proper ventilation; do not block ventilation openings.
- Place the television on a stable, level surface to prevent it from falling.
- Unplug the power cord from the wall outlet during lightning storms or when unused for long periods.
- Do not open the television casing; refer all servicing to qualified service personnel.
- Keep batteries out of reach of children.

3. What's in the Box

Carefully unpack the box and ensure all items are present:

- EMtronics 19" LED TV
- TV Stand
- Remote Control

- Quick Start Guide
- AAA Batteries (2x)

4. Product Overview

4.1 Front View



Figure 4.1: Front view of the EMtronics 19" LED TV, showing the screen, EMtronics logo, and a partially inserted DVD.

4.2 Side View (DVD Slot)





Figure 4.2: Side view of the EMtronics 19" LED TV, highlighting the built-in DVD player slot.

4.3 Rear View (Ports and VESA Mount)



Figure 4.3: Rear view of the EMtronics 19" LED TV, displaying the connectivity ports and VESA mounting points.

Familiarize yourself with the location of the power button, input ports (HDMI, USB, SCART), and the DVD slot for optimal use.

5. Setup

5.1 Unpacking

Carefully remove the television and all accessories from the packaging. Retain the packaging for future transport or storage.

5.2 Attaching the Stand

1. Place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align the stand with the mounting holes on the bottom of the TV.
3. Secure the stand using the provided screws. Ensure the stand is firmly attached, though some slight movement may be inherent to the design.

5.3 Wall Mounting (Optional)

This TV supports VESA wall mounts with dimensions of 75 x 75 mm. A wall mount bracket is not included. Follow the instructions provided with your wall mount bracket for proper installation. Ensure the wall can support the weight of the TV.

5.4 Connecting Power

Plug the power cord into the AC IN port on the TV, then plug the other end into a wall power outlet.

5.5 Connecting External Devices

- **HDMI:** Connect Blu-ray players, game consoles, or other HDMI-enabled devices to the HDMI input port.
- **USB:** Insert USB drives for multimedia playback (photos, music, videos) into the USB port.
- **SCART:** Connect older devices using the SCART input.
- **Antenna:** Connect a digital antenna to the ANT IN port for Freeview reception.

6. Operating Instructions

6.1 Initial Setup and Freeview Tuning

1. After connecting power and antenna, press the **POWER** button on the remote control or TV.
2. The first-time installation wizard will appear. Follow the on-screen prompts to select your language, country, and perform an automatic channel scan for Freeview channels.
3. Once the scan is complete, your TV is ready to watch Freeview channels.

6.2 Basic TV Functions

- **Power On/Off:** Press the **POWER** button.
- **Channel Selection:** Use the **CH+/-** buttons or number pad on the remote.
- **Volume Control:** Use the **VOL+/-** buttons.
- **Input Source:** Press the **SOURCE** button to switch between TV, HDMI, AV, USB, and DVD inputs.

6.3 Using the Built-in DVD Player

1. Ensure the TV is powered on.
2. Gently insert a DVD disc into the DVD slot on the side of the TV, label side facing forward. The TV will automatically switch to DVD mode or prompt you to select it.
3. Use the DVD control buttons on the remote (Play, Pause, Stop, Fast Forward, Rewind, Skip) to manage playback.
4. To eject the disc, press the **EJECT** button on the remote or the TV.

6.4 USB Multimedia Playback

Insert a USB flash drive containing compatible media files (photos, music, videos) into the USB port. Select the USB input source. Navigate through your files using the remote control to play your desired content.

7. Maintenance

7.1 Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and casing.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive cleaner specifically designed for electronics. Do not spray cleaner directly onto the screen.

- Avoid using abrasive cloths, waxes, or solvents.

7.2 Storage

If storing the TV for an extended period, disconnect it from power, remove batteries from the remote, and store it in a cool, dry place, preferably in its original packaging.

8. Troubleshooting

Problem	Possible Cause / Solution
No Power	Check if the power cord is securely plugged into the TV and the wall outlet. Test the outlet with another device.
No Picture / Poor Picture Quality	Ensure the correct input source is selected. Check antenna connection for TV channels. Adjust picture settings (brightness, contrast). For DVD, ensure disc is clean and inserted correctly.
No Sound	Check volume level and mute status. Ensure external audio devices are connected correctly.
Remote Control Not Working	Check and replace batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
DVD Not Playing	Ensure the disc is inserted correctly (label side facing forward). Clean the disc. Try a different disc. Ensure the TV is in DVD input mode.

If the problem persists after trying these solutions, please contact EMtronics customer support.

9. Specifications

- **Model:** EM19DVD12
- **Screen Size:** 19 Inches / 49 cm (Visible diagonal)
- **Display Technology:** LED LCD
- **Resolution:** HD Ready 720p
- **Aspect Ratio:** 16:9
- **Special Feature:** Built-in DVD Player
- **Connectivity:** USB, HDMI, SCART
- **Supported Internet Services:** Freeview
- **Product Dimensions:** 6.8 x 44.61 x 26.66 cm
- **Product Weight:** 2.09 kg
- **Energy Efficiency Class:** F
- **On-mode Power Consumption:** 36.00 watts
- **Annual Energy Consumption:** 25.00 kWh (based on 4 hours/day, 365 days)
- **Batteries for Remote:** 2 AAA (included)
- **VESA Wall Mount:** 75 x 75 mm
- **Manufacturer:** EMtronics
- **Country of Origin:** China

10. Warranty and Support

Your EMtronics television is covered by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact EMtronics customer service.

For further assistance, visit the official EMtronics store on Amazon:EMtronics Store

© 2024 EMtronics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08ZYP6ZR8

More documents and user manuals: **https://manuals.plus/**