Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GreenLife CC004426-001

GreenLife Digital Rice Cooker Instruction Manual

Brand: GreenLife | Model: CC004426-001

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

Included Components

- GreenLife Digital Rice Cooker Unit
- Removable Nonstick Ceramic Inner Pot
- Measuring Cup

- Rice Paddle
- Power Cord



Image: The GreenLife Digital Rice Cooker in pink, shown with its removable nonstick inner pot, measuring cup, and power cord. The product box is visible in the background.



Image: Side view of the GreenLife Digital Rice Cooker, highlighting its compact dimensions of 7.44"D x 8.23"W x 7.36"H.

Setup

Before first use, wash the removable inner pot, measuring cup, and rice paddle with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the rice cooker with a damp cloth.

Place the rice cooker on a stable, level, heat-resistant surface. Ensure the inner pot is properly seated inside the main unit before adding ingredients.



Image: The GreenLife Digital Rice Cooker with its lid open, revealing the removable nonstick inner pot ready for use.

Operating Instructions

Basic Cooking Steps

1. Use the provided measuring cup to measure your desired amount of rice or grains.
2. Rinse rice thoroughly if desired, then place it into the removable inner pot.
3. Add the appropriate amount of water according to the Rice & Grain Chart below.
4. Place the inner pot into the rice cooker and close the lid securely.
5. Plug the rice cooker into an available 110V AC outlet.
6. Press the 'Menu' button to cycle through the preset options (White Rice, Brown Rice, Quinoa, Steel Cut Oats). The selected option will illuminate.
7. Adjust cooking time using the '+' and '-' buttons if needed (refer to the chart for suggested ranges).

8. Press the 'Start' button to begin cooking. The display will show the countdown timer.
9. Once cooking is finished, the unit will automatically switch to 'Keep Warm' mode.



Image: A visual guide showing four steps: 1. Pour in rice/grains, 2. Add water, 3. Choose your preset on the control panel, 4. Makes up to 4 cups of cooked rice.



Image: A close-up of the rice cooker's control panel, showing buttons for White Rice, Brown Rice, Quinoa, Steel Cut Oats, Keep Warm/Stop, Delay Timer, Menu, and Start.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and ease of use of the GreenLife PFAS-Free Nonstick Rice Cooker.

Rice & Grain Chart

Use the included measuring cup (1 Rice Measuring Cup = 2/3 U.S. Cup) for accurate results.



Image: A chart detailing recommended uncooked rice/grain volume, corresponding water line, default cooking time, and adjustable cooking time range for White Rice, Brown Rice, Quinoa, and Steel Cut Oats.

Rice & Grain Cooking Guide

Grain Type	Uncooked Volume (using included cup)	Water Line	Default Time	Cook Time Range
White Rice	1 cup	Line 1	25 min	20-60 min
White Rice	2 cups	Line 2	25 min	20-60 min
Brown Rice	1 cup	Line 1	50 min	45-90 min
Brown Rice	1 1/2 cups	Line 1 1/2	50 min	45-90 min
Quinoa	1/2 cup	Line 1	30 min	20-40 min
Steel Cut Oats	1 cup	Line 2 1/2	25 min	20-40 min

Keep Warm Function

After the cooking cycle is complete, the rice cooker will automatically switch to the 'Keep Warm' function. This feature keeps your rice or grains at an optimal serving temperature until you are ready to eat. The display will show how long the unit has been in 'Keep Warm' mode.



Image: A hand pressing the 'Keep Warm/Stop' button on the GreenLife Digital Rice Cooker, with the display showing a timer, indicating the unit is in 'Keep Warm' mode.

Delay Timer

The Delay Timer allows you to set a specific time for your cooking cycle to begin. This is useful for meal planning, ensuring your rice or grains are ready exactly when you need them. To use, select your desired cooking preset, then press 'Delay Timer' and use the '+' and '-' buttons to set the delay time. Press 'Start' to confirm.

Maintenance

Cleaning

Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.

- **Removable Inner Pot:** The healthy ceramic nonstick inner pot is dishwasher safe for effortless cleanup. For best results, hand wash with warm, soapy water and a non-abrasive sponge.
- **Measuring Cup & Rice Paddle:** These accessories are also dishwasher safe.
- **Exterior:** Wipe the exterior of the rice cooker with a damp cloth. Do not immerse the main unit in water or any other liquid.
- **Lid:** The inner lid can be wiped clean. Ensure no food particles are left in the steam vent.



Image: A hand cleaning the removable nonstick inner pot under running water, demonstrating its easy-to-clean surface.

Troubleshooting

- **Rice is too dry/hard:** Ensure the correct water-to-grain ratio was used according to the Rice & Grain Chart. Make sure the lid was closed securely during cooking.
- **Rice is too wet/mushy:** Reduce the amount of water slightly for the next batch. Ensure rice was not over-rinsed if applicable.
- **Unit not turning on:** Check if the power cord is securely plugged into both the appliance and a working electrical outlet.
- **Steam/Water leaking from lid:** Ensure the inner pot is correctly seated and the lid is fully closed. Check the steam vent for any blockages.
- **Rice sticking to the pot:** While the pot is nonstick, ensure you are using the recommended measuring cup and water levels. Avoid using metal utensils that could scratch the nonstick coating.

Specifications

Feature	Detail
Brand	GreenLife
Model Name	Go Grains! Rice & Grain Cooker
Model Number	CC004426-001
Capacity	4 Cups (cooked)
Product Dimensions	7.44"D x 8.23"W x 7.36"H
Power Source	Corded Electric
Voltage	110 Volts
Wattage	240 watts

Feature	Detail
Material	Ceramic (inner pot)
Special Features	Timer, Advanced Fuzzy Logic, Easy Clean, Non-Stick
Product Care Instructions	Dishwasher Safe Parts, Wipe with Damp Cloth
Item Weight	4 Pounds
Country of Origin	China

Warranty and Support

For detailed warranty information and customer support, please refer to the official User Manual PDF provided by GreenLife. You can typically find this document on the product's Amazon listing page or the manufacturer's official website.

For further assistance, please contact GreenLife customer service.

© 2024 GreenLife. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091C3Z1FP

More documents and user manuals: **https://manuals.plus/**