LASIKA W-F83

Lasika Sport Watch W-F83 Instruction Manual

Model: W-F83

1. Introduction and Overview

Thank you for choosing the Lasika Sport Watch W-F83. This digital watch is designed for durability and functionality, featuring a clear digital display and a comfortable resin band. This manual provides detailed instructions to help you understand and operate your watch effectively.





Image 1: Front view of the Lasika Sport Watch W-F83, displaying the digital time, day, and various mode indicators. The watch features a black resin case and strap with prominent buttons on the sides.

2. Product Features

- **Digital Display:** Clear and easy-to-read time and function display.
- **Sport Watch Design:** Durable construction suitable for active use.
- **Resin Band:** Comfortable and robust band material.
- **Multifunctional:** Includes features such as time, date, alarm, and stopwatch.

3. Watch Components and Setup

Familiarize yourself with the watch's buttons and display indicators before initial setup.



Image 2: Top-down view of the Lasika Sport Watch W-F83, highlighting the watch face and the four control buttons located on the sides of the watch case. These buttons are used for mode selection, setting, and light activation.

Button Functions:

- **MODE Button (Bottom Left):** Cycles through display modes (Time, Alarm, Stopwatch).
- **LIGHT Button (Top Left):** Activates the backlight.
- **START Button (Top Right):** Used for starting/stopping stopwatch, adjusting values.
- **RESET Button (Bottom Right):** Used for resetting stopwatch, selecting items, or confirming settings.

4. Operating Instructions

4.1. Setting Time and Date

1. From the normal time display, press the **MODE** button three times to enter time setting mode. The seconds digits will flash.
2. Press the **RESET** button to cycle through the setting items: Seconds → Hours → Minutes → Month → Date → Day of Week.
3. While an item is flashing, press the **START** button to adjust the value. Hold the **START** button to rapidly advance the value.
4. Once all settings are correct, press the **MODE** button to exit the setting mode and return to the normal time display.

4.2. Using the Alarm Function

1. From the normal time display, press the **MODE** button once to enter alarm mode. The alarm time will be displayed.
2. Press the **RESET** button to toggle the alarm ON/OFF. An alarm icon will appear when the alarm is active.
3. To set the alarm time, press the **MODE** button twice from the normal time display (or once from alarm display) to enter alarm setting mode. The hour digits will flash.
4. Press the **START** button to adjust the hour.
5. Press the **RESET** button to select the minute digits, then press **START** to adjust the minutes.
6. Press the **MODE** button to exit alarm setting mode.

4.3. Using the Stopwatch Function

1. From the normal time display, press the **MODE** button twice to enter stopwatch mode. The display will show "00:00:00".
2. Press the **START** button to begin timing.

3. Press the **START** button again to pause timing.
4. Press the **START** button to resume timing from the paused point.
5. While the stopwatch is paused, press the **RESET** button to reset the stopwatch to "00:00:00".
6. Press the **MODE** button to exit stopwatch mode and return to the normal time display.

4.4. Activating the Backlight

Press the **LIGHT** button (top left) to illuminate the display for a few seconds, allowing for visibility in low-light conditions.

5. Maintenance and Care

- **Cleaning:** Wipe the watch with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then wipe dry. Avoid harsh chemicals.
- **Water Resistance:** While designed for sport, avoid prolonged exposure to water or submersion unless specifically rated for such activities. Refer to product specifications for water resistance details.
- **Temperature:** Avoid exposing the watch to extreme temperatures (hot or cold) as this can affect battery life and display performance.
- **Battery Replacement:** When the display becomes dim or functions become erratic, the battery may need replacement. It is recommended to have this done by a qualified watch technician.



Image 3: Side view of the Lasika Sport Watch W-F83, showcasing the black resin strap and the watch case profile. This view emphasizes the material and construction of the band.

6. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery.	Replace the battery.
Time is incorrect.	Time not set properly or accidental button press.	Refer to Section 4.1 to reset the time.
Buttons are unresponsive.	Watch may be in a locked mode (unlikely for this model) or internal issue.	Try removing and reinserting the battery (if accessible) or consult a technician.
Alarm does not sound.	Alarm is turned off or set incorrectly.	Refer to Section 4.2 to ensure the alarm is ON and set to the correct time.

7. Specifications

- **Model Number:** W-F83

- **Display Type:** Digital
- **Band Material:** Resin
- **Case Material:** Resin
- **Targeted Group:** Unisex (as per product description)
- **Manufacturer:** Lasika
- **Package Dimensions:** 11 x 11 x 6 cm
- **Item Weight:** Approximately 66 g

8. Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

For further assistance, you may visit the official Lasika website or contact their customer service department. Contact details are typically found on the product packaging or the manufacturer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question