Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lasika W-H9006

Lasika W-H9006 Men's Sport Watch User Manual

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Lasika W-H9006 Men's Sport Watch. Please read this manual carefully to ensure proper use and to maximize the lifespan of your watch.

Product Overview

The Lasika W-H9006 is a digital sport watch designed for men, featuring a round dial, rubber band, and water resistance. It includes functions such as time display, date, day of the week, alarm, and a backlight.



Figure 1: Front view of the Lasika W-H9006 Sport Watch. The digital display shows time, day, and date. Buttons are visible on both sides of the watch case.

Watch Components and Button Functions

- **LIGHT Button (Top Left):** Activates the backlight for visibility in low-light conditions.
- **MODE Button (Bottom Left):** Cycles through different operational modes (Time, Chronograph, Alarm).
- **START Button (Top Right):** Used to start/stop functions in Chronograph mode and to adjust values during setting.

- **RESET Button (Bottom Right):** Used to reset functions in Chronograph mode and to select items during setting.
- **Display:** Shows time (hours, minutes, seconds), day of the week (SU, MO, TU, WE, TH, FR, SA), date, and alarm indicator (ALM, bell icon).

Setup

Setting Time and Date

1. From the normal time display, press the **MODE** button three times to enter time setting mode. The seconds digits will flash.
2. Press the **RESET** button to select the value you wish to adjust (seconds, hours, minutes, month, date, day of the week). The selected value will flash.
3. Press the **START** button to increase the selected value. Hold the **START** button to advance rapidly.
4. Once all settings are correct, press the **MODE** button to return to the normal time display.

Setting the Alarm

1. From the normal time display, press the **MODE** button twice to enter alarm setting mode. The hour digits of the alarm will flash.
2. Press the **RESET** button to switch between setting hours and minutes.
3. Press the **START** button to adjust the flashing hour or minute value.
4. Once the desired alarm time is set, press the **MODE** button to return to the normal time display.
5. To activate/deactivate the alarm, press the **START** and **RESET** buttons simultaneously in normal time mode. A bell icon or "ALM" indicator will appear/disappear on the display.

Operating Modes

Time Mode

This is the default display mode, showing the current time, day of the week, and date. Press the **LIGHT** button to illuminate the display.

Chronograph (Stopwatch) Mode

1. From the normal time display, press the **MODE** button once to enter Chronograph mode. The display will show "00:00:00".
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button while paused to reset the stopwatch to "00:00:00".
5. Press the **MODE** button to exit Chronograph mode and return to the normal time display.

Alarm Function

When the alarm is active, it will sound at the set time for approximately 20 seconds. To stop the alarm sound, press any button. The alarm will sound again at the same time the next day unless deactivated.

Maintenance

- **Cleaning:** Wipe the watch with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by

drying. Avoid harsh chemicals or abrasive cleaners.

- **Water Resistance:** The watch is water-resistant. However, it is not suitable for diving or prolonged submersion. Avoid pressing buttons underwater to prevent water ingress.
- **Battery Replacement:** When the display becomes dim or functions become erratic, the battery may need replacement. This should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery.
Time is incorrect.	Time not set correctly or accidental adjustment.	Refer to "Setting Time and Date" section to reset the time.
Alarm does not sound.	Alarm is deactivated or set incorrectly.	Ensure the alarm is activated (bell icon visible) and the alarm time is set correctly.
Buttons are unresponsive.	Temporary software glitch or low battery.	Try removing and reinserting the battery (if accessible) or allow the battery to be replaced. If issue persists, contact support.

Specifications

- **Brand:** Lasika
- **Model:** W-H9006
- **Display Type:** Digital
- **Targeted Group:** Men
- **Band Material:** Rubber
- **Dial Case Diameter:** 30 millimeters
- **Water Resistance:** Yes (Note: Not suitable for diving or hot water activities)
- **Package Dimensions:** 11 x 11 x 5 cm
- **Item Weight:** 11 g

Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.
For general inquiries about Lasika products, you may visit the manufacturer's official website if available, or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091CWVP4D

More documents and user manuals: **https://manuals.plus/**