Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY T-B16

Instruction Manual

YING RAY Replacement Infrared Remote Control

Model: **T-B16**

For Twin Star CHIMNEYFREE / Dura Flame Fireplace Stove Heaters

1. Introduction

This manual provides instructions for the YING RAY T-B16 replacement infrared remote control. This remote is designed to operate specific Twin Star CHIMNEYFREE and Dura Flame fireplace and stove heater models. It is not a universal remote control.

Important Note: If you are uncertain about compatibility with your unit, please verify your fireplace or stove heater model number before use.

Compatible models include, but are not limited to:

- 1811040FGL, 1811040FSL, 1811040CGL
- 2311040FGL, 2311040FSL, 2311040CGL
- 2511040FGL, 2511040FSL, 2511040CGL
- 2611040FGL, 2611040FSL, 2611040CGL
- 2811040FGL, 2811040FSL, 2811040CGL
- 3211040FGL, 3211040FSL, 3211040CGL
- 3311040FGL, 3311040FSL, 3311040CGL
- 4211040FGL, 4211040FSL, 4211040CGL
- 181RM9984-C325, 1811801FGL

2. Setup

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA 1.5V batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Batteries are not included with the remote control.



The back of the YING RAY T-B16 remote control is shown with the battery compartment cover removed, revealing the two AAA battery slots. A single AAA battery is depicted next to the remote, indicating the required battery type for operation.

2.2 Initial Use

The YING RAY T-B16 remote control operates without any programming. Once batteries are correctly installed, it is ready for immediate use with compatible fireplace or stove heater models.

3. Operating Instructions

Point the remote control directly at the infrared receiver on your fireplace or stove heater. Ensure there are no obstructions between the remote and the unit.



This image displays the YING RAY T-B16 remote control alongside a simplified diagram illustrating its button functions. The remote features buttons for Power, Flame, Speed, Timer, and directional controls.

Button Functions:

- **POWER:** Turns the fireplace/heater unit ON or OFF.
- **FLAME:** Adjusts the flame brightness or effect settings.

- **SPEED:** Controls the fan speed or other operational speeds.
- **TIMER:** Sets or adjusts the operational timer function.
- **Up Arrow (▲):** Increases settings (e.g., temperature, flame intensity).
- **Down Arrow (▼):** Decreases settings (e.g., temperature, flame intensity).

4. Troubleshooting

- **Remote not responding:**
  - Ensure fresh AAA batteries are installed with correct polarity.
  - Check for any obstructions between the remote and the fireplace/heater unit.
  - Verify that the remote is pointed directly at the unit's infrared receiver.
  - Confirm your fireplace/heater model is listed as compatible.
- **Intermittent operation:**
  - Replace batteries if they are low.
  - Clean the remote's infrared emitter and the unit's receiver with a soft, dry cloth.

5. Specifications

Model	T-B16
Brand	YING RAY
Power Source	2 x AAA 1.5V Batteries (not included)
Technology	Infrared (IR)
Special Feature	Ergonomic design

6. Maintenance

- Keep the remote control dry and away from extreme temperatures.
- Clean the remote with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.

7. Warranty and Support

This product is manufactured by ZHUHAI YINGRAY TRADING CO., LTD. For support or inquiries regarding this replacement remote control, please contact your retailer or the manufacturer directly.

Please retain your purchase receipt for any warranty claims.

© 2023 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091F58JNT

More documents and user manuals: **https://manuals.plus/**