Midea FS40-7ARB

Midea FS40-7ARB 16-Inch Stand Fan User Manual

Model: FS40-7ARB

1. Introduction

Thank you for choosing the Midea FS40-7ARB 16-inch Stand Fan. This manual provides important information regarding the safe operation, assembly, maintenance, and troubleshooting of your fan. Please read this manual thoroughly before using the appliance and retain it for future reference.
The Midea FS40-7ARB is designed to provide efficient and quiet air circulation, featuring multiple operating speeds, a digital panel, and various modes for enhanced comfort.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Ensure the power supply voltage matches the rating label on the fan.
- Always unplug the fan from the power outlet before cleaning, assembling, or disassembling parts.
- Do not insert fingers or any objects through the grill when the fan is operating.
- Keep the fan away from water or other liquids. Do not use it in wet areas like bathrooms.
- Do not operate the fan with a damaged cord or plug. Contact qualified service personnel for repair.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Package Contents

Before assembly, please check that all components listed below are present in the package:

- Fan Motor Housing with Control Panel
- Front and Rear Grills
- Fan Blades (5 blades)

- Stand Pole (Adjustable)
- Round Base
- Remote Control
- Power Cord (attached to motor housing)
- Fasteners (nuts, screws, washers)
- User Manual (this document)

4. Setup and Assembly

Follow these steps to assemble your Midea Stand Fan:

1. **Attach the Stand Pole to the Base:** Insert the bottom end of the adjustable stand pole into the round base. Secure it firmly using the provided large screw and washer from underneath the base.



Image: Illustrates the fan's base and lower stand pole, indicating where the pole connects to the base.

2. **Mount the Motor Housing:** Place the fan motor housing onto the top of the stand pole. Ensure it clicks securely into place or is fastened with the designated screw/knob.
3. **Install the Rear Grill:** Remove the spinner cap and plastic nut from the motor shaft. Place the rear grill onto the motor housing, aligning the locating pins. Secure it with the plastic nut, tightening it clockwise.
4. **Attach the Fan Blades:** Slide the fan blades onto the motor shaft, ensuring the notch on the blades aligns with the pin on the shaft. Secure the blades with the spinner cap, tightening it counter-clockwise.
5. **Install the Front Grill:** Align the front grill with the rear grill, ensuring the clips or locking mechanism engage properly. Secure the two grills together using the provided clips or screws around the rim.



Image: Shows the complete Midea Stand Fan, illustrating the final assembled product with all components in place.

6. **Adjust Height:** Loosen the height adjustment knob on the stand pole, adjust to desired height, and tighten the knob firmly.

5. Operating Instructions

Your Midea FS40-7ARB fan offers various settings for customized comfort:

Control Panel and Remote Control

The fan can be operated using the digital control panel on the motor housing or the included remote control. Ensure the remote control has working batteries.

Functions:

- **Power ON/OFF:** Press the 'Power' button to turn the fan on or off.
- **Speed Settings:** The fan features 4 operating speeds. Press the 'Speed' button repeatedly to cycle through Low, Medium, High, and Turbo settings.
- **Modes:** Select from Normal, Natural, and Sleep modes using the 'Mode' button.
  - *Normal Mode:* Constant airflow at the selected speed.
  - *Natural Mode:* Simulates natural breeze by varying fan speed.
  - *Sleep Mode:* Gradually decreases fan speed over time for quiet operation during sleep.
- **Timer Function:** Set the fan to automatically turn off after a specified period (e.g., 1-8 hours) using the 'Timer' button. Each press increases the timer setting.
- **Oscillation:** Press the 'Swing' or 'Oscillation' button to enable or disable the fan's head oscillating from side to side for wider air distribution.
- **Electronic Thermostat:** The fan may include an electronic thermostat to maintain a desired room temperature (refer to digital panel for specific temperature display/setting).

6. Maintenance and Cleaning

Regular cleaning will help maintain your fan's performance and extend its lifespan.

- **Always unplug the fan** from the power outlet before cleaning.
- **Cleaning the Grills and Blades:** Use a soft, damp cloth to wipe the exterior surfaces. For thorough cleaning, the front grill can be removed (refer to assembly steps in reverse) to access the blades. Wipe blades gently to remove dust.
- **Do not use abrasive cleaners, waxes, or solvents** as they may damage the surface.
- **Do not immerse the fan in water** or allow water to drip into the motor housing.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging to protect it from dust.

7. Troubleshooting

If you experience issues with your Midea fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; Power cord not plugged in; Remote control batteries dead.	Check power outlet; Ensure plug is fully inserted; Replace remote control batteries.
Weak airflow.	Fan speed set too low; Grills or blades are dusty.	Increase fan speed; Clean the fan grills and blades.
Fan makes unusual noise.	Loose parts; Fan not on a stable surface; Obstruction in blades.	Check for loose screws/parts and tighten; Place fan on a flat, stable surface; Unplug and check for obstructions around blades.

Problem	Possible Cause	Solution
Remote control not working.	Dead batteries; Obstruction between remote and fan sensor.	Replace batteries; Ensure clear line of sight to fan's sensor.

If the problem persists after trying these solutions, please contact Midea customer support.

8. Specifications

Feature	Description
Brand	Midea
Model Number	FS40-7ARB
Type	Stand Fan (Pedestal Fan)
Size	16 Inch (40cm)
Operating Speeds	4 (with Remote Control Function)
Blades	5 blades rotation
Control	Digital Panel / Remote Control
Modes	Normal, Natural, and Sleep modes
Timer	Yes
Thermostat	Electronic thermostat
Noise Level	Very silent operation
Color	Black
Power Source	Corded Electric
Included Components	Cord, Remote

9. Warranty and Support

Midea products are manufactured to the highest quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Midea website. Keep your purchase receipt as proof of purchase.
For technical support, spare parts, or service inquiries, please contact Midea customer service through their official channels. You can often find contact information on the Midea website or on your product packaging.
Visit the Midea Store on Amazon for more products and information.

© 2024 Midea. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question