Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LAWOHO 890MAX

LAWOHO 890MAX Universal Garage Door Remote Instruction Manual

Model: 890MAX

1. Introduction

The LAWOHO 890MAX Universal Garage Door Remote is designed for compatibility with various garage door openers. This remote can control up to three garage door openers or gates and utilizes 315MHz/390MHz rolling code technology for secure access. Its compact design allows for easy portability on a keychain, in a pocket, or a purse.
Compatibility: This remote is compatible with Liftmaster, Chamberlain, and Craftsman garage door opener motors that feature Yellow, Red, Orange, Purple, or Green learn buttons.

2. Important Safety Information

- Always ensure the garage door area is clear of people, pets, and objects before operating the garage door.
- Keep the remote control out of reach of children.
- Do not allow children to operate the garage door opener.
- Only operate the garage door when it is in full view and free of obstructions.
- If the remote control is lost or stolen, reprogram your garage door opener immediately to prevent unauthorized access.

3. Package Contents

Verify that all items are present in your package:

- 2 x LAWOHO 890MAX Universal Garage Door Remotes
- 2 x Metal Keychains
- 1 x Product Instruction Manual



Image: Package contents including two remotes, two metal keychains, and the instruction manual.

4. Setup and Programming

Follow these steps to program your LAWOHO 890MAX remote control to your garage door opener.

4.1. Step 1: Identify Your Garage Door Opener's Learn Button Color

You will need a stepladder to access your garage door opener motor unit. Locate the 'Learn' button on the motor unit. The color of this button is crucial for programming.



Image: Examples of garage door opener motor units with different colored learn buttons (Yellow, Purple, Red, Orange, Green).



Image: Compatibility table detailing learn button colors, frequencies, years, and compatible models for various garage door opener brands.

4.2. Step 2: Pre-program the Remote Control

1. Press and hold the small 'program button' located at the bottom right of the remote control using a safety pin. Hold for approximately 3-5 seconds until the indicator light begins to flash (it will flash 4 times), then release the button.
2. Choose one of the three remote control buttons you wish to use. Press this button a specific number of times based on your garage door opener's frequency or the color of its learn button:
    - Press **1 time** for Security+ 2.0 (Yellow Learn Button)
    - Press **2 times** for 315 MHz Security+ (Purple Learn Button)
    - Press **3 times** for 390 MHz Security+ (Red or Orange Learn Button)
    - Press **4 times** for 390 MHz Billion Code (Green Learn Button)
3. After selecting the button and pressing it the required number of times, press the 'program button' two times to confirm. The indicator light will illuminate on the second press.

At this point, the remote control is pre-programmed. Proceed to the next step to sync it with your garage door opener.

4.3. Step 3: Sync with Your Garage Door Opener Receiver

1. On your garage door opener motor unit, press and release the 'Learn' button. The learn indicator light on the motor unit will glow steadily for 30 seconds.
2. Within these 30 seconds, press the remote control button (the same button you used in Step 2) until the light on your garage door opener flashes or you hear two clicks (if a light bulb is not installed).
3. Test the remote by pressing the programmed button. The garage door should activate.

Your browser does not support the video tag.

Video: Detailed instructions on how to program the LAWOHO 890MAX garage door remote with a compatible opener.



Image: Visual guide for programming the remote control.

5. Operating the Remote Control

Once programmed, operating the LAWOHO 890MAX remote is straightforward:

- Press the programmed button on the remote control to open or close your garage door.
- The remote supports up to three different garage doors or gates, with each button controlling a separate device.



Image: Remote in use, opening a garage door.

6. Maintenance

6.1. Battery Replacement

The LAWOHO 890MAX remote uses one CR2 battery. If the remote's indicator light does not illuminate or the range decreases significantly, it may be time to replace the battery.

1. Locate the small slot on the side of the remote control.
2. Carefully insert a small flat-head screwdriver or a coin into the slot and gently pry open the remote casing.
3. Remove the circuit board. The battery is located on the circuit board.
4. Carefully remove the old CR2 battery.
5. Insert a new CR2 battery, ensuring the positive (+) side is facing up.
6. Reassemble the remote control casing, ensuring it snaps securely into place.

Your browser does not support the video tag.

Video: Instructions on how to replace the battery in the LAWOHO 890MAX remote control.



Image: Remote control with an arrow indicating the battery access point.

7. Troubleshooting

If you encounter issues with your LAWOHO 890MAX remote, refer to the following common solutions:

- **Remote not working after programming:** Double-check that you selected the correct number of presses for your garage door opener's learn button color/frequency during Step 2 of programming. Repeat the programming steps carefully.
- **Remote has poor range:** Ensure the battery is not low. Replace the battery if necessary (refer to Section 6.1). Obstructions between the remote and the garage door opener can also reduce range.
- **Indicator light not flashing during programming:** Ensure you are holding the program button for the correct duration (3-5 seconds) and releasing it when the light starts flashing. If the battery is new, try replacing it.
- **Garage door opener not responding during syncing:** Ensure the learn button on your garage door opener was pressed and its indicator light is glowing steadily before pressing the remote button. Make sure you are within the 30-second window.

8. Specifications

Feature	Detail
Model Number	890MAX
Brand	LAWOHO
Manufacturer	LAWOHO
Item Weight	2.82 ounces
Package Dimensions	3.98 x 2.68 x 0.87 inches
Batteries	1 CR2 battery required (included)
Battery Cell Type	Alkaline (CR2, 12V)
Item Package Quantity	1 (for 2-pack variant)
Special Feature	Ergonomic

Max Number of Supported Devices	3
Compatible Devices	Liftmaster, Sears Craftsman, Chamberlain (370LM, 971LM, 891LM, etc.) with Red, Orange, Yellow, Purple, Green Learn Buttons (315MHz, 390MHz)

9. Warranty and Customer Support

LAWOHO provides professional customer service to address any issues you may encounter after purchasing the remote. If you experience problems, please contact LAWOHO customer support for assistance. A full money-back guarantee is offered within 90 days of purchase.
For support, please refer to the contact information provided with your purchase or visit the official LAWOHO website.

© 2023 LAWOHO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091K9N8MD

More documents and user manuals: **https://manuals.plus/**