TEKMAGIC 751315216081

TEKMAGIC 751315216081 100M Water Resistant Digital Sports Watch User Manual

Model: 751315216081

1. Introduction

Thank you for choosing the TEKMAGIC 751315216081 Digital Sports Watch. This watch is designed for active individuals, featuring a robust 100-meter water resistance, making it suitable for swimming, diving, and various water sports. It includes essential functions such as a stopwatch, alarm, dual time zone display, and backlight. This manual provides detailed instructions to help you set up and operate your watch effectively.



Image 1.1: The TEKMAGIC Digital Sports Watch, highlighting its water resistance for activities like scuba diving.

2. Setup and Initial Configuration

Before using your watch, please ensure it is properly set up. The watch comes with a pre-installed battery (CR2025).

2.1 Button Functions Overview



Image 2.1: Overview of watch buttons and their primary functions.

- **SET Button (Top Left):** Used to enter and confirm settings.
- **MODE Button (Bottom Left):** Cycles through different modes (Time, Chronograph, Alarm, Timer, Dual Time).
- **ADJ Button (Top Right):** Adjusts values during setting.
- **LIGHT Button (Bottom Right):** Activates the backlight.

2.2 Setting Time and Date

1. From the normal time display, press and hold the**SET** button until the seconds start flashing. This indicates you are in setting mode.
2. Press the **MODE** button to cycle through the settings: Seconds → Hour → Minute → 12/24 Hour Format → Month → Date → Day of Week.
3. Use the **ADJ** button to increase the flashing value. Hold**ADJ** for faster adjustment.
4. Once all settings are adjusted, press the**SET** button to exit the setting mode and save your changes.

Note: If no button is pressed for a period during setting, the watch may automatically exit setting mode.

2.3 Adjusting the Strap

The watch features a comfortable TPU strap with a buckle clasp. Adjust the strap to fit your wrist securely but not too tightly. The strap is designed to accommodate wrist circumferences from 160mm to 215mm.



Image 2.2: Watch dimensions and strap adjustment range.

3. Operating Instructions

3.1 Mode Selection

Press the **MODE** button to cycle through the following functions:

- Normal Time Display
- Chronograph (Stopwatch)
- Alarm
- Timer (Countdown)

- Dual Time Zone

3.2 Using the Chronograph (Stopwatch)

1. Press **MODE** until "CHRONO" or "STW" appears on the display.
2. Press **ADJ** to start the stopwatch.
3. Press **ADJ** again to pause the stopwatch.
4. To reset, press **SET** while the stopwatch is paused.



Image 3.1: The watch displaying the stopwatch function.

3.3 Setting and Using the Alarm

1. Press **MODE** until "ALARM" appears.
2. Press and hold **SET** until the hour digits flash.
3. Use **ADJ** to set the desired hour.
4. Press **MODE** to move to the minute setting, then use **ADJ** to set the minutes.

5. Press **SET** to confirm and exit.
6. To activate/deactivate the alarm, press **ADJ** while in Alarm mode (without holding **SET**). An alarm icon will appear/disappear.



Image 3.2: The watch displaying alarm and calendar features.

3.4 Using Dual Time Zone

1. Press **MODE** until "DUAL TIME" or "T2" appears.
2. Press and hold **SET** until the hour digits flash.
3. Use **ADJ** to set the desired hour for the second time zone.
4. Press **MODE** to move to the minute setting, then use **ADJ** to set the minutes.
5. Press **SET** to confirm and exit.



Image 3.3: The watch displaying the dual time zone function.

3.5 Activating the Backlight

Press the **LIGHT** button (bottom right) to illuminate the display for easy viewing in low-light conditions. The backlight will remain on for a few seconds.



Image 3.4: The watch display with backlight activated.

3.6 Hourly Chime

The watch has an hourly chime function. To activate or deactivate it, navigate to the normal time display. Press the **SET** button once (do not hold). The chime icon will appear or disappear, indicating its status.

4. Maintenance

4.1 Water Resistance

This watch is water resistant up to 10 ATM (100 meters). This means it is suitable for swimming, snorkeling, and recreational diving. Do not press any buttons while the watch is submerged in water to prevent water ingress. Avoid exposing the watch to hot water or steam, as this can compromise the seals.

4.2 Battery Replacement

The watch uses a CR2025 battery, which typically lasts 1.5 to 2 years. If the display becomes dim or the watch stops

functioning, it is likely time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure the water resistance seal is maintained.

4.3 Cleaning

Clean the watch regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly. Avoid using harsh chemicals or abrasive materials.

5. Troubleshooting

5.1 Watch Not Functioning or Display Unclear

- **Issue:** The watch display is blank, dim, or showing incorrect characters.
- **Solution:** The battery may be depleted. Replace the CR2025 battery. It is recommended to have this done by a professional to ensure water resistance.

5.2 Difficulty Setting Time/Date

- **Issue:** Unable to set the correct time or date, or settings revert.
- **Solution:** Ensure you are pressing and holding the **SET** button long enough to enter the setting mode (seconds flashing). Cycle through settings using **MODE** and adjust values with **ADJ**. Always press **SET** to confirm and exit the setting mode. If the issue persists after a battery change, contact support.

5.3 Watch Strap Breaks

- **Issue:** The watch strap breaks or detaches.
- **Solution:** The strap is made of TPU. While durable, excessive force or wear can cause damage. Replacement straps may be available from the manufacturer or third-party retailers.

6. Specifications

Brand	TEKMAGIC
Model Number	751315216081 (W60-UK-RD)
Display Type	Digital
Movement	Japanese Quartz
Water Resistance Depth	100 Meters (10 ATM)
Case Material	Resin
Dial Window Material	High Transparency Resin
Band Material	TPU (Thermoplastic Polyurethane)
Clasp Type	Buckle
Case Diameter	55 mm
Case Thickness	18 mm
Band Width	22 mm

Wrist Circumference (Min/Max)	160 mm / 215 mm
Battery Type	CR2025 (Included)
Battery Life	1.5 to 2 years
Product Weight	62 Grams
Special Features	Alarm, Countdown Timer, Chronograph, Dual Time Zone, 12/24 Hour Format, Backlight, Hourly Chime, Calendar

7. Warranty and Support

For information regarding warranty coverage, please refer to the documentation provided with your purchase or contact the retailer.
If you encounter any issues not covered in this manual or require further assistance, please contact TEKMAGIC customer support through their official website or the retailer where the product was purchased. Please have your model number (751315216081) and purchase details ready.

© 2023 TEKMAGIC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question