Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Shop Japan CKP-AM04

Shop Japan Cooking Pro CKP-AM04 Electric Pressure Cooker User Manual

Model: **CKP-AM04** | Brand: **Shop Japan**

1. Introduction

The Shop Japan Cooking Pro CKP-AM04 is an advanced 8-in-1 electric pressure cooker designed to simplify your cooking process. This appliance combines the functions of pressure cooking, steaming, slow cooking, stewing, waterless cooking, frying, reheating, and rice cooking into a single, convenient unit. Its "Quick Touch Technology" features pre-set time and temperature settings for various ingredients and cooking methods, allowing for efficient meal preparation.

This manual provides essential information for the safe and effective use of your Cooking Pro CKP-AM04. Please read it thoroughly before operating the appliance and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent injury or damage, always adhere to the following safety precautions:

- Read all instructions carefully before using the appliance.
- Do not immerse the main unit, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children and pets.
- Ensure the lid is properly sealed before starting any pressure cooking function.
- Do not touch hot surfaces. Use handles or oven mitts.
- Always unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.
- Use only accessories and attachments recommended by the manufacturer.
- Ensure adequate ventilation around the appliance during operation.

3. Package Contents

Upon unpacking, verify that all the following items are included:

- Main unit
- Lid
- Inner cover
- Inner pot
- Saucepan
- Power cord
- Rice scoop
- Measuring cup
- Cleaning pins
- Instruction manual

4. Product Overview

Familiarize yourself with the components of your electric pressure cooker.



Image showing the complete Shop Japan Cooking Pro CKP-AM04 Electric Pressure Cooker with its lid.

The main unit houses the heating element and control panel. The lid features a sealing mechanism and pressure release valve. The removable inner pot is where food is cooked.

5. Setup

Before first use, follow these steps:

1. Remove all packaging materials and labels from the appliance.
2. Wash the inner pot, lid, inner cover, saucepan, rice scoop, and measuring cup with warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
4. Place the inner pot inside the main unit, ensuring it is seated correctly.
5. Place the appliance on a stable, level, heat-resistant surface, away from walls or other appliances to allow for proper ventilation.

6. Connect the power cord to the appliance and then to a suitable electrical outlet.

6. Operating Instructions

The Cooking Pro CKP-AM04 offers 8 cooking functions. Follow these general steps for operation:

1. Prepare your ingredients and place them into the inner pot.
2. Secure the lid onto the main unit, ensuring it is properly locked and sealed according to the markings.
3. Select your desired cooking function using the control panel. The "Quick Touch Technology" provides pre-set programs for common dishes.
4. Adjust cooking time or temperature if necessary, based on your recipe.
5. Press the Start button to begin cooking. The appliance will automatically adjust pressure and temperature.
6. Once cooking is complete, the appliance may switch to a Keep Warm setting. Carefully release pressure before opening the lid, following the instructions for your specific recipe.

Examples of Cooking Times:

- Rice: Approximately 15 minutes under pressure.
- Boiled Squid: Approximately 8 minutes.

The integrated timer function allows you to set the appliance to start cooking at a later time, accommodating your meal schedule.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

- Always unplug the pressure cooker and allow it to cool completely before cleaning.
- The non-stick inner pot is easy to clean. Wash it with warm, soapy water and a soft sponge. Rinse thoroughly and dry.
- **Note:** The inner pot is **not** dishwasher safe.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scourers.
- Clean the lid, including the sealing ring and pressure release valve, after each use to prevent food buildup. Ensure all parts are dry before reassembling.
- Use the provided cleaning pins to clear any blockages in the pressure release valve or float valve if necessary.

8. Troubleshooting

If you encounter issues with your Cooking Pro CKP-AM04, refer to the following common solutions:

- **Appliance does not turn on:** Ensure the power cord is securely plugged into both the appliance and a working electrical outlet. Check your household circuit breaker.
- **Pressure not building:** Verify that the lid is properly closed and sealed. Check the sealing ring for damage or improper placement. Ensure the pressure release valve is in the sealed position.
- **Food not cooking properly:** Confirm that the correct cooking function and time were selected. Ensure sufficient liquid is added for pressure cooking.
- **Steam leaking from lid:** Check the sealing ring for proper installation and any damage. Ensure the lid is securely closed.

For issues not resolved by these steps, please contact customer support.

9. Specifications

Feature	Specification
Brand	Shop Japan
Model Number	CKP-AM04
Capacity	3.2 Liters
Material	PP, steel, aluminum, etc.
Color	Black
Finish Type	Enamel
Special Feature	Keep Warm Setting
Wattage	700 watts
Item Weight	3.6 Kilograms (7.92 pounds)
Control Method	Touch
Dishwasher Safe	No (Inner Pot)
Voltage	100 Volts
Product Dimensions (L x W x H)	10.75 x 11.22 x 11.61 inches (273 x 285 x 295 mm)
Date First Available	June 28, 2022

10. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact Shop Japan customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Shop Japan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091L6Y9WP

More documents and user manuals: **https://manuals.plus/**