TASER TASER 7CQ

TASER 7CQ Professional Series Instruction Manual

Model: TASER 7CQ (Model 39066)
Brand: TASER

1. Introduction

The TASER 7CQ Professional Series is an advanced personal and home defense device designed for civilian use. It incorporates technology trusted by law enforcement agencies worldwide, offering effective protection against aggressive assailants. This manual provides essential information for the safe and proper use, setup, and maintenance of your TASER 7CQ device.



Image: The TASER 7CQ Professional Series device, showcasing its compact and ergonomic design.

2. Package Contents

Your TASER 7CQ Professional Series kit includes the following components:

- One (1) TASER 7CQ Device
- One (1) 7CQ Replaceable Battery Pack
- Two (2) Cartridges
- One (1) Conductive Practice Target
- One (1) Rugged Carrying Case



Image: All components included in the TASER 7CQ Professional Series kit.

3. Key Features

The TASER 7CQ device is engineered with several key features to enhance its effectiveness and user experience:

- **Dual-Shot Capability:** Holds two cartridges, allowing for a backup or follow-up probe deployment against one or multiple attackers.
- **Improved Darts:** Dual-shot darts fly straighter and faster, delivering nearly twice the kinetic energy for better target connection.
- **Adaptive Cross Connect:** Probes are designed to achieve optimal spread when deployed as close as 4 feet away from a subject. Electricity is intentionally driven between all contacts to maximize effectiveness.
- **Extended Range:** Features a 12-foot range for effective deployment.
- **Contact Stun:** Provides a direct contact stun capability for close-quarters defense.
- **5-Second Cycle:** Delivers a 5-second exposure cycle upon deployment.
- **Central Information Display (CID):** Provides critical device status information.
- **LED Flashlight:** Integrated light for improved visibility.



Image: Detailed diagram highlighting the various components and features of the TASER 7CQ.



Image: Visual representation of the TASER 7CQ's optimized close-range performance.

4. Setup

Before operating your TASER 7CQ device, ensure it is properly set up:

1. **Battery Installation:** Insert the 7CQ Replaceable Battery Pack into the device's handle. Ensure it clicks securely into place.
2. **Cartridge Loading:** Load the cartridges into the front of the device. The TASER 7CQ supports two cartridges for dual-shot capability. Ensure they are firmly seated.
3. **Familiarization:** Before carrying, familiarize yourself with the device's safety switch and trigger mechanism. Practice engaging and disengaging the safety.
4. **Practice Target Use:** Utilize the included conductive practice target to understand the device's range and dart spread in a safe, controlled environment.



Image: Proper installation of the battery pack into the TASER 7CQ device.

5. Operating Instructions

Follow these steps for safe and effective operation of your TASER 7CQ device:

1. **Assess the Threat:** Only deploy the device when faced with an immediate threat to personal safety or the safety of others.
2. **Disengage Safety:** Move the safety switch to the 'FIRE' position.
3. **Aim:** Aim the device at the target's center mass. The integrated laser will assist with aiming.
4. **Deploy:** Press the trigger to deploy the probes. The device will deliver a 5-second electrical cycle.
5. **Contact Stun (if necessary):** If probes do not make contact or if the situation requires, the device can be pressed directly against the subject for a contact stun.
6. **Re-engage Safety:** After use, immediately re-engage the safety switch to the 'SAFE' position.
7. **Reload:** If cartridges were deployed, replace them with new ones as soon as it is safe to do so.

WARNING: Always handle the TASER 7CQ with extreme caution. Misuse can result in serious injury or death. Adhere to all local laws and regulations regarding the ownership and use of conducted energy

devices.

6. Maintenance

Proper maintenance ensures the longevity and reliability of your TASER 7CQ device:

- **Cleaning:** Keep the device clean and free of dust and debris. Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in its rugged carrying case in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it out of reach of children and unauthorized users.
- **Battery Check:** Regularly check the battery level via the Central Information Display (CID). Replace the battery pack when indicated or as needed to ensure optimal performance.
- **Cartridge Inspection:** Inspect cartridges for any damage before loading. Do not use damaged cartridges.

7. Troubleshooting

If you encounter issues with your TASER 7CQ device, consider the following common troubleshooting steps:

- **Device Not Firing:**
  - Ensure the safety switch is fully disengaged (in the 'FIRE' position).
  - Check if a cartridge is properly loaded and seated.
  - Verify the battery level. A low battery may prevent operation.
- **No Arc/Spark:**
  - Confirm the battery is fully charged or replaced.
  - Ensure the cartridge is correctly installed.
- **CID Not Displaying:**
  - Check battery connection and charge level.
  - Ensure the device is powered on (if applicable).

If problems persist after attempting these steps, do not attempt to repair the device yourself. Contact TASER customer support for assistance.

8. Specifications

Attribute	Detail
Model Name	TASER 7CQ (Model 39066)
Manufacturer	Axon Enterprises, Inc.
Range	12 feet
Exposure Cycle	5 seconds
Dimensions (LxW)	7.45"L x 1.65"W
Item Weight	9.6 ounces
Material	Plastic

Attribute	Detail
Color	Yellow
UPC	796430202137

9. Warranty and Support

Your TASER 7CQ Professional Series device is covered by a Manufacturer's Warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty documentation included with your product or visit the official TASER website.

For technical support, troubleshooting assistance beyond what is provided in this manual, or to inquire about replacement parts and accessories, please contact TASER customer service. Contact information can typically be found on the manufacturer's website or in your product packaging.

Online Resources: For additional information, FAQs, and product registration, please visit the official TASER website: www.axon.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question