**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**VGR V-071**

# VGR V-071 Rechargeable Hair Clipper

User Instruction Manual

## 1. Important Safety Information

Please read all safety instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always keep the trimmer away from water sources.
- Avoid contact with skin and eyes.
- Use it once a day and clean it after each use.
- Do not use on infants.
- Always unplug and allow to cool before cleaning.
- Always replace guards and combs after use.

## 2. Product Overview

The VGR V-071 is a professional rechargeable hair clipper designed for precise grooming. Familiarize yourself with its components and included accessories.

### 2.1 Main Unit

*Image: Front and back view of the VGR V-071 hair clipper, showing the power button, indicator light, and model information on the back.*

1. **Blade Set:** High-precision alloy steel blades for efficient cutting.
2. **Power Button:** Press to turn the clipper on/off and cycle through speed settings.
3. **Speed Indicator Light:** Displays the current operating speed.
4. **Charging Indicator Light:** Shows charging status.
5. **USB Charging Port:** For recharging the built-in battery.

### 2.2 Included Accessories

*Image: All accessories included with the VGR V-071 hair clipper, including guide combs, USB charging cable, cleaning brush, and lubricating oil.*

- **Guide Combs:** Various sizes (e.g., 1mm, 2mm, 3mm) for different hair lengths.

- **USB Charging Cable:** For convenient charging.
- **Cleaning Brush:** To remove hair clippings from the blades.
- **Lubricating Oil:** For blade maintenance.

## 3. Setup

### 3.1 Initial Charging

Before first use, fully charge the hair clipper. This typically takes about 1.5 hours.

1. Connect the USB charging cable to the clipper's charging port.
2. Plug the other end of the USB cable into a suitable USB power adapter (not included) or a computer USB port.
3. The charging indicator light will illuminate during charging. It will change or turn off once fully charged.

### 3.2 Attaching Guide Combs

Select the desired guide comb for your preferred hair length.

- Align the guide comb with the clipper blade.
- Push the comb firmly until it clicks into place.
- To remove, gently pull the comb away from the blade.

## 4. Operating Instructions

### 4.1 Power On/Off and Speed Adjustment



*Image: Close-up of the VGR V-071 hair clipper showing the power button and indicator lights for two-speed adjustment (middle and high gears).*

1. Press the power button once to turn on the clipper at the default speed (e.g., middle gear).
2. Press the power button again to switch to the higher speed (high gear).
3. Press the power button a third time to turn off the clipper.

### 4.2 Trimming Hair

For best results, ensure hair is clean and dry before trimming.

- Start with a longer guide comb if you are unsure of the desired length.
- Hold the clipper with the blade flat against the skin.
- Move the clipper slowly against the direction of hair growth.
- Overlap strokes to ensure an even cut.
- For detailing or edging, remove the guide comb and use the bare blade carefully.

## 5. Maintenance

### 5.1 Cleaning the Blades

Clean the blades after each use to maintain performance and hygiene.

1. Ensure the clipper is turned off and unplugged.
2. Use the provided cleaning brush to brush away any loose hair from the blades.
3. For a more thorough clean, you may carefully detach the blade head (refer to specific instructions if applicable for

your model) and rinse under running water, ensuring the main body does not get wet. Dry thoroughly before reattaching.

### 5.2 Oiling the Blades

Regular oiling ensures smooth operation and extends blade life.

- After cleaning, apply 1-2 drops of the lubricating oil onto the blades.
- Turn on the clipper for a few seconds to distribute the oil evenly.
- Wipe off any excess oil with a soft cloth.

## 6. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Clipper does not turn on | Battery is low or depleted | Charge the clipper fully. |
| Clipper pulls hair or cuts poorly | Blades are dull, dirty, or not oiled | Clean and oil the blades. If still poor, blades may need replacement. |
| Clipper makes unusual noise | Blades are misaligned or dirty | Clean and oil the blades. Check for any obstructions. |

## 7. Specifications

| Feature | Detail |
|---|---|
| Model Number | VGR V-071 |
| Power Source | Battery Powered (Rechargeable) |
| Battery Type | Requires 1 AAA battery (internal) |
| Battery Charge Time | 1.5 hours |
| Blade Material | Alloy Steel |
| Material | Alloy Steel |
| Item Dimensions (L x W x H) | 14 x 8 x 4 cm |
| Item Weight | 250 grams |
| Color | Silver |
| Operation Mode | Cordless |
| Maximum Cutting Length | 3 millimeters (with shortest comb) |
| Number of Settings | 5 (implied by comb sizes/speed settings) |
| Country of Origin | China |

## 8. Warranty and Support

### 8.1 Warranty Information

This VGR V-071 Hair Clipper comes with a limited one-year warranty from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

### 8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact your retailer or the official VGR customer support channel. Please have your product model number and proof of purchase ready when contacting support.

You can often find support contact information on the product packaging or the official VGR website.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B092312R94**

More documents and user manuals: **https://manuals.plus/**