**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Innsky IS-AF005

# Innsky 1.8L Electric Air Fryer User Manual

Model: IS-AF005 | Brand: Innsky

## 1. Introduction

Thank you for purchasing the Innsky 1.8L Electric Air Fryer, Model IS-AF005. This appliance is designed to provide a healthy and convenient way to cook your favorite fried foods with significantly less oil. Please read this manual thoroughly before use to ensure safe operation and optimal performance. Keep this manual for future reference.




Image: The Innsky 1.8L Electric Air Fryer, showcasing its compact design and the variety of dishes it can prepare, including chicken wings, shrimp, and fries.

## 2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The air fryer operates in a closed environment, eliminating oil splattering.
- Equipped with overheat protection to reduce fire risk from abnormal voltage.
- Removing the basket automatically powers off the unit; reinserting it automatically powers it on.

## 3. Product Components

Familiarize yourself with the parts of your Innsky Air Fryer.

**Main Unit:** Houses the heating element and fan.

**Control Panel:** LED touch display for settings.

**Frying Basket:** Non-stick coated basket for food.

**Basket Handle:** For safe removal and insertion of the basket.

**Air Outlet:** Located at the back for hot air exhaust.




Image: Detailed view of the Innsky Air Fryer's LED touch control panel, highlighting temperature and time settings, and various cooking presets.

## 4. Setup

1. **Unpacking:** Carefully remove all packaging materials and stickers.
2. **Initial Cleaning:** Wash the frying basket and any removable accessories with hot water, dish soap, and a non-abrasive

sponge. Wipe the inside and outside of the main unit with a damp cloth.

3. **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and 10 cm (4 inches) above the appliance.
4. **First Use (Odor Removal):** Before first use, it is recommended to run the air fryer empty for about 10-15 minutes with lemon or orange peels inside to eliminate any manufacturing odors. This process may produce a slight plastic smell, which is normal and will dissipate with subsequent uses.
5. **Power Connection:** Plug the power cord into a grounded wall outlet.

## 5. Operating Instructions

### 5.1 Basic Operation

1. **Prepare Food:** Place your ingredients into the frying basket. Do not overfill the basket.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks into place. The unit will automatically power on.
3. **Power On:** Press the power button on the LED touch panel.
4. **Select Preset or Manual Settings:**
    - **Presets:** Choose from 7 preset cooking functions (e.g., potato chips, steak, chicken, shrimp) by tapping the corresponding icon.
    - **Manual:** Adjust the temperature (80°C to 200°C) and time (0 to 60 minutes) using the '+' and '-' buttons.
5. **Start Cooking:** Press the start button to begin the cooking process. The air fryer features a unique warm-up function that preheats the unit before starting the main cooking cycle.
6. **Check Food:** You can remove the basket at any time during cooking to shake or check the food. The air fryer will automatically pause and resume once the basket is reinserted.
7. **Finish Cooking:** The timer will beep when cooking is complete. Carefully remove the basket and transfer the food to a serving plate.




Image: A hand touching the LED display of the Innsky Air Fryer, demonstrating the ease of selecting cooking settings.

## 5.2 Auto Pause/Resume Feature

The Innsky Air Fryer is designed for convenience and safety. If you remove the frying basket during operation to check or shake your food, the appliance will automatically pause. Once the basket is securely reinserted, the cooking cycle will automatically resume from where it left off.




Image: Illustration of the air fryer's automatic pause function when the basket is pulled out and automatic resume when it is pushed back in.

## 5.3 Healthy Cooking Benefits

The Innsky Air Fryer utilizes 360° high-speed hot air circulation to cook food, effectively using the food's natural oils. This method allows for up to an 80% reduction in fat intake compared to traditional deep frying, while preserving essential nutrients. Enjoy delicious and balanced meals.




Image: Diagram illustrating the 360-degree high-speed hot air circulation technology inside the Innsky Air Fryer, ensuring even cooking.




Image: A visual comparison highlighting the difference between air-fried food and traditionally deep-fried food, emphasizing the healthier aspect of air frying.

## 6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Clean Basket:** The non-stick coated frying basket is dishwasher safe. Alternatively, wash it with hot water, dish soap, and a non-abrasive sponge.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth and mild detergent. Do not use abrasive cleaners or steel wool.
4. **Clean Exterior:** Wipe the exterior with a damp cloth.
5. **Heating Element:** Clean the heating element with a cleaning brush to remove any food residues.
6. **Storage:** Ensure all parts are dry before storing the appliance.



Image: A hand cleaning the non-stick basket of the Innsky Air Fryer under running water, demonstrating its easy-to-clean design.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Air fryer does not turn on. | The appliance is not plugged in. The basket is not properly inserted. | Plug the power cord into a grounded wall outlet. Ensure the basket is fully pushed into the main unit. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Food is not cooked evenly. | Basket is overcrowded. Food pieces are too large. | Cook food in smaller batches. Cut food into smaller, more uniform pieces. Shake the basket halfway through cooking. |
| White smoke comes from the appliance. | Grease residue from previous use. Excess oil on food. | Clean the basket and interior thoroughly. Pat food dry before cooking, or use less oil if adding. |
| Appliance emits a plastic smell during first use. | New appliance odor. | This is normal. Run the air fryer empty with lemon or orange peels for 10-15 minutes before first use. The smell will dissipate with subsequent uses. |

## 8. Specifications

| | |
|---|---|
| **Brand Name** | Innsky |
| **Model Number** | IS-AF005 |
| **Product Dimensions (D x W x H)** | 23.2 x 30 x 31.4 cm |
| **Color** | White |
| **Capacity** | 1.8 Liters |
| **Item Weight** | 2.67 kg |
| **Wattage** | 1230 W |
| **Control Method** | Touch |
| **Minimum Temperature Setting** | 80 °C |
| **Maximum Temperature Setting** | 200 °C |
| **Non-stick Coating** | Yes |

## 9. Warranty and Support

Innsky provides a warranty for this product. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact Innsky customer service. Contact information can typically be found on the product packaging or the official Innsky website.
The product is PSE certified, ensuring compliance with Japanese electrical appliance safety standards.

© 2024 Innsky. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B092317SZH**

More documents and user manuals: **https://manuals.plus/**