AT&T CL82267

AT&T CL82267 DECT 6.0 2-Handset Cordless Phone User Manual

Model: CL82267

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your AT&T CL82267 DECT 6.0 2-Handset Cordless Phone system. This system features DECT 6.0 technology for enhanced range and clarity, a digital answering machine, Smart Call Blocker, Caller ID Announce, and intercom functionality. Please read this manual thoroughly to ensure proper use and to take full advantage of all features.

Image: The AT&T CL82267 DECT 6.0 2-Handset Cordless Phone system, showing the main base unit with a handset and a separate charging cradle with another handset. Both units feature a black and wood grain finish.

SETUP

1. Unboxing and Package Contents

Verify that your package contains the following items:

- Base unit
- 2 handsets
- 1 charger (for the second handset)
- 2 AC adaptors (one for the base, one for the charger)
- 2 battery packs
- Wall mount bracket
- Telephone line cord
- Quick start guide (refer to this full manual for complete instructions)

2. Battery Installation

1. Open the battery compartment cover on the back of each handset.
2. Connect the battery pack plug securely into the jack inside the compartment.
3. Place the battery pack with the label facing up.

4. Close the battery compartment cover.

Important: Use only the supplied battery packs. Ensure correct polarity when inserting the battery.

3. Connecting the Base Unit and Charger

1. Plug one end of the telephone line cord into the TEL LINE jack on the back of the base unit.

2. Plug the other end of the telephone line cord into a telephone wall jack.

3. Plug the small end of the base unit's AC adapter into the POWER jack on the back of the base unit.

4. Plug the large end of the base unit's AC adapter into an electrical outlet.

5. For the second handset, plug the small end of the charger's AC adapter into the POWER jack on the back of the charger.

6. Plug the large end of the charger's AC adapter into an electrical outlet.

Note: Use only the AC adapters provided with this product. Do not connect the telephone line cord to a broadband modem or router if you have DSL internet service without a DSL filter.

4. Initial Charging

Place each handset in its respective base unit or charger. The CHARGE light on the handset will illuminate, indicating proper charging. Allow the handsets to charge for at least 16 hours before initial use to ensure optimal battery performance.

OPERATING INSTRUCTIONS

1. Making and Receiving Calls

- **To Make a Call:** Press **PHONE** or **SPEAKER**, then dial the number.
- **To Answer a Call:** When the phone rings, press **PHONE** or **SPEAKER**.
- **To End a Call:** Press **OFF** or place the handset in the charger.

2. Digital Answering System

The integrated digital answering system can record up to 22 minutes of messages, announcements, and memos. A voice guide assists with setup.

Digital Answering System

"Hi, Johnson. Don't forget our meeting"

With up to 22 minutes of recording time, the digital answering system grabs calls when you can't.

Image: The digital answering system controls on the base unit, highlighting the playback buttons. The system records messages for later retrieval.

- **To Play Messages:** Press **PLAY/STOP** on the base unit.
- **To Turn On/Off:** Press **ANS ON/OFF** on the base unit.

3. Smart Call Blocker

The Smart Call Blocker feature helps filter unwanted calls. It can block up to 1,000 numbers.

Smart Call Blocker

Save time by not checking all calls, unlike other phones

One touch block

Smart Call Blocker (SCB) - Explainer*

Caller	SCB Action		CL8xx67 Series	
Address Book Calls, Star name List Calls	Call allowed	📞	Ringing	📞
Unknown Calls, Robo Calls	SCB instructions to caller	📞	Rejected	📵
			Answering Machine	📠
Block List Calls	Call rejected	📵	Rejected	📵

* For more details refer product support documents

Image: The handset's 'CALL BLOCK' button, illustrating the one-touch blocking feature. A diagram explains how the Smart Call Blocker handles various incoming call types.

- **To Block a Number:** During a call or after reviewing Caller ID, press the **CALL BLOCK** button on the handset.
- **Call Screening:** The system can announce callers and allow you to screen calls before answering.

4. Caller ID Announce

When a call comes in, the handset announces the name of the caller (if available in your directory or Caller ID service) so you know who is calling without looking at the display.

Image: The Caller ID Announce feature in action, showing a handset on its base unit with a speech bubble indicating an incoming call announcement.

5. Intercom

Use the intercom feature to communicate between handsets or between a handset and the base unit.

- **To Initiate Intercom:** Press **MENU/SELECT** on a handset, scroll to "Intercom", and select the desired destination handset or base.

6. Speakerphone

Each handset includes a simulated full-duplex speakerphone, allowing hands-free conversations where both parties can speak and be heard simultaneously.

Simulated Full-duplex Handset Speakerphone

Enjoy a speakerphone that can keep up with your calls. Increase participation by allowing both ends to speak—and be heard—at the same time for conversations that are more true to life.

Image: A user utilizing the simulated full-duplex speakerphone feature on a handset while performing another task in a kitchen setting.

7. Speed Dial

Program frequently called numbers into speed dial locations for quick access.

Image: A hand interacting with the handset keypad, highlighting the ability to use speed dial for quick calling.

8. HD Audio with Equalizer

Customize your audio experience with the built-in equalizer for clearer sound during calls.

Image: A visual representation of the HD Audio with Equalizer feature, showing a handset and an equalizer graphic.

9. Expanding Your System

The system is expandable up to 12 handsets using AT&T CL80107 or CL80067 accessory models. Only one phone jack is required for the base unit.

MAINTENANCE

- **Cleaning:** Clean the phone and base unit with a soft, damp cloth. Do not use cleaning sprays or harsh chemicals.
- **Battery Care:** Replace batteries when they no longer hold a charge. Dispose of old batteries responsibly according to local regulations.
- **Location:** Avoid placing the phone near heat sources, direct sunlight, or areas with excessive moisture.

TROUBLESHOOTING

Problem	Solution

Problem	Solution
No dial tone	Ensure the telephone line cord is securely connected to both the base unit and the wall jack.
	Check if the AC adapter is properly connected to the base unit and a working electrical outlet.
	Test with another phone to confirm the phone line is active.
Handset does not charge	Ensure the handset is correctly seated in the charging cradle. The CHARGE light should be on.
	Verify the AC adapter for the charger is plugged into a working outlet.
	Clean the charging contacts on both the handset and charger with a dry cloth.
	The battery pack may need to be replaced.
Poor sound quality or static	Move the handset closer to the base unit.
	Avoid placing the base unit near other electronic devices (e.g., microwaves, Wi-Fi routers) that may cause interference.
	Check for loose connections of the telephone line cord.
Answering system not recording messages	Ensure the answering system is turned ON.
	Check if the memory is full. Delete old messages to free up space.
	Adjust the number of rings before the answering system picks up.

SPECIFICATIONS

Feature	Detail
Product Dimensions	3.87 x 9.12 x 7 inches
Item Weight	2.16 pounds
Model Number	CL82267
Brand	AT&T
Color	Wood Grain Finish Cordless
Telephone Type	Cordless (DECT 6.0)
Material	Plastic
Power Source	Corded Electric
Dialer Type	Dual Keypad
Answering System Type	Digital (up to 22 minutes recording)
Compatible Devices	AT&T cordless product line
Conference Call Capability	Basic (up to 5 participants)
Call Blocking Capacity	Up to 1,000 name and number entries

Dimensions

Base Unit

A: Height   7.24 inches   18.40 cm

B: Width   3.89 inches   9.88 cm

C: Length   6.66 inches   16.94 cm

Image: Dimensions of the base unit, illustrating its height, width, and length.

Dimensions

Handset

A: Height 7.28 inches
          18.50 cm

B: Width   3.00 inches
          7.63 cm

C: Length 2.83 inches
          7.20 cm

Image: Dimensions of a single handset, illustrating its height, width, and length.

WARRANTY

AT&T products typically come with a standard manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the warranty card included in your product packaging or visit the official AT&T support website. Keep your purchase receipt as proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or to download the latest version of this manual, please visit the official AT&T support website or contact customer service.

- **Online User Manual (PDF):** Download User Manual
- **Installation Manual (PDF):** Download Installation Manual
- **AT&T Support:** Refer to your product packaging for contact information or visit the official AT&T website.