Remax RB-S11

Remax RB-S11 Wireless Bluetooth Sports Earphones User Manual

Model: RB-S11 | Brand: Remax

Introduction

Thank you for choosing the Remax RB-S11 Wireless Bluetooth Sports Earphones. These earphones are designed to provide a high-fidelity audio experience with the convenience of wireless connectivity, making them ideal for sports and active lifestyles. Featuring a water and sweat-resistant design and a magnetic clasp for easy storage, the RB-S11 offers comfort and durability.



Figure 1: Remax RB-S11 Wireless Bluetooth Sports Earphones, showing the full product with earbuds and in-line controls.

Setup

Charging the Earphones

Before first use, fully charge your RB-S11 earphones. A full charge takes approximately 2 hours.

1. Locate the charging port on the in-line control unit.
2. Connect the provided USB charging cable to the charging port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, wall adapter).
4. The indicator light will show charging status (refer to LED indicator section for details). Once fully charged, disconnect the cable.

Bluetooth Pairing

Pair your earphones with your Bluetooth-enabled device (smartphone, tablet, etc.) to begin listening.

1. Ensure the earphones are charged and turned off.
2. Press and hold the Multi-function Button (usually the center button on the in-line control) until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device, enable Bluetooth and search for available devices.
4. Select "RB-S11" from the list of found devices.
5. Once paired, the LED indicator on the earphones will flash blue slowly, and you will hear a confirmation tone.

The earphones will automatically attempt to reconnect to the last paired device when turned on.

Operating Instructions

Controls Overview



Figure 2: Close-up of the in-line control unit on the Remax RB-S11 earphones, showing the volume up, volume down, and multi-function buttons.

Table 1: Earphone Control Functions

Button/Action	Function
Multi-function Button (Center)	• Press and hold (3s): Power On/Off • Short press: Play/Pause music, Answer/End call • Double press: Redial last number • Press and hold (2s) during call: Reject call
Volume Up Button (+)	• Short press: Increase volume • Press and hold: Next track
Volume Down Button (-)	• Short press: Decrease volume • Press and hold: Previous track

Wearing the Earphones

Insert the earbuds gently into your ears. The RB-S11 features a magnetic design, allowing the earbuds to clasp together when not in use, preventing tangles and making them easy to carry around your neck.

Maintenance

Proper care will extend the life of your Remax RB-S11 earphones.

- **Cleaning:** Use a soft, dry cloth to wipe the earphones. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earphones are water and sweat resistant, suitable for workouts. However, they are not designed for submersion. Avoid exposing them to excessive water or high humidity.
- **Storage:** When not in use, store the earphones in a cool, dry place, away from direct sunlight and extreme temperatures. The magnetic earbuds help keep them tangle-free.
- **Charging:** Only use the provided charging cable or a certified equivalent. Do not overcharge the battery.

Troubleshooting

Table 2: Common Issues and Solutions

Problem	Possible Cause	Solution
Earphones won't turn on.	Low battery.	Charge the earphones for at least 2 hours.
Cannot pair with device.	Earphones not in pairing mode; Bluetooth off on device; too far from device.	Ensure earphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move earphones closer to the device (within 10 meters). Try unpairing and re-pairing.
No sound or poor sound quality.	Volume too low; earphones not properly connected; interference.	Increase volume on both earphones and device. Reconnect earphones. Move away from other wireless devices.

Problem	Possible Cause	Solution
Intermittent connection.	Out of range; interference; low battery.	Stay within 10 meters of your device. Avoid strong electromagnetic fields. Charge the earphones.

Specifications



Figure 3: Visual representation of Remax RB-S11 key specifications and features, including Bluetooth version, sound quality, ergonomic design, and battery life.

Table 3: Remax RB-S11 Technical Specifications

Feature	Detail
Brand	Remax
Model	RB-S11
Bluetooth Version	5.0
Wireless Distance	10 meters
Impedance	16 Ohm
Charging Time	2 hours
Playback Time	4 - 6 hours
Standby Time	200 hours
Water Resistance	Water and Sweat Resistant
Design Feature	Magnetic Earbuds

Feature	Detail
Form Factor	In Ear
Connectivity Technology	Wireless
Included Components	Ear Cushions
Material	Plastic
Color	Black

Warranty and Support

Specific warranty information for the Remax RB-S11 earphones is not detailed in this manual. Please refer to the product packaging or the official Remax website for warranty terms and conditions.
For technical support or further assistance, please contact Remax customer service through their official channels.

© 2024 Remax. All rights reserved.
This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question