Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eagle Claw LPSWWB-316

Instruction Manual: Eagle Claw PRO Series Lead Worm SINKERS

Model: LPSWWB-316

Product Overview

The Eagle Claw PRO Series Lead Worm SINKERS are designed for various freshwater fishing applications, including Texas rig setups. These sinkers provide the necessary weight to present your bait effectively in different water conditions.



Image: A single dark-colored, bullet-shaped lead worm sinker, tapered at one end and flat at the other, designed for fishing applications.

Setup and Installation

These lead worm sinkers are typically used with a fishing line and a hook, often in a Texas rig configuration. Follow these general steps for setup:

1. **Thread the Line:** Pass your fishing line through the narrow end of the sinker, allowing it to slide freely.
2. **Attach the Hook:** Tie your fishing hook to the end of the line using a secure fishing knot.
3. **Add Bait:** Rig your soft plastic worm or other bait onto the hook. The sinker will rest against the nose of the bait or a bead, depending on your specific rig.

For specific rigging techniques like the Texas rig, consult specialized fishing guides or videos.

Operating Instructions

Once rigged, the sinker's primary function is to add weight for casting and to help your bait sink to the desired depth. Its bullet shape allows it to move through cover with reduced snagging.

- **Casting:** Cast your line to the desired fishing spot. The weight of the sinker will assist in achieving distance and accuracy.
- **Retrieval:** Allow the bait to sink. Retrieve your line with varying speeds and pauses to mimic natural bait movement, depending on the fish species and conditions.
- **Bottom Contact:** The sinker helps maintain contact with the bottom, allowing you to feel subtle bites or changes in bottom structure.

Maintenance

Eagle Claw PRO Series Lead Worm SINKERS require minimal maintenance. After use, it is recommended to:

- **Rinse:** Rinse the sinkers with fresh water, especially after use in saltwater environments, to remove any residue.
- **Dry:** Ensure the sinkers are completely dry before storing to prevent oxidation or damage to other tackle.
- **Store:** Store in a dry tackle box or container, away from direct sunlight and extreme temperatures.

Troubleshooting

While lead sinkers are simple components, some common issues can be addressed:

- **Frequent Snagging:** If your sinker frequently gets snagged, try using a lighter weight sinker, a different rigging technique (e.g., weedless rig), or fishing in areas with less underwater obstruction.
- **Line Abrasion:** Ensure the hole in the sinker is smooth. If you notice line fraying, consider using a bead between the sinker and your knot to protect the line.
- **Losing Sinkers:** This is common in fishing. Ensure your knots are strong and that you are not casting into overly dense cover that might cause the sinker to become irretrievably stuck.

Specifications

Brand	Eagle Claw
Model Name	LPSWWB-316
Material	Blend (Lead)
Shape	Worm (Bullet)
Color	Multi
Recommended Uses	Freshwater fishing, Texas rig, regular use
UPC	047708774888
Item Dimensions (LxWxH)	1 x 1 x 1 inches
Package Weight	1 Pounds

Safety Information and Warnings

WARNING: This product contains lead, a chemical known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.
Always handle fishing tackle responsibly. Keep out of reach of children and pets. Do not ingest. Dispose of lead products according to local regulations.

Warranty and Support

For specific warranty information or product support, please contact Eagle Claw customer service directly. You can find more information and contact details by visiting the official Eagle Claw store on Amazon:
Visit the Eagle Claw Store on Amazon

© 2024 Eagle Claw. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B092Y71YDT

More documents and user manuals: **https://manuals.plus/**