Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC TH-S320B

JVC TH-S320B 30-Inch Bluetooth Sound Bar User Manual

Model: TH-S320B

1. Introduction

Thank you for purchasing the JVC TH-S320B 30-Inch Bluetooth Sound Bar. This sound bar is designed to enhance your television audio and provide wireless audio streaming capabilities. With its versatile connectivity options and powerful sound output, it delivers an immersive listening experience for movies, music, and more.

Key Features

- Power output of 150 watts max, 60 watts RMS
- Frequency response: 45 Hz to 20 kHz for faithful sound reproduction
- 2.5 in. x 2 full-range drivers for stereo sound
- Bluetooth audio streaming from Bluetooth-enabled devices
- HDMI ARC, optical, USB, and 3.5 mm inputs



An angled view of the JVC TH-S320B sound bar, showcasing its sleek black design and the JVC logo on the front left side. The sound bar is long and rectangular, designed to sit horizontally.

2. Package Contents

Please check that all items are present and in good condition:

- JVC TH-S320B Sound Bar
- Remote Control
- Power Adapter
- RCA to 3.5 mm Adapter
- Wall Mount Kit
- User Manual (this document)

3. Important Safety Information

To reduce the risk of electric shock, fire, or injury, always follow basic safety precautions when using this product.

- Do not expose this appliance to dripping or splashing.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- Ensure proper ventilation. Do not block any ventilation openings.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

4. Connecting Your Sound Bar

Before connecting, ensure all devices are powered off.

4.1 HDMI ARC Connection (Recommended)

HDMI ARC (Audio Return Channel) allows audio to be sent from your TV to the sound bar using a single HDMI cable. This also enables control of the sound bar's power and volume using your TV remote.

1. Connect one end of an HDMI cable (not included) to the HDMI ARC port on your TV.
2. Connect the other end of the HDMI cable to the HDMI ARC port on your sound bar.
3. Enable HDMI ARC on your TV's settings (refer to your TV's manual for specific instructions).

4.2 Optical Connection

Use an optical cable for high-quality digital audio if your TV does not support HDMI ARC or if you prefer this connection type.

1. Connect one end of an optical cable (not included) to the Optical Digital Audio Out port on your TV.
2. Connect the other end of the optical cable to the OPTICAL IN port on your sound bar.
3. Ensure your TV's audio output is set to 'Optical' or 'PCM' format.

4.3 Auxiliary (3.5mm) Connection

For connecting devices with a 3.5mm audio output, such as smartphones or MP3 players.

1. Connect the 3.5mm end of the included RCA to 3.5mm adapter to the AUX IN port on your sound bar.
2. Connect the RCA ends of the adapter to the audio output of your source device (if applicable), or use a standard 3.5mm to 3.5mm cable (not included) directly.

4.4 USB Connection

For playing audio files directly from a USB storage device.

1. Insert a USB flash drive (FAT32 format, max 32GB) into the USB port on the sound bar.
2. The sound bar will automatically switch to USB input and begin playing compatible audio files.

5. Initial Setup

5.1 Placement

The sound bar can be placed on a flat surface in front of your TV or mounted on a wall.

- **Tabletop Placement:** Place the sound bar on a stable, flat surface directly below the center of your TV. Ensure there are no obstructions in front of the sound bar.
- **Wall Mounting:** Use the included wall mount kit and follow the instructions provided with the kit for secure installation. Ensure the wall can support the weight of the sound bar.

5.2 Power Connection

1. Connect the power adapter to the DC IN port on the sound bar.
2. Plug the other end of the power adapter into a wall outlet.

6. Operating Your Sound Bar

6.1 Power On/Off

Press the **POWER** button on the remote control or on the sound bar to turn the unit on or off.

6.2 Input Selection

Press the **INPUT** button on the remote control or on the sound bar repeatedly to cycle through the available input sources: HDMI ARC, OPTICAL, AUX, USB, and BLUETOOTH.

6.3 Volume Control

Press the **VOL+** or **VOL-** buttons on the remote control or on the sound bar to adjust the volume level. Press the **MUTE** button to temporarily silence the audio.

6.4 Bluetooth Pairing

To stream audio wirelessly from a Bluetooth-enabled device:

1. Turn on the sound bar and select the BLUETOOTH input. The LED indicator will flash, indicating it is in pairing mode.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for available Bluetooth devices and select "JVC TH-S320B" from the list.
4. Once paired, the LED indicator will stop flashing and remain solid. You can now play audio from your device through the sound bar.

6.5 Remote Control

The included remote control provides full functionality for your sound bar. Ensure the batteries are correctly inserted. Point the remote control directly at the sound bar's front panel.

7. Care and Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the sound bar. Do not use liquid cleaners or aerosol sprays.
- **Ventilation:** Ensure the ventilation openings are not blocked.
- **Storage:** If storing the sound bar for an extended period, disconnect it from the power outlet and store it in a cool, dry place.

8. Troubleshooting

If you experience issues with your sound bar, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not active	Ensure power cord is securely connected; Try a different power outlet
No sound	Incorrect input selected; Volume too low; Mute is on; Incorrect TV audio settings	Select correct input; Increase volume; Press MUTE button; Adjust TV audio output settings (e.g., PCM for optical)
Bluetooth not connecting	Sound bar not in pairing mode; Device too far; Interference	Ensure sound bar is in Bluetooth input and flashing; Move device closer; Avoid other wireless devices
Remote control not working	Batteries are dead or incorrectly inserted; Obstruction between remote and sound bar	Replace batteries; Ensure correct polarity; Remove any obstructions

9. Technical Specifications

Feature	Specification
Model Name	TH-S320B
Speaker Type	Soundbar
Speaker Maximum Output Power	150 Watts
Frequency Response	45 Hz to 20 kHz
Connectivity Technology	RCA, Bluetooth, Auxiliary, USB, Optical, HDMI
Wireless Communication Technology	Bluetooth
Audio Output Mode	Stereo (2.0 Channel)
Color	Black
Item Weight	5.64 pounds (2.56 kg)
Product Dimensions	29.5 x 2.9 x 3.1 inches (74.9 x 7.4 x 7.9 cm)

Feature	Specification
Power Source	Corded Electric
Compatible Devices	Smartphone, Tablet, MP3 Player, Televisions
Mounting Type	Tabletop, Wall Mount

10. Warranty and Customer Support

This JVC TH-S320B Sound Bar comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the duration and coverage of the warranty.
For technical support, troubleshooting assistance, or warranty claims, please contact JVC customer support through their official website or the contact information provided in your product documentation. Please have your model number (TH-S320B) and purchase details ready when contacting support.

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B093235Z3T

More documents and user manuals: **https://manuals.plus/**