Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easytry123 RG57A3/BGEF, RG57A2/BGEF, AWMI-09UHPDC2A, RG57B/BGE, RG57D/BGE, AWMI-12UHPDC2A, RG57B1/BGE

User Manual for Easytry123 Replacement Remote Control

Model Compatibility: AlpicAir RG57A3/BGEF, RG57A2/BGEF, AWMI-09UHPDC2A, RG57B/BGE, RG57D/BGE, AWMI-12UHPDC2A & Rient RG57B1/BGE A/C Air Conditioners

1. Product Overview

This document provides instructions for the Easytry123 replacement remote control, designed for various AlpicAir and Rient air conditioner models. This remote utilizes infrared technology for communication with your air conditioning unit and features an ergonomic design for comfortable handling. Please note that as a replacement unit, some advanced functions of your original remote may not be supported.
It is essential to verify that your air conditioner model is listed in the compatible models section to ensure proper functionality. This remote control requires two AAA batteries for operation, which are not included.

2. Setup: Battery Installation

Before using the remote control, you must install the batteries. This remote requires two (2) AAA batteries.

1. Locate the battery compartment on the back of the remote control.
2. Gently slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect installation can prevent the remote from functioning.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2.1: Rear view of the remote control with the battery cover removed, illustrating the battery insertion slots. Ensure correct polarity when inserting AAA batteries.

3. Operating Instructions

This section details the functions of the buttons on your replacement remote control. Point the remote directly at the air conditioner's receiver when operating.



Figure 3.1: Front view of the remote control, displaying the layout of buttons and the LCD screen.

ON/OFF Button: Press to turn the air conditioner unit on or off.

MODE Button: Cycles through available operating modes such as Cool, Heat, Fan, Dry, and Auto. The active mode is typically displayed on the remote's LCD screen.

TEMP Buttons (Up/Down Arrows): Adjusts the desired temperature setting. Press the up arrow to increase temperature and the down arrow to decrease it.

FAN Button: Changes the fan speed (e.g., Low, Medium, High, Auto).

ECO Button: Activates or deactivates the energy-saving mode, if supported by your AC unit.

TIMER ON Button: Sets a timer for the unit to turn on automatically at a specified time. Refer to your AC unit's manual for specific timer setting procedures.

TIMER OFF Button: Sets a timer for the unit to turn off automatically at a specified time.

SWING Button: Controls the vertical swing of the air deflector (louvers) to distribute air evenly.

DIRECT Button: Adjusts the horizontal direction of the airflow.

LED Button: Toggles the display light on the air conditioner unit on or off.

SLEEP Button: Activates the sleep mode, which typically adjusts temperature and fan speed for comfortable sleep and energy saving.

TURBO Button: Engages maximum cooling or heating power for rapid temperature change.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control periodically with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the display fades. Always replace both batteries at the same time with new ones of the same type (AAA). Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.

5. Troubleshooting

If you experience issues with your remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's infrared receiver.
  - Make sure you are within the effective operating range of the air conditioner unit.
- **Limited Functionality:**

  As a replacement remote, it may not support all advanced or unique functions of your original air conditioner remote. This is normal for universal or replacement remotes. Focus on core functions like ON/OFF, Mode, Temperature, and Fan speed.
- **Display Issues:**

  If the remote's LCD display is dim or blank, replace the batteries. If the issue persists, the remote may require replacement.

6. Specifications

Brand	Easytry123
Compatible Devices	AlpicAir and Rient A/C Air Conditioners (Specific models listed in title)
Connectivity Technology	Infrared
Controller Type	Button Control
Special Feature	Ergonomic Design
Batteries Required	2 x AAA batteries (not included)

7. Warranty and Support

Specific warranty terms for this replacement remote control are typically provided by the seller at the time of purchase. Please refer to your purchase documentation or contact the seller directly for detailed warranty information and support regarding product defects or operational issues.
For technical assistance or inquiries not covered in this manual, it is recommended to contact the seller or the manufacturer, Easytry123, through the platform where the product was purchased.

© 2024 Easytry123. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09332N9M9

More documents and user manuals: **https://manuals.plus/**