ZdalaMit RC-970R

Instruction Manual

RC-970R Replacement Remote Control

For Onkyo AV Receiver Models: TX-SR393, TX-SR494, HT-R398, HT-S3910

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your new ZdalaMit RC-970R Replacement Remote Control. This remote is designed as a direct replacement for specific Onkyo AV Receiver models, offering seamless functionality without the need for complex programming.

Package Contents

Please verify that all items are present in your package:

- 1x RC-970R Replacement Remote Control

Note: Batteries are not included and must be purchased separately.

Specifications

Attribute	Detail
Model Number	RC-970R
Brand	ZdalaMit
Dimensions (L x W x H)	5 x 2 x 0.55 inches
Item Weight	1.41 ounces
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Connectivity Technology	Infrared (IR)

Compatible Devices	Onkyo AV Receivers (TX-SR393, TX-SR494, HT-R398, HT-S3910)

Setup

Battery Installation

Follow these steps to install batteries into your remote control:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by the arrow to open it.
3. Insert two (2) AAA alkaline batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: Always use new batteries of the same type. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.





Image: Front view of the RC-970R remote control, showing all buttons and the model number at the bottom.

Operating Instructions

The RC-970R remote control is designed for immediate use with compatible Onkyo AV Receivers without any programming or pairing. Once batteries are installed, it is ready to operate your device.

Basic Operation

- **Power Button:** Located at the top, typically yellow, to turn the AV Receiver on or off.
- **Input Selectors:** Buttons like BD/DVD, GAME, CBL/SAT, STB/BOX, PC, AUX, CD, TV, TUNER, BLUETOOTH allow you to switch between different audio/video inputs on your receiver.
- **Volume Control (VOL +/-):** Adjusts the master volume of your AV Receiver.
- **Mute Button:** Temporarily silences the audio output.
- **Navigation Pad (Up, Down, Left, Right, ENTER):** Used for navigating menus and confirming selections on your receiver's display.
- **Playback Controls:** Buttons for Play, Pause, Stop, Fast Forward, Rewind, Skip Track (Next/Previous) for connected media devices.
- **Tone Controls (TREBLE, VOCAL, BASS):** Adjust audio characteristics.
- **Sound Modes (STEREO, MOVIE/TV, MUSIC):** Select different audio processing modes.

Refer to your Onkyo AV Receiver's original manual for specific functions of each button and advanced settings.





Image: Angled view of the RC-970R remote control, highlighting the ergonomic design and button layout.

Maintenance

Proper care will extend the life of your remote control:

- **Cleaning:** Use a soft, dry cloth to clean the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the remote is not going to be used for an extended period (e.g., more than a month) to prevent battery leakage, which can damage the remote.
- **Avoid Drops:** Protect the remote from physical shocks and drops, as this can damage internal components.

Troubleshooting

If you encounter issues with your remote control, try the following solutions:

Problem	Possible Solution
Remote not responding	◦ Check if batteries are inserted correctly with correct polarity (+/-). ◦ Replace old batteries with new AAA alkaline batteries. ◦ Ensure there are no obstructions between the remote and the AV Receiver's IR sensor. ◦ Make sure you are within the effective range of the receiver.
Certain buttons not working	◦ Clean the remote surface, especially around the non-working buttons, to remove any dirt or debris. ◦ Ensure the remote is pointed directly at the AV Receiver. ◦ Verify that the function you are trying to use is supported by your specific Onkyo AV Receiver model.
Remote works intermittently	◦ Batteries may be low; replace them. ◦ Check for strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the IR signal.

If the problem persists after trying these steps, please contact customer support.

Warranty and Support

This ZdalaMit RC-970R Replacement Remote Control comes with a standard manufacturer's warranty. Please refer to the product packaging or the seller's information for specific warranty terms and conditions. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact the seller or manufacturer directly through the platform where the product was purchased. Provide your order details and a clear description of the issue for prompt assistance.

Manufacturer: ZdalaMit Factory

© 2024 ZdalaMit. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.