Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 783746845523

JustFine Replacement Remote Control User Manual

Compatible with Element TV Models: ELEFW5517, ELEFW3916, ELEFJ191, ELEFT195, ELEFW195, ELEFW504, ELEFW328, ELEFT222, ELEFW40C

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your JustFine replacement remote control. This remote is designed to be compatible with various Element brand television models, offering a direct replacement without the need for complex programming.

Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your remote control.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off in the direction indicated by the arrow.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image 1: Rear view of the remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

Important: Ensure batteries are inserted with correct polarity. Incorrect installation can damage the remote control.

2.2 Initial Use (No Programming Required)

This JustFine replacement remote control is pre-programmed for compatibility with the listed Element TV models. No additional programming or setup is required. Once batteries are installed, the remote is ready for immediate use with your compatible television.

3. Operating Instructions

Point the remote control directly at the infrared sensor on your Element TV. Ensure there are no obstructions between the remote and the TV.





Image 2: Front view of the remote control, displaying the layout of all functional buttons.

3.1 Button Functions Overview

Below is a general guide to the primary functions of the buttons on your remote control. Specific functionality may vary slightly depending on your Element TV model.

- **POWER ( )**: Turns the TV on or off.
- **P.MODE** / **S.MODE**: Picture Mode / Sound Mode selection.
- **SLEEP**: Sets the sleep timer.
- **ASPECT**: Changes the screen aspect ratio.
- **USB**: Accesses USB media.
- **Number Buttons (0-9)**: Direct channel selection.
- **VOL +/-**: Adjusts the volume level.
- **CH +/-**: Changes the channel up or down.
- **MUTE**: Mutes or unmutes the TV sound.
- **SOURCE**: Selects input sources (HDMI, AV, etc.).
- **MENU**: Opens the TV's main menu.
- **INFO**: Displays channel or program information.
- **EXIT**: Exits the current menu or function.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigates through menus.
- **OK**: Confirms selections in menus.
- **RETURN**: Returns to the previous menu or screen.
- **CH LIST**: Displays the channel list.
- **MTS**: Multi-channel Television Sound (SAP).
- **FREEZE**: Freezes the current image on screen.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward)**: Controls media playback.
- **REPEAT**: Repeats media playback.
- **C.C**: Closed Captioning.
- **V-CHIP**: Accesses V-Chip parental controls.
- **AUTO**: Automatic picture adjustment.

- **ADD/ERASE**: Adds or erases channels.
- **FAV**: Accesses favorite channels.

4. Maintenance

4.1 Cleaning the Remote Control

To clean your remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes inconsistent or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Dispose of used batteries according to local regulations.

5. Troubleshooting

- **Remote is not responding:**
  - Ensure the batteries are installed correctly with the correct polarity.
  - Replace the batteries with fresh ones.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective operating range and pointing the remote directly at the TV.
- **Some buttons do not work:**
  - While this remote is broadly compatible, some advanced or specific functions of your original TV remote might not be replicated. Refer to your TV's original manual for specific button functions if needed.
  - Ensure the remote is clean and free from debris that might obstruct button presses.

6. Specifications

Feature	Detail
Brand	JustFine
Model Number	783746845523
Compatible Devices	Element Televisions (Specific models listed in title)
Connectivity Technology	Infrared (IR)
Number of Buttons	25
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.65 ounces
Power Source	2 x AAA Batteries (not included)

7. Warranty and Support

This product is sold with a 30-day quality warranty and a money-back guarantee, offering hassle-free returns. For any issues or inquiries regarding your JustFine replacement remote control, please contact the seller directly via the platform

where the purchase was made.

Please retain your purchase receipt for warranty purposes.

© 2025 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0934FN5VP

More documents and user manuals: **https://manuals.plus/**