Disney Disney book collection

User Manual for Disney Me Reader Electronic Book Bundle

Model: Disney book collection

1. Product Overview

The Disney Me Reader Electronic Book Bundle is an interactive learning system designed for young children. It includes an electronic reader module and a collection of 8 unique Disney books, allowing children to engage with stories by pressing buttons on the reader to hear the text read aloud.



Figure 1: Complete Disney Me Reader Electronic Book Bundle contents.

Package Contents:

- 1 x Disney Me Reader Electronic Reader Module
- 8 x Unique Disney Books (featuring Mickey Mouse, Toy Story, Monsters Inc, Wall-E, UP, Tangled, The Incredibles, and Disney Cars)
- 1 x Bonus Toy Story Travel Sticker Book (containing 350+ stickers, 12 activity pages, and 2 play scenes)

2. Setup

2.1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Inspect all items for any signs of damage. Retain packaging for future storage or transport if needed.

2.2. Battery Installation

The Disney Me Reader module requires batteries for operation. Locate the battery compartment on the back of the reader. Using a small Phillips head screwdriver, open the battery cover. Insert the required number of new batteries (typically AAA, check the compartment for specific type and polarity markings). Close the battery cover and secure it with the screw.

2.3. Powering On

Press the power button located on the Me Reader module. A sound or light indicator will confirm the device is powered on and ready for use.

3. Operating Instructions

3.1. Selecting a Book

Each of the 8 included books has a corresponding icon on the Me Reader module. To begin reading, select the book you wish to hear and place it in front of the reader. Press the button on the Me Reader that matches the icon of the chosen book.



Figure 2: Disney Me Reader module surrounded by the included storybooks.

3.2. Using the Me Reader Module

- **Book Selection Buttons:** Press the button corresponding to the book you want to read.
- **"Read Story" Button:** After selecting a book, press this button to hear the entire story read aloud.
- **Page Buttons:** As the story progresses, the reader will prompt you to turn the page. Press the corresponding page button on the module to hear the text for that specific page.
- **Volume Control:** Adjust the volume using the dedicated volume buttons on the reader.

The Me Reader is designed to guide the user through the story, indicating when to turn pages and providing audio narration for each page.

3.3. Using the Bonus Sticker Book

The bonus Toy Story travel sticker book contains over 350 stickers, 12 activity pages, and 2 play scenes. These can be used independently for creative play and learning.




Disney · PIXAR
Cars



Figure 3: Example of stickers included in the bonus Toy Story travel sticker book.

4. Maintenance

4.1. Cleaning

To clean the Me Reader module and books, use a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, but ensure no moisture enters the electronic components. Do not use abrasive cleaners or solvents.

4.2. Storage

Store the Me Reader and books in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, it is recommended to remove the batteries from the Me Reader module to prevent leakage.

4.3. Battery Replacement

When the audio becomes distorted or the reader fails to power on, it is likely time to replace the batteries. Follow the battery installation steps outlined in Section 2.2.

5. Troubleshooting

Problem	Possible Cause	Solution
Me Reader does not turn on.	Low or dead batteries; Batteries inserted incorrectly.	Replace batteries with new ones; Ensure batteries are inserted with correct polarity.
No sound or low sound.	Volume is too low; Low batteries.	Increase volume using the volume buttons; Replace batteries.
Reader does not recognize the book.	Incorrect book button pressed; Book not properly aligned.	Ensure the correct book icon button is pressed; Verify the book is placed correctly in front of the reader.
Audio is distorted or skips.	Low batteries; Interference.	Replace batteries; Move away from other electronic devices that may cause interference.

6. Specifications

Attribute	Detail
Brand	Disney
Model Number	Disney book collection
ASIN	B0934GTT24
Package Dimensions	10.83 x 9.37 x 2.72 inches
Item Weight	2.81 pounds
Manufacturer	P I Kids

Attribute	Detail
Recommended Age	Ages 3 and up

7. Warranty and Support

7.1. Warranty Information

Specific warranty details for the Disney Me Reader Electronic Book Bundle are typically provided with the product packaging or can be obtained from the retailer or manufacturer. Please refer to any enclosed warranty cards or visit the official Disney or P I Kids website for the most current warranty policy.

7.2. Customer Support

For technical assistance, troubleshooting beyond this manual, or inquiries regarding product parts, please contact the manufacturer or retailer where the product was purchased. Keep your purchase receipt and product model information readily available when contacting support.
You may also visit the official Disney Store on Amazon for additional product information or frequently asked questions.

© 2025 Disney. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question