BESTTEN RCS-9U

BESTTEN Outdoor Indoor Remote Control Outlet User Manual

Model: RCS-9U

Introduction

This manual provides detailed instructions for the safe and efficient operation of your BESTTEN Outdoor Indoor Remote Control Outlet, Model RCS-9U. Please read this manual thoroughly before installation and use, and retain it for future reference.



Image: The BESTTEN Outdoor Indoor Remote Control Outlet (green, weatherproof housing with two grounded outlets and a 6-inch power cord) shown alongside its matching green wireless remote control.

Safety Information

- Ensure the product is used within its specified electrical ratings (125 Volts).
- Do not immerse the unit in water. This product is weatherproof, not submersible.
- Do not attempt to disassemble or repair the unit. Refer all servicing to qualified personnel.
- Keep out of reach of children.
- Always unplug the unit from the power source before cleaning or when not in use for extended periods.
- Avoid overloading the outlets.

Package Contents

- 1 x BESTTEN Outdoor Indoor Remote Control Outlet (Model RCS-9U)
- 1 x Wireless Remote Control
- 1 x User Manual

Product Features

- **Wireless Control:** Operate connected devices from a distance using the included remote.
- **Dual Grounded Outlets:** Provides two 3-prong outlets for multiple devices.
- **Weatherproof Design:** Suitable for both indoor and outdoor environments.
- **Heavy-Duty Cord:** Features a durable 6-inch power cord.
- **ETL Certified:** Ensures safety and quality standards are met.

Setup

1. **Unpack the Unit:** Carefully remove the remote control outlet and remote from its packaging. Inspect for any damage.
2. **Remote Battery Installation:** The remote control typically comes with a pre-installed battery or requires a small coin cell battery (e.g., CR2032). If not pre-installed, open the battery compartment on the back of the remote and insert the battery, observing polarity (+/-).
3. **Plug in the Outlet:** Connect the 3-prong plug of the remote control outlet into a standard 125V wall receptacle. Ensure the receptacle is properly grounded.
4. **Connect Devices:** Plug the devices you wish to control into the two grounded outlets on the remote control unit. Ensure the total power consumption of connected devices does not exceed the outlet's maximum rating.
5. **Pairing (if necessary):** Most units are pre-paired. If your remote does not control the outlet immediately, refer to the "Operating" section for pairing instructions.

Operating

Remote Control Functions

The wireless remote control allows you to turn the connected devices ON or OFF from a distance.

- **ON/OFF Buttons:** The remote features individual ON and OFF buttons for each outlet (if applicable, or a single pair for both outlets). Press the **ON** button to turn the connected device(s) on. Press the**OFF** button to turn the connected device(s) off.
- **ALL ON/ALL OFF Button:** Some remotes include an "ALL" button to control both outlets simultaneously. Press**ALL ON** to turn all connected devices on, and**ALL OFF** to turn all connected devices off.

Manual Override Button

The outlet unit itself may have a manual override button. Pressing this button will cycle the power state of the connected outlets (ON/OFF) without using the remote control.

Pairing Instructions (if needed)

If the remote control does not operate the outlet, it may need to be paired. Follow these steps:

1. Ensure the remote control outlet is plugged into a live power source.
2. Press and hold the small pairing button on the remote control outlet unit for approximately 3-5 seconds until the indicator light begins to flash.
3. While the indicator light is flashing, press the desired "ON" button on your remote control. The indicator light on the outlet should stop flashing and remain solid, indicating successful pairing.
4. Test the remote control to ensure proper operation.

Maintenance

- **Cleaning:** Disconnect the unit from power before cleaning. Wipe the surface with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the unit in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement (Remote):** If the remote control's range decreases or it stops responding, replace the battery. Refer to the "Setup" section for battery type and installation.

Troubleshooting

Problem	Possible Cause	Solution
Outlet does not turn ON/OFF with remote.	Remote battery is dead or incorrectly installed. Outlet and remote are not paired. Outlet is not receiving power. Remote is out of range.	Replace or correctly install remote battery. Refer to "Pairing Instructions" in the Operating section. Check the wall outlet and circuit breaker. Move closer to the outlet unit.
Connected device does not turn on.	Device is not properly plugged into the outlet. Device itself is faulty or turned off. Outlet is overloaded.	Ensure the device is fully inserted into the outlet. Test the device by plugging it directly into a working wall outlet. Ensure the device's power switch is ON. Reduce the number of connected devices or their total wattage.
Indicator light on outlet is off.	No power to the outlet unit.	Check the wall outlet and circuit breaker.

Specifications

Model Number	RCS-9U
Input Voltage	125 Volts AC
Total Power Outlets	2 Grounded Outlets
Cord Length	6 inches
Dimensions (L x W x H)	7.28 x 4.29 x 1.89 inches
Item Weight	8.8 ounces
Certifications	ETL Certified
Recommended Use Environment	Indoor/Outdoor (Weatherproof)

Warranty and Support

BESTTEN products are designed and manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please visit the official BESTTEN website or contact their customer support team directly.

Website: BESTTEN Official Store on Amazon

Please have your model number (RCS-9U) and purchase information ready when contacting support.

© 2025 BESTTEN. All rights reserved.

Manual Version: 1.0