Qinkada Qinkada-Meat Grinder

Qinkada 500W Food Processor Instruction Manual

Model: Qinkada-Meat Grinder

Safety Instructions Product Overview Assembly & Setup Operating Instructions Maintenance & Cleaning Troubleshooting Specifications Warranty & Support

1. Important Safety Instructions

Please read all instructions carefully before using the Qinkada Food Processor. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the power supply voltage matches the rating on the appliance. Do not immerse the motor unit in water or other liquids. Always unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- **Blade Safety:** The blades are very sharp. Handle them with extreme care, especially when removing, inserting, or cleaning. Always ensure the blades are securely in place before operation.
- **Prevent Injury:** Avoid contact with moving parts. Never feed food by hand. Always use the safety cover and ensure all parts are correctly assembled before operating.
- **Overheat Protection:** The food processor is equipped with an overheat protection function. If the motor stops due to overheating, allow it to cool down for at least 30 minutes before attempting to use it again. Do not operate for more than 2 minutes continuously.
- **Child Safety:** This appliance is not intended for use by children. Keep the appliance and its cord out of reach of children. Close supervision is necessary when any appliance is used near children.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer support for assistance.

2. Product Overview

The Qinkada Food Processor is designed for efficient food preparation, featuring a powerful motor and durable stainless steel components.

2.1 Components

- Motor Base (500W)
- Food Grade Lid
- S-shape Bi-Level Blades
- 14-Cup (3.5L) Stainless Steel Bowl
- Anti-slip Rubber Mat
- Foldable Handle (on motor base)
- Hidden Safety Switch



Figure 1: Labeled diagram of the Qinkada Food Processor components, including the motor base, lid, S-shape blades, stainless steel bowl, and anti-slip mat.

2.2 Dimensions



Figure 2: Diagram showing the dimensions of the Qinkada Food Processor, including the motor base height (18cm), bowl diameter (22.5cm), and overall assembled height (33.8cm).

3. Assembly and Setup

Follow these steps to correctly assemble your Qinkada Food Processor before use.

1. **Place the Bowl:** Position the stainless steel bowl on a stable, flat surface. Ensure the anti-slip rubber mat is attached to the bottom of the bowl for stability.
2. **Install the Blade:** Carefully place the S-shape bi-level blade assembly onto the fixed shaft inside the bowl. Ensure it sits securely.
3. **Add Ingredients:** Place your desired ingredients into the bowl. Do not overfill the bowl beyond the 'MAX' line.
4. **Cover the Bowl:** Place the food grade lid onto the stainless steel bowl, ensuring it is properly aligned and seated.
5. **Attach Motor Unit:** Carefully place the motor base onto the lid. The hidden safety switch will engage when correctly positioned. The appliance will not operate if the motor unit is not properly installed.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet.



Figure 3: Visual guide for assembling the food processor, showing steps from placing the blade, adding ingredients, covering with the safety lid, installing the motor head, and the final minced result.

4. Operating Instructions

The Qinkada Food Processor features 3-speed modes for versatile processing. Select the appropriate speed based on the ingredients.

4.1 Speed Modes

- **Slow Gear (Speed I):** Ideal for soft vegetables and fruits such as tomatoes, garlic, capsicum, strawberries, and lemon.
- **Mid-range (Speed II):** Suitable for harder vegetables and fruits like potatoes, carrots, beans, nuts, and apples.
- **Fast Gear (Speed III):** Designed for processing meat, including pork, steak, chicken, duck, and fish.



Figure 4: Illustration of the three-speed options (Slow, Mid-range, Fast) and corresponding food types they are best suited for, from soft fruits to meat.

4.2 Processing Tips

- For best results, cut larger ingredients into smaller, uniform pieces before processing.
- Do not overload the bowl. Process in batches if necessary.
- Use short pulses for coarse chopping or to achieve desired consistency. Hold down for continuous processing.
- The appliance is designed for quick chopping. Most ingredients can be processed in 6-10 seconds. Avoid continuous operation for more than 2 minutes to prevent motor overheating.

4.3 Official Product Video

Your browser does not support the video tag.

Video 1: An official product video demonstrating the Qinkada electric meat grinder in operation, showcasing its functionality and ease of use for various ingredients.

5. Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your food processor.

- **Unplug Before Cleaning:** Always unplug the appliance from the power outlet before cleaning.
- **Disassembly:** Disassemble all removable parts: the motor base, lid, blades, and stainless steel bowl.
- **Cleaning Blades and Bowl:** The stainless steel bowl, lid, and blades are dishwasher safe. Alternatively, they can be washed by hand with warm, soapy water. Handle blades with extreme caution due to their sharpness. Use the included cleaning brush for hard-to-reach areas.
- **Cleaning Motor Base:** The motor base contains electrical components and **must not be immersed in water or any other liquid**. Wipe the motor base with a damp cloth, then dry thoroughly.
- **Drying:** Ensure all parts are completely dry before reassembling or storing the appliance.
- **Storage:** Store the assembled food processor in a dry, safe place away from children.

6. Troubleshooting

If you encounter any issues with your Qinkada Food Processor, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	1. Power cord not securely plugged in. 2. Motor unit not correctly assembled on the lid. 3. Overheat protection activated.	1. Ensure the power cord is firmly plugged into a working outlet. 2. Reassemble the motor unit, ensuring it clicks into place and the safety switch is engaged. 3. Unplug and let the unit cool for at least 30 minutes.
Ingredients are not chopping evenly.	1. Bowl is overloaded. 2. Ingredients are too large. 3. Incorrect speed setting.	1. Reduce the amount of ingredients in the bowl and process in smaller batches. 2. Cut ingredients into smaller, uniform pieces. 3. Select a higher speed for harder ingredients or use pulse function for better control.
Motor stops during operation.	1. Overheat protection activated. 2. Bowl is overloaded or ingredients are too dense.	1. Unplug and let the unit cool for at least 30 minutes. Reduce processing time. 2. Reduce the load or cut ingredients into smaller pieces.
Loud noise or vibration during operation.	1. Blades not properly installed. 2. Appliance not on a stable surface. 3. Bowl not correctly seated.	1. Ensure blades are securely placed on the shaft. 2. Place the appliance on a flat, stable, and dry surface. 3. Re-seat the stainless steel bowl and ensure the motor unit is properly attached.

If the problem persists after trying these solutions, please contact Qinkada customer support.

7. Specifications

Feature	Detail

Feature	Detail
Brand	Qinkada
Model Name	Qinkada-Meat Grinder
Product Dimensions	7.7"D x 6.9"W x 12.4"H
Color	Silver
Wattage	500 watts
Recommended Uses	Grind (meat, vegetables, nuts, fruits)
Included Components	Stainless Steel Bowl, Food Scraper, Cleaning Brush
Bowl Capacity	3.5 Liters (14 Cup)
Number of Speeds	3
Voltage	120 Volts
Power Source	AC
Material	Stainless Steel
Product Care Instructions	Dishwasher Safe (bowl, lid, blades)
Blade Material	Stainless Steel
Item Weight	4.1 Pounds
UPC	653871661742

8. Warranty and Support

Qinkada products are manufactured to high-quality standards. This product is covered by a limited warranty against defects in materials and workmanship from the date of purchase.

8.1 Warranty Information

Please retain your proof of purchase for warranty claims. The warranty does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair. For specific warranty terms and conditions, please refer to the warranty card included with your product or contact customer support.

8.2 Customer Support

If you have any questions, require assistance, or need to make a warranty claim, please contact Qinkada Customer Support:

- **Website:** Visit the official Qinkada website (if available) for support resources.
- **Email:** [Insert Customer Support Email Here]
- **Phone:** [Insert Customer Support Phone Number Here]

Please have your model number (Qinkada-Meat Grinder) and purchase date ready when contacting support.

© 2024 Qinkada. All rights reserved.