Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY WESTINGH-VYN

ALLIMITY Replacement Remote Control User Manual

Model: WESTINGH-VYN

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your new ALLIMITY Replacement Remote Control. This remote is designed to be compatible with various Westinghouse TV models, including WD42FB2680, WD50FB2530, WE42UC4200, WD40FW2490, WD32FB2530, and WD40FB2530.

Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

Setup

The ALLIMITY Replacement Remote Control is designed for immediate use with compatible Westinghouse TV models without the need for complex programming or setup procedures.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Rear view of the remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

Once batteries are installed, the remote control is ready for operation.

Operating Instructions

This remote control operates using infrared (IR) technology and is compatible with various Westinghouse Television models. Ensure there is a clear line of sight between the remote control and the TV's IR receiver.





Figure 2: Front view of the ALLIMITY remote control, displaying the layout of all functional buttons.

Button Functions

Button	Function
Power (Red Circle with Line)	Turns the television On or Off.
VUDU / YouTube / Netflix	Direct access buttons for respective streaming applications.
Menu (Three Horizontal Lines)	Opens the TV's main menu.
Back/Return (Curved Arrow)	Returns to the previous screen or menu.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menus and options.
OK	Confirms a selection or enters a menu.
INFO (Green Button)	Displays information about the current program or input.
EXIT	Exits the current menu or application.
Volume Up/Down (VOL +/-)	Adjusts the television's volume level.
Input	Cycles through available input sources (HDMI, AV, etc.).
Channel Up/Down (CH ^/v)	Changes the television channel.
Playback Controls (Rewind, Play/Pause, Fast Forward)	Controls media playback functions.

This remote control is designed to work with Westinghouse TV models:*WD42FB2680, WD50FB2530, WE42UC4200, WD40FW2490, WD32FB2530, WD40FB2530*. It supports up to 20 devices, though its primary function is for television control.

Maintenance

Proper maintenance ensures the longevity and reliable operation of your remote control.

Cleaning

- Wipe the remote control regularly with a soft, dry cloth to remove dust and fingerprints.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the remote's surface or internal components.

Battery Care

- Replace batteries when the remote's response becomes sluggish or inconsistent.

- If the remote control will not be used for an extended period (e.g., more than a month), remove the batteries to prevent leakage and potential damage to the remote.
- Dispose of used batteries according to local regulations.

Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.

Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Remote is not responding.	• **Batteries are dead or inserted incorrectly:** Replace the AAA batteries with new ones, ensuring correct polarity (+/-). • **No clear line of sight:** Ensure there are no obstructions between the remote control and the TV's infrared receiver. • **Remote is too far from the TV:** Move closer to the television.
Certain buttons are not working.	• **Stuck or dirty button:** Gently press the button multiple times. Clean around the button if visible debris is present. • **Battery issue:** Even if some buttons work, low battery power can affect others. Replace batteries.
Remote works intermittently.	• **Low battery power:** Replace batteries. • **Interference:** Ensure no strong light sources (like direct sunlight) are hitting the TV's IR receiver.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	WESTINGH-VYN
Brand	ALLIMITY
Product Dimensions	4 x 1.5 x 0.6 inches
Item Weight	0.634 ounces
Batteries Required	2 x AAA batteries (not included)
Connectivity Technology	Infrared (IR)

Feature	Detail
Compatible Devices	Television (Specific Westinghouse models: WD42FB2680, WD50FB2530, WE42UC4200, WD40FW2490, WD32FB2530, WD40FB2530)
Special Feature	No Programming Required
Max Number of Supported Devices	20 (Primarily for TV control)
Manufacturer	YuedaxinFactory
Date First Available	April 23, 2021

Warranty and Support

Warranty Information

This ALLIMITY Replacement Remote Control comes with a**30-day warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product is free from material and workmanship flaws under normal use.

The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or improper battery installation.

Customer Support

For any questions, concerns, or assistance regarding your remote control, please do not hesitate to contact our customer support team via email. We are committed to helping you resolve any issues promptly.

Please refer to your purchase documentation or the seller's contact information for specific email addresses or support channels.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B093BTYHPR

More documents and user manuals: **https://manuals.plus/**