Davilis MXQ

Davilis MXQ Replacement Remote Control User Manual

For Android TV Boxes

Introduction

This manual provides comprehensive instructions for the Davilis MXQ Replacement Remote Control. This remote is designed to be a direct replacement for various Android TV Box models, offering reliable control without complex setup. Please read this manual carefully to ensure proper use and longevity of your device.





Front view of the Davilis MXQ Replacement Remote Control, showcasing its ergonomic design and button layout.

Setup

1. Battery Installation

The Davilis MXQ Replacement Remote Control requires two AAA batteries (not included) for operation. Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.


UM-4(AAA)
LR03,1.5Vx2



The back of the remote control with the battery compartment cover removed, showing the slots for two AAA batteries.

2. Compatibility Check

This remote control is designed to be compatible with a wide range of Android TV Boxes. It requires no programming; simply insert the batteries, and it should function. However, it is crucial to verify that the button layout of your original remote matches the Davilis remote for full functionality. If the button layout differs significantly, some functions may not work as expected.



An image illustrating the compatible remote control layout (left, marked with a green check) and an incompatible layout (right, marked with a red cross) to help users verify their original remote's button configuration.

Operating Instructions

The Davilis MXQ Replacement Remote Control offers intuitive operation for your Android TV Box. Below is a guide to the main buttons and their functions:



A detailed diagram highlighting the key buttons on the Davilis MXQ Replacement Remote Control, including Power, TV Control, Home, Return, Menu, Cursor, Mute, and Backspace, along with their respective functions.

- **Power Button (Red):** Turns the Android TV Box on or off.
- **TV Control Buttons (Grey):** These buttons (Power, SET, TV IN, VOL-, VOL+) are typically used for controlling basic functions of your television, such as power, input selection, and volume. They may require initial setup with your TV.
- **SETUP Button (Red):** Used for programming the TV Control buttons (if applicable).
- **APP Button (Green):** Quick access to applications.
- **VOL- / VOL+ Buttons (Yellow/Blue):** Adjust the volume of the Android TV Box.
- **Home Button:** Returns to the main home screen of the Android TV Box.
- **Return Button:** Navigates back to the previous screen or menu.
- **Directional Pad (Up, Down, Left, Right) & OK Button:** Used for navigating menus and selecting items. The OK button confirms selections.
- **Menu Button:** Opens context-sensitive menus or options.
- **Cursor Button:** Activates or deactivates a virtual mouse cursor on screen (if supported by the TV Box).

- **Numeric Keypad (0-9):** For direct input of numbers, such as channel selection or passwords.
- **Mute Button:** Mutes or unmutes the audio.
- **Backspace Button:** Deletes characters during text input.

Maintenance

To ensure the longevity and optimal performance of your Davilis MXQ Replacement Remote Control, please follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners, aerosols, or harsh chemicals, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Avoid dropping the remote control or subjecting it to strong impacts, as this can damage internal circuitry.
- **Liquid Exposure:** Keep the remote control away from liquids. If it comes into contact with liquid, remove the batteries immediately and allow it to dry completely before reinserting them.

Troubleshooting

If you encounter issues with your Davilis MXQ Replacement Remote Control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the Android TV Box's infrared receiver.
  - Make sure you are within the effective operating range (up to 10 meters).
- **Specific Buttons Not Working:**
  - Verify that the button layout of your original remote matches the Davilis remote. Some functions may not be supported if the layouts differ significantly.
  - Clean the remote control, especially around the non-functioning buttons, to remove any dirt or debris that might be interfering.
- **TV Control Buttons Not Working:**
  - These buttons may require programming to your specific television model. Refer to the instructions for programming universal remote functions, if available, or consult your TV's manual.
- **Interference:**
  - Infrared signals can be affected by strong light sources, such as direct sunlight or certain types of fluorescent

lighting. Try operating the remote in a different environment.

If the problem persists after trying these steps, please contact customer support.

Specifications

Feature	Detail
Brand	Davilis
Model Name	MXQ
Color	Black
Connectivity Technology	Infrared
Compatible Devices	Android TV Boxes (MXQ, MXQ PRO, PRO 4K, M8S, M8C, M10, M12, M12N, T95M, T95N, T95X, MX9, H96, H96 pro+, TX1, TX2, TX3, TX3 TX5, TX5 MINI, MAX, Q, MAX+, X96, X96 AIR, X96S, X96Q, X96M, DroidPlayer, GBOX, Skystream X4, Element TI4)
Controller Type	Button Control
Number of Buttons	31
Maximum Range	10 Meters
Power Source	2 x AAA Batteries (not included)
Material	Plastic
Special Features	Lightweight, Low Power Consumption
Dimensions (L x W x H)	Approx. 15 x 5 x 2.5 cm
Country of Origin	China



This image displays the physical dimensions of the Davilis MXQ Replacement Remote Control, measuring approximately 14 cm in length, 4.5 cm in width, and 1.8 cm in thickness.

Warranty and Support

Warranty Information

The Davilis MXQ Replacement Remote Control comes with a**24-month manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Spare Parts Availability

Spare parts for this product are available for a period of**2 years** from the date of purchase.

Customer Support

For any issues, questions, or warranty claims, please do not hesitate to contact Davilis customer support. We are committed to assisting you in the best possible way.

Warning:

Not suitable for children under 3 years old.

© 2025 Davilis. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question