Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cirbic JB12

Cirbic JB12 Big Talking Watch with Jumbo Numbers User Manual

Model: JB12

1. Introduction

This manual provides comprehensive instructions for the operation and maintenance of your Cirbic JB12 Big Talking Watch. Designed for individuals with visual impairments, this watch features large, easy-to-read numbers and a clear, loud North American male voice that announces the time and date. Please read this manual carefully to ensure proper use and longevity of your device.



Image 1.1: Front view of the Cirbic JB12 Big Talking Watch, showing the large numbers and the sound icon indicating its talking feature.

2. Setup

2.1 Initial Activation

Your Cirbic JB12 Talking Watch comes with batteries installed and is ready for immediate use. If the watch does not respond to button presses, it may be in a power-saving 'sleep' mode. To activate the watch:

- Press and **hold the single button on the right side of the watch for approximately 5 seconds** until you hear a voice announcement. This will wake the watch from sleep mode.

2.2 Setting Time and Date

The Cirbic JB12 features a simplified one-button setting mechanism. Follow these steps to set the time and date:

1. Ensure the watch is active (not in sleep mode).
2. Press and **hold the single button for approximately 5 seconds** until you hear an announcement indicating entry into 'Setting Mode'. The watch will typically announce the current hour.
3. **To adjust the hour:** While in setting mode, each short press of the button will advance the hour. The watch will announce the hour as it changes.
4. **To confirm the hour and move to minutes:** Press and **hold the button for approximately 3 seconds**. The watch will announce the current minute.
5. **To adjust the minutes:** Each short press of the button will advance the minute.
6. **To confirm minutes and move to year:** Press and **hold the button for approximately 3 seconds**. The watch will announce the current year.
7. Continue this pattern (short press to adjust, 3-second hold to confirm and move to next setting) for the **Year, Month, and Day**.
8. After setting the Day, press and **hold the button for approximately 5 seconds** to exit 'Setting Mode'. The watch will confirm that settings are saved.

If no button is pressed for an extended period during setting mode, the watch may automatically exit setting mode, saving any changes made up to that point.

3. Operating Instructions

The Cirbic JB12 Talking Watch is designed for straightforward operation with its single button.

3.1 Announcing the Time

- To hear the current time announced, simply **press the single button briefly**. The watch will speak the time in a clear North American male voice.

3.2 Announcing the Date

- To hear the current date announced, **press and hold the single button for approximately 3 seconds** The watch will speak the date.

3.3 Sleep Mode

The watch may enter a power-saving 'sleep' mode if inactive for a prolonged period. This helps conserve battery life.

- If the talking feature stops working, the watch is likely in sleep mode. To reactivate it, **press and hold the single button for approximately 5 seconds**.





Image 3.1: Close-up front view of the Cirbic JB12 Big Talking Watch, highlighting the large, clear numbers on the watch face.

4. Maintenance

4.1 Battery Replacement

The Cirbic JB12 Talking Watch is powered by standard watch batteries. When the voice becomes faint or the watch stops functioning, it is time to replace the battery.

- Battery replacement should ideally be performed by a qualified watch technician to prevent damage to the internal components and ensure water resistance (if applicable).
- If attempting replacement yourself, carefully open the watch back using a suitable tool. Note the battery type and orientation before removal. Replace with an identical new battery.

4.2 Cleaning and Care

- Wipe the watch case and strap with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- While the watch is designed for daily wear, avoid submerging it in water unless explicitly stated as water-resistant for swimming.



Image 4.1: Rear view of the Cirbic JB12 Big Talking Watch, showing the stainless steel back cover and the black leather strap with buckle clasp.

5. Troubleshooting

If you encounter issues with your Cirbic JB12 Talking Watch, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Watch does not speak when button is pressed.	Watch is in 'sleep' mode or battery is low/depleted.	Press and **hold the button for 5 seconds** to wake the watch. If still unresponsive, replace the battery.
Time or date is incorrect.	Time/date was not set correctly or has drifted.	Refer to Section 2.2 'Setting Time and Date' to reset the watch.
Voice is faint or distorted.	Low battery.	Replace the battery.
Button feels stuck or unresponsive.	Debris under the button or mechanical issue.	Gently clean around the button. If the issue persists, contact customer support.

6. Specifications

- **Model Number:** JB12
- **Brand:** Cirbic
- **Item Type:** Watch
- **Clasp Type:** Buckle
- **Voice:** North American Male Voice
- **Display:** Analog with Jumbo Numbers
- **Package Dimensions:** 5.75 x 2.17 x 1.46 inches
- **Item Weight:** 2.47 ounces
- **Manufacturer:** Cirbic
- **First Available:** May 7, 2021

7. Warranty and Support

For information regarding product warranty, please refer to the documentation included with your purchase or contact Cirbic customer support directly. For technical assistance or further inquiries, please visit the official Cirbic website or use the contact information provided with your product.

© 2023 Cirbic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What battery type is needed for the Cirbic JB12 Big Talking Watch?

The user manual for the Cirbic JB12 Big Talking Watch does not specify a specific battery model number (such as CR2032 or SR626SW). Instead, it describes the power source as "standard watch batteries." Because...

Read full answer

Open the live page

https://manuals.plus/asin/B094DG5ZDQ

More documents and user manuals: **https://manuals.plus/**