Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gracemind 1089D

Gracemind Wireless Bluetooth Keyboard with Touchpad Instruction Manual

Model: 1089D

1. Introduction

Product Overview

This manual provides instructions for the Gracemind Wireless Bluetooth Keyboard with Touchpad, designed to enhance your Microsoft Surface Pro experience. It features a detachable magnetic design, 7-color adjustable backlighting, and a responsive touchpad.

Compatibility

This keyboard is compatible with the following Microsoft Surface Pro models:

- Microsoft Surface Pro 3
- Microsoft Surface Pro 4
- Microsoft Surface Pro 5
- Microsoft Surface Pro 6
- Microsoft Surface Pro 7
- Microsoft Surface Pro 7+

Note: This keyboard is not compatible with Surface Go 3, Surface Go 2, Surface Go 2018, or Surface 3.

Image 1.1: Compatibility chart for the Gracemind Wireless Bluetooth Keyboard.

2. What's in the Box

Please verify that all items are present in the package:

- Gracemind Wireless Bluetooth Keyboard with Touchpad
- USB Charging Cable
- User Manual (this document)

3. Setup

3.1 Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the provided USB charging cable to the keyboard's Type-C charging port and to a USB power source (e.g., computer, wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.

- Charging Time: Approximately 2.5 hours
- Continuous Usage (backlight off): Up to 125 hours
- Continuous Usage (backlight on): Up to 5 hours
- Standby Time: Up to 100 days



Image 3.1: Keyboard structure display highlighting the Type-C charging port and magnetic adsorption.



Image 3.2: Battery endurance details for the keyboard.

3.2 Bluetooth Pairing

Follow these steps to pair your keyboard with your Microsoft Surface Pro:

1. Ensure the keyboard is charged.
2. Turn on the keyboard by sliding the power switch (usually located on the side or top edge). The Bluetooth indicator light will blink.
3. On your Surface Pro, go to **Settings** > **Devices** > **Bluetooth & other devices**.
4. Ensure Bluetooth is turned **On**.
5. Click **Add Bluetooth or other device**, then select **Bluetooth**.
6. The Surface Pro will search for nearby Bluetooth devices. Select "Bluetooth Keyboard" or a similar name from the list.
7. Follow any on-screen prompts to complete the pairing process. The Bluetooth indicator on the keyboard will stop blinking once successfully paired.



Image 3.3: Wireless Bluetooth connection with magnetic attachment.

Your browser does not support the video tag.

Video 3.1: This video demonstrates the Bluetooth pairing process for the Gracemind keyboard with a Surface Pro device.

3.3 Attaching and Detaching the Keyboard

The keyboard features a strong magnetic attachment strip for easy connection to your Surface Pro. Align the magnetic strip of the keyboard with the bottom edge of your Surface Pro until it snaps into place.

- **To Attach:** Bring the top edge of the keyboard close to the bottom edge of your Surface Pro. The magnets will guide it into position.
- **To Detach:** Gently pull the keyboard away from the Surface Pro.



Image 3.4: Keyboard attachment and detachment options with adjustable angles.

4. Operating Instructions

4.1 Backlight Functions

The keyboard features 7-color backlighting with 3 brightness levels.

- **To Adjust Brightness:** Press the **Fn** key simultaneously with the ☀ (sun icon) button. Cycle through 3 brightness levels.
- **To Change Backlight Color:** Press the ☀ (sun icon) button alone to cycle through 7 different colors.

Image 4.1: 7-color backlight options and 3 brightness levels.

Image 4.2: Keyboard function key guide for backlight and touchpad controls.

4.2 Touchpad Usage

The integrated touchpad allows for precise navigation and control of your Surface Pro, similar to a mouse.

- **To Lock/Unlock Touchpad:** Press the **Fn** key simultaneously with the (touchpad icon) button. This can prevent accidental input during typing.

4.3 Adjustable Typing Angles

The keyboard can be positioned at two different angles for comfortable typing and viewing. The strong magnetic attachment ensures stability.

- **Flat Position:** Attach the keyboard directly to the Surface Pro for a flat typing surface.
- **Angled Position:** Attach the keyboard and then slightly fold the top edge upwards to create an ergonomic angle.

5. Maintenance

5.1 Cleaning

To clean your keyboard, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the finish or keys. Ensure the keyboard is powered off before cleaning.

5.2 Battery Care

To prolong battery life:

- Avoid fully discharging the battery frequently.
- Charge the keyboard regularly, even if not in constant use.
- Store the keyboard in a cool, dry place when not in use for extended periods.

6. Troubleshooting

6.1 Keyboard Not Responding

- Ensure the keyboard is powered on.
- Check the battery level and charge the keyboard if necessary.
- Verify Bluetooth connection (see Section 3.2). Try re-pairing the device.

- Restart your Surface Pro and the keyboard.

6.2 Bluetooth Connection Issues

- Ensure the keyboard is within the 10-meter (33 ft) Bluetooth range of your Surface Pro.
- Turn off and then turn on Bluetooth on your Surface Pro.
- Remove the keyboard from your Surface Pro's Bluetooth device list and then re-pair it.
- Ensure no other devices are interfering with the Bluetooth signal.

6.3 Backlight Not Working

- Ensure the keyboard is powered on and charged.
- Press the backlight control keys (Fn + ☀ or ☀ alone) to activate or change the backlight settings.

6.4 Touchpad Sensitivity/Jumping Cursor

- Ensure the touchpad is not locked (Fn +).
- Clean the touchpad surface to remove any dirt or debris.
- Adjust touchpad sensitivity settings in your Surface Pro's operating system.

6.5 Charging Issues

- Ensure the USB charging cable is securely connected to both the keyboard and the power source.
- Try a different USB cable or power adapter.
- Verify the charging port on the keyboard is free of debris.

7. Specifications

Feature	Specification
Brand	Gracemind
Model Number	1089D
Connectivity Technology	Bluetooth 5.0
Compatible Devices	Microsoft Surface Pro 3/4/5/6/7/7+
Keyboard Layout	QWERTY (78 keys)
Backlight	7 Colors, 3 Brightness Levels
Battery Capacity	550mAh Rechargeable
Charging Port	Type-C
Material	Polyurethane (PU)
Dimensions (L x W x H)	11.65" x 8.66" x 0.26" (29.6cm x 22cm x 0.66cm)
Weight	325 g
Operating System Compatibility	Windows (Minimum Windows 10)

Image 7.1: Keyboard dimensions.

8. Warranty and Support

8.1 Warranty Information

Gracemind products are covered by a limited warranty against defects in materials and workmanship. Please refer to the product packaging or contact customer support for specific warranty terms and duration.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact Gracemind customer support through the retailer where the product was purchased or visit the official Gracemind website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B094FYHFDQ

More documents and user manuals: **https://manuals.plus/**