Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-MB-10001-QYSY

ALLIMITY Replacement Remote Control User Manual

For BLAUPUNKT TV Models

Introduction

Thank you for choosing the ALLIMITY Replacement Remote Control. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new remote control. This remote is designed to replace your original BLAUPUNKT TV remote, offering full functionality without the need for complex programming.
Compatible Models:

- 32/124I-WB-5B-HBKUP-UK
- 32/122I-GB-5B-HBKU-UK
- 32-56J-GB-5B-F3HKUP
- 32/112J-GB-3B2-HKUP-EU
- 215/155J-GB-1B-FHBKUP-UK

Setup

Setting up your ALLIMITY replacement remote control is straightforward. No programming or pairing is required.

1. **Insert Batteries:** Locate the battery compartment on the back of the remote control. Open the cover and insert two AAA alkaline batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
2. **Close Compartment:** Securely close the battery compartment cover.
3. **Ready for Use:** The remote control is now ready to operate your compatible BLAUPUNKT TV.





Figure 1: Front view of the ALLIMITY replacement remote control, showing all buttons and layout.

Operating Instructions

This remote control provides access to all standard functions of your BLAUPUNKT TV. Familiarize yourself with the button layout for optimal use.

- **Power Button (STANDBY):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **Volume Control (VOL +/-):** Adjusts the audio volume.
- **Channel Control (CH +/-):** Changes channels sequentially.
- **Mute Button (MUTE):** Mutes or unmutes the TV audio.
- **Source/Input (SOURCE):** Cycles through available input sources (HDMI, AV, etc.).
- **Menu Button (MENU):** Accesses the TV's main menu for settings and options.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Exit Button (EXIT):** Exits the current menu or function.
- **Playback Controls (REC, Play, Pause, Stop, Fast Forward, Rewind):** For controlling media playback on connected devices (e.g., USB, DVD).
- **TV/RADIO:** Switches between TV and Radio modes.
- **USB/DVD:** Dedicated buttons for USB and DVD functions.



Figure 2: Angled view of the remote control, highlighting the ergonomic design and button placement.

Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new alkaline batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

If you encounter issues with your remote control, try the following solutions:

- **Remote Not Responding:**
  - Check the batteries. Ensure they are inserted correctly with the proper polarity.
  - Replace old batteries with new alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Make sure you are within the effective range (up to 10 meters) of the TV.
- **Specific Buttons Not Working:**
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be preventing contact.
  - If cleaning does not help, the button mechanism might be faulty.
- **No Programming Required:** Remember, this remote does not require programming. If it's not working, the issue is almost certainly battery-related or an obstruction, not a programming error.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	QYSY-MB-10001-QYSY
Connectivity Technology	Infrared
Compatible Devices	Television
Maximum Range	10 Meters
Battery Type	Alkaline
Number of Buttons	25
Maximum Supported Devices	10 (referring to the remote's capability to replace multiple original remotes, not control 10 devices simultaneously)
Manufacturer	ALLIMITYQYSY
Country of Origin	China

Warranty and Support

For warranty information and customer support, please refer to the purchase documentation or contact the seller directly. Specific details regarding spare parts availability and software updates are not provided for this product. For further assistance, you may also visit the official ALLIMITY website or contact their customer service if available.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B094JFBFM7

More documents and user manuals: **https://manuals.plus/**