Fagor FGE0072

Fagor Lexie Portable Induction Hob User Manual

Model: FGE0072

1. Introduction

Thank you for choosing the Fagor Lexie Portable Induction Hob, Model FGE0072. This compact and powerful induction cooker is designed for efficient and convenient cooking. With its 2000W power, ultra-slim design, and intuitive touchscreen controls, it offers a versatile cooking experience for various culinary needs. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance.



Image 1.1: The Fagor Lexie Portable Induction Hob with a frying pan containing cooked food, demonstrating its use. The hob features a sleek black glass surface and a clear control panel.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, always follow basic safety precautions, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure proper ventilation around the unit during operation.
- Only use induction-compatible cookware. Non-compatible cookware will not heat up.
- The appliance features overheat protection. If the hob overheats, it will automatically shut down.

3. Product Features

The Fagor Lexie Portable Induction Hob is equipped with advanced features for a superior cooking experience:

- **Powerful Performance:** 2000 Watts of power for rapid heating and efficient cooking.
- **Ultra-Slim Design:** Compact and portable, making it easy to transport and store.
- **Intuitive Touchscreen:** Modern touch control panel for easy operation.
- **6 Predefined Functions:** Dedicated settings for BBQ, Fry, Hot Pot, Soup, Water, and Warm.
- **9 Heating Levels:** Precise control over cooking intensity.
- **Adjustable Temperature:** Temperature control ranging from 80°C to 200°C.
- **Integrated Timer:** Set cooking times up to 60 minutes.
- **Safety Lock Function:** Prevents accidental changes to settings.
- **Overheat Protection:** Automatic shutdown feature for enhanced safety.



Image 3.1: A promotional image of the Fagor Lexie Induction Cooker, showcasing its key features such as 2000W power, super slim design, touch panel with 6 functions, 9 heating levels, lock button, timer, On/Off button, and dimensions.

4. Setup

Follow these steps to set up your Fagor Lexie Portable Induction Hob:

1. **Unpack:** Carefully remove the induction hob from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the hob on a flat, stable, heat-resistant surface. Ensure there is adequate space around the unit for ventilation (at least 10 cm on all sides). Do not place it on a metal surface.
3. **Power Connection:** Plug the power cord into a standard 220V electrical outlet. Ensure the outlet is properly grounded.
4. **Cookware:** Ensure you are using induction-compatible cookware. This typically includes pots and pans made of cast iron, magnetic stainless steel, or those with a magnetic base. If a magnet sticks to the bottom of your cookware, it is likely induction-compatible.



Image 4.1: The Fagor Lexie Portable Induction Hob surrounded by shrimp and lemon slices, with text indicating its compatibility with induction cookware.

5. Operating Instructions

Operating your Fagor Lexie Portable Induction Hob is straightforward with its intuitive touchscreen controls.



Image 5.1: A top-down view of the Fagor Lexie Portable Induction Hob, clearly showing its touch control panel with various function icons and the digital display.

5.1. Basic Operation

1. **Power On/Off:** Press the **ON/OFF** button to turn the hob on or off. The display will light up when powered on.
2. **Place Cookware:** Place your induction-compatible pot or pan centrally on the cooking zone.
3. **Select Function:** Choose one of the 6 predefined functions by pressing the corresponding icon:
    - **BBQ:** For grilling or searing.
    - **Fry:** For frying foods.
    - **Hot Pot:** Ideal for hot pot dishes.
    - **Soup:** For simmering soups and stews.
    - **Water:** For boiling water quickly.
    - **Warm:** To keep food warm.
4. **Adjust Heating Level/Temperature:** Use the **UP** and **DOWN** buttons to adjust the heating level (1-9) or temperature (80°C-

200°C) depending on the selected function.

5.2. Timer Function

- Press the **TIMER** button.
- Use the **UP** and **DOWN** buttons to set the desired cooking time, up to 60 minutes.
- The hob will automatically turn off once the timer expires.

5.3. Lock Function

- Press the **LOCK** button to disable the control panel and prevent accidental changes to settings during cooking.
- Press the **LOCK** button again to unlock the control panel.

6. Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your induction hob.

- **Before Cleaning:** Always unplug the hob from the power outlet and allow it to cool completely before cleaning.
- **Cleaning the Surface:** Wipe the glass surface with a soft, damp cloth and a mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic or induction cooktops.
- **Avoid Abrasives:** Do not use abrasive pads, harsh chemicals, or scouring agents, as these can scratch or damage the glass surface.
- **Control Panel:** Gently wipe the control panel with a soft, dry cloth. Do not allow water to seep into the control area.
- **Ventilation Openings:** Ensure the ventilation openings on the sides and bottom of the hob are free from dust and debris. Use a soft brush or vacuum cleaner if necessary.
- **Storage:** When not in use, store the hob in a cool, dry place, away from direct sunlight and moisture.

7. Troubleshooting

If you encounter any issues with your Fagor Lexie Portable Induction Hob, refer to the following table for common problems and their solutions:

Problem	Possible Cause	Solution
Hob does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the power cord is securely plugged in. Check the power supply. Try a different outlet.
Cookware is not heating.	Cookware is not induction-compatible; cookware is too small or not centered; no cookware on hob.	Use induction-compatible cookware. Ensure the cookware base covers the cooking zone. Place cookware centrally.
Hob makes a humming or buzzing noise.	Normal operation of the cooling fan; resonance from cookware.	This is normal. The cooling fan operates to prevent overheating. Some cookware may produce a slight hum due to material composition.
Hob shuts off unexpectedly.	Overheat protection activated; timer expired; cookware removed.	Allow the hob to cool down. Check if the timer was set. Ensure cookware remains on the hob during operation.
Control panel is unresponsive.	Lock function is activated; dirty control panel.	Press the **LOCK** button to deactivate the lock. Clean the control panel surface.

8. Specifications

Feature	Detail
Brand	Fagor
Model Number	FGE0072
Power Output	2000 Watts
Voltage	220 Volts
Product Dimensions (L x W x H)	37 x 29 x 5 cm
Weight	350 Grams
Color	Black
Material	Glass
Control Type	Button, Touchscreen
Number of Heating Elements	1
Special Feature	Portable



Image 8.1: A side perspective of the Fagor Lexie Portable Induction Hob, illustrating its compact dimensions of 29cm width, 37cm length, and 5cm height.

9. What's in the Box

Upon opening the package, you will find the following items:

- 1 x Fagor Lexie 2000 Watt Induction Hob (29 x 37 x 5 cm)
- 1 x User Manual (this document)

10. Warranty and Support

Fagor products are manufactured to high-quality standards. For any warranty claims, technical support, or service inquiries, please contact Fagor customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Fagor website or contact their customer support line.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question