Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool WB70I952X

Whirlpool Combined Refrigerator User Manual

Model: WB70I952X / 869991631130
Brand: Whirlpool

1. Important Safety Information

Please read these instructions carefully before using your appliance and retain them for future reference. This manual provides essential information for the safe installation, use, and maintenance of your refrigerator.

- Ensure the appliance is disconnected from the power supply before performing any maintenance or cleaning.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments, unless they are of the type recommended by the manufacturer.
- This appliance is intended for household use only.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

2. Setup and Installation

2.1 Unpacking and Placement

Unpack the refrigerator carefully and remove all packaging materials. This is a freestanding appliance. Ensure adequate ventilation space around the unit. Do not place the appliance in direct sunlight or near heat sources.

Dimensions (H x W x D): 195 x 70 x 75.5 cm

Weight: 84 kg



Figure 2.1: Technical drawing with dimensions for installation planning.

2.2 Leveling and Door Reversibility

Level the appliance using the adjustable feet to ensure proper door closure and efficient operation. The doors of this refrigerator are reversible, allowing you to change the opening direction to suit your kitchen layout. Refer to the detailed installation guide for instructions on reversing the doors.



Figure 2.2: Exterior view of the Whirlpool combined refrigerator.

2.3 Electrical Connection

Connect the appliance to a grounded electrical outlet. Ensure the voltage matches the rating plate on the appliance. After installation, wait at least 2-3 hours before plugging in the appliance to allow the refrigerant to settle.

3. Operating Instructions

3.1 Control Panel and Temperature Settings

The refrigerator features an electronic thermostat for precise temperature control. The control panel is located at the top of the refrigerator compartment.



Figure 3.1: Electronic control panel for temperature adjustment and function selection.

- **Temperature Adjustment:** Use the controls to set the desired temperature for both the refrigerator and freezer compartments.
- **Fast Freeze Function:** Activate this function for rapid freezing of fresh food, preserving its quality.
- **6th Sense Technology:** This intelligent technology continuously monitors the temperature inside the refrigerator and automatically adjusts it to maintain optimal conditions, reducing energy consumption.

3.2 Interior Features

The refrigerator is equipped with various features designed for optimal food storage.



Figure 3.2: Interior layout of the refrigerator and freezer.

- **No Frost System:** Both the refrigerator and freezer compartments feature a Total No Frost system, preventing ice build-up and eliminating the need for manual defrosting.
- **Multiflow Column:** Ensures even temperature distribution throughout the refrigerator compartment.
- **LED Interior Lighting:** Provides bright and energy-efficient illumination of the refrigerator interior.
- **Glass Shelves:** Three glass shelves, two of which are adjustable, provide flexible storage options.
- **0° Compartment:** A dedicated compartment for delicate foods requiring a colder temperature.
- **Vegetable Crisper:** A transparent drawer designed to maintain the freshness of fruits and vegetables.
- **Door Alarm:** An audible alarm will sound if the refrigerator door is left open for too long.

4. Maintenance and Cleaning

4.1 Defrosting

This appliance features an automatic defrosting system for both the refrigerator and freezer compartments. No manual defrosting is required.

4.2 Cleaning the Interior

Before cleaning, always unplug the appliance. Clean the interior regularly with a solution of lukewarm water and a mild, non-abrasive detergent. Rinse thoroughly and dry with a soft cloth. Avoid using abrasive cleaners, scouring pads, or solvents.

4.3 Cleaning the Exterior

Clean the exterior surfaces with a soft cloth and a mild detergent. For stainless steel surfaces, use a specialized stainless steel cleaner and polish in the direction of the grain. Do not spray water directly onto the appliance.

5. Troubleshooting

If you encounter any issues with your refrigerator, please consult the following common troubleshooting tips before contacting service.

- **Appliance not cooling:** Check if the power cord is securely plugged in. Ensure the circuit breaker has not tripped. Verify that the temperature settings are correct.
- **Door alarm sounding:** Close the door completely. Ensure no items are obstructing the door from closing properly.
- **Excessive noise:** Check if the appliance is level. Ensure there is sufficient space around the unit for proper ventilation.
- **Water on the floor:** Check if the drain hole in the refrigerator compartment is clear. Ensure the appliance is level.

If the problem persists after checking these points, please refer to the warranty and support section for assistance.

6. Specifications

Feature	Specification
Model Number	WB70I952X / 869991631130
Brand	Whirlpool
Installation Type	Freestanding
Dimensions (H x W x D)	195 x 70 x 75.5 cm
Net Weight	84 kg
Total Volume	462 Liters
Refrigerator Volume	309 Liters

Feature	Specification
Freezer Volume	153 Liters
Energy Efficiency Class	E
Annual Energy Consumption	291 kWh/year
Noise Level	37 dB
Defrost System	Automatic (No Frost)
Refrigerant Type	R600A
Climate Class	SN-N-ST-T
Freezing Capacity	18 kg/24 h
Autonomy (Power Cut)	15 hours
Door Reversibility	Yes
Special Features	Electronic Thermostat, 6th Sense, Multiflow Column, LED Lighting, Door Alarm, Fast Freeze Function



Figure 6.1: Energy efficiency label indicating class E.

7. Warranty and Support

7.1 Manufacturer's Warranty

This Whirlpool appliance comes with a**2-year manufacturer's commercial warranty**. Please retain your proof of purchase for warranty claims.

7.2 Spare Parts Availability

Information regarding the availability of spare parts is currently unavailable. Please contact customer support for further details.

7.3 Customer Support

For technical assistance, warranty service, or general inquiries, please contact Whirlpool customer support. Contact details can typically be found on the official Whirlpool website or in the documentation provided with your appliance.

© 2025 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B094YH7BZP

More documents and user manuals: **https://manuals.plus/**