Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool WB70E 972 X

Whirlpool WB70E 972 X Freestanding Refrigerator-Freezer User Manual

Model: WB70E 972 X

1. Introduction

Thank you for choosing a Whirlpool appliance. This user manual provides essential information for the safe and efficient use of your new WB70E 972 X Freestanding Refrigerator-Freezer. Please read these instructions carefully before installation and use, and keep them for future reference.

2. Safety Information

Your safety and the safety of others are paramount. This manual contains important safety messages that must be read and observed at all times.

- Ensure the appliance is properly grounded.
- Do not use electrical adapters or extension cords.
- Keep ventilation openings clear of obstruction.
- Do not damage the refrigerant circuit.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. Setup and Installation

3.1 Unpacking

Remove all packaging materials. Ensure no parts are missing or damaged. Keep packaging materials out of reach of children.

3.2 Placement

Place the refrigerator-freezer on a firm, level floor. Avoid direct sunlight and heat sources (e.g., radiators, cookers). Ensure adequate ventilation around the appliance. Maintain a minimum distance of 5 cm from walls and other furniture to allow for proper air circulation.



Figure 1: Front view of the Whirlpool WB70E 972 X Refrigerator-Freezer.

3.3 Leveling

Adjust the front feet to level the appliance. This prevents vibrations and ensures proper door closure.

3.4 Electrical Connection

Connect the appliance to a properly grounded electrical outlet. The voltage and frequency must match the specifications on the rating plate inside the appliance. Do not use multi-plugs or extension cords.

3.5 Initial Startup

After installation, wait at least 2-4 hours before plugging in the appliance to allow the refrigerant to settle. Once plugged in, set the temperature controls and allow the appliance to cool for several hours before loading food.




Figure 2: Installation diagram with recommended clearances.

4. Operating Instructions

4.1 Control Panel

The control panel, typically located on the top front of the refrigerator door, allows you to adjust temperature settings and activate special functions. Refer to the specific icons on your appliance for detailed functions.

4.2 Temperature Settings

The refrigerator and freezer compartments have adjustable temperature controls. Recommended settings are usually +4°C for the refrigerator and -18°C for the freezer. Adjust as needed based on ambient temperature and food load.

4.3 Food Storage Guidelines

- **Refrigerator Compartment:** Store fresh foods such as fruits, vegetables, dairy products, and cooked meals. Use the crisper drawers for produce.
- **Freezer Compartment:** Suitable for long-term storage of frozen foods. Do not place hot food directly into the freezer.
- Ensure food is properly wrapped or sealed to prevent drying out and odor transfer.



Figure 3: Interior layout of the refrigerator and freezer compartments.



Figure 4: Detailed view of the refrigerator's adjustable shelves and crisper drawer.

4.4 No Frost System

This appliance features a No Frost system, which prevents ice build-up in the freezer compartment, eliminating the need for manual defrosting. This system also helps maintain a more consistent temperature throughout the refrigerator.

5. Maintenance and Cleaning

5.1 Cleaning the Interior

Unplug the appliance before cleaning. Clean the interior regularly with a solution of warm water and mild detergent. Rinse thoroughly and dry completely. Do not use abrasive cleaners or sharp objects.

5.2 Cleaning the Exterior

Wipe the exterior surfaces with a soft cloth dampened with water and a mild detergent. For stainless steel surfaces, use a specialized stainless steel cleaner and polish in the direction of the grain.

5.3 Door Seals

Check the door seals regularly for cleanliness and damage. Clean them with warm water and ensure they are dry. Damaged seals can lead to inefficient operation.

5.4 Power Outage

In case of a power outage, keep the doors closed to maintain the internal temperature for as long as possible. Avoid opening the doors unnecessarily.

6. Troubleshooting

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate	No power supply	Check if the plug is inserted correctly and the circuit breaker is on.
Temperature is not cold enough	Door opened too frequently; large amount of warm food added; poor ventilation; temperature setting too high	Reduce door openings; allow food to cool before storing; ensure proper ventilation; adjust temperature setting lower.
Unusual noises	Appliance not level; objects touching the back wall; compressor noise	Level the appliance; ensure nothing is touching the back; compressor noise is normal during operation.
Water on the floor	Drain hole blocked; drip tray overflowing	Clear the drain hole; check and empty the drip tray if accessible.

If the problem persists after checking these points, please contact customer service.

7. Specifications

Feature	Specification
Brand	Whirlpool
Model Number	WB70E 972 X
Capacity	462 Liters
Configuration	Bottom Freezer
Color	Metallic (Stainless Steel)
Installation Type	Freestanding
Number of Doors	2
Defrost System	No Frost

Feature	Specification
Adjustable Temperature Control	Yes
Product Dimensions (L x W x H)	2.79 x 24.64 x 16.51 cm (approximate, check actual product for precise measurements)
Item Weight	88 Kilograms

8. Warranty and Support

This Whirlpool appliance comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. Keep your proof of purchase for warranty claims.
For technical assistance, spare parts, or to report a fault, please contact Whirlpool customer service. Contact details can typically be found on the Whirlpool website or in the documentation provided with your appliance.

© 2023 Whirlpool. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B094YKNM8J

More documents and user manuals: **https://manuals.plus/**