JOYOUNG JY-580

JOYOUNG Air Fryer Toaster Oven User Manual

Model: JY-580

1. Introduction

Thank you for choosing the JOYOUNG Air Fryer Toaster Oven. This appliance combines the functionality of an air fryer and a convection oven, offering versatile cooking options with less oil. This manual provides essential information for safe operation, proper maintenance, and effective use of your new appliance. Please read it thoroughly before first use and keep it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Always place the appliance on a stable, heat-resistant surface, away from walls and other appliances to allow for proper ventilation.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the power supply voltage matches the rating on the appliance.
- Do not touch hot surfaces. Use oven mitts or gloves when handling hot components or food. The dual-wall glass window is designed to reduce external temperature, but surfaces can still be hot.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool completely before handling or storing.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.
- Do not place any materials other than manufacturer-recommended accessories in the oven.

3. Product Overview

The JOYOUNG Air Fryer Toaster Oven is designed for convenience and efficiency in your kitchen. It features a robust stainless steel construction and intuitive controls.



Figure 3.1: Front view of the JOYOUNG Air Fryer Toaster Oven, showcasing the digital display, control knob, and large glass door.

Key Features:

- **Intuitive One-Touch Operation Panel:** Features 14 settings and 8 smart preset programs for various recipes, including French fries, cake, pizza, air fry, dehydrate, slow cook, defrost, ferment, and keep warm.
- **Premium Metal and Glass Structure:** Full metal inner and outer structure for durability, with a dual-wall glass window and cold-touch handle for safety.
- **25QT Large Capacity:** Spacious 25-quart / 24L interior accommodates up to a 3-pound chicken, a 10-inch pizza, or 9 muffins, suitable for family-sized meals.
- **Powerful and Efficient:** 1700W high power enables rapid warm-up within 3 minutes.
- **Precise Temperature Control:** Wide temperature range of 100-450°F with 10°F adjustment increments and up to a 72-hour timer for precise culinary control.
- **Healthy Cooking:** 360° air flow technology ensures crispy results with up to 90% less fat compared to traditional deep-frying.



Figure 3.2: Close-up of the intuitive one-touch operation panel, displaying various preset functions for easy cooking.



Figure 3.3: Illustration of the 360° air flow technology, showing hot air circulating around food for even cooking and crisping.



Figure 3.4: The spacious 25-quart interior of the oven, capable of fitting a whole chicken, pizza, or multiple muffins.

4. Setup

Unpacking:

Carefully remove all packaging materials from the appliance and its accessories. Ensure all components listed in the packing list are present and undamaged. Keep packaging for future storage or transport if needed.

Placement:

Place the air fryer toaster oven on a flat, stable, and heat-resistant surface. Ensure there is at least 6 inches (15 cm) of clear space on all sides of the appliance for adequate air circulation. Do not place it near flammable materials or under cabinets.

Before First Use:

1. Wipe the exterior of the appliance with a damp cloth.
2. Wash all removable accessories (air fry basket, baking pan, crumb tray) with warm, soapy water. Rinse thoroughly and dry completely.

3. Insert the crumb tray at the bottom of the oven.
4. Plug the appliance into a grounded electrical outlet.
5. To eliminate any manufacturing odors, run the oven empty for about 15 minutes at 350°F (175°C) in 'Bake' mode. A slight odor or smoke is normal during this initial use. Ensure the area is well-ventilated.

5. Operating Instructions

Control Panel Overview:

The control panel features a digital display, function buttons, and a time/temperature control knob. The display shows the selected temperature and remaining cooking time.

Using Preset Functions:

The oven comes with 14 preset functions for common dishes. To use a preset:

1. Place food on the appropriate accessory (e.g., air fry basket for air frying, baking pan for baking).
2. Close the oven door.
3. Press the 'Function' button repeatedly or turn the 'Function' knob to select the desired preset (e.g., 'Air Fry', 'Roast', 'Bake'). The corresponding icon will illuminate on the display.
4. The oven will display a default time and temperature for the selected preset. You can adjust these settings using the 'Time/Temp' knob.
5. Press the 'Start/Pause' button to begin cooking.

Manual Operation:

For custom cooking, you can manually set the time and temperature:

1. Place food inside the oven.
2. Turn the 'Time/Temp' knob to set the desired temperature (100-450°F).
3. Press the 'Time/Temp' knob to switch to time setting, then turn it to set the desired cooking time (up to 72 hours).
4. Press the 'Start/Pause' button to begin cooking.

Cooking Demonstration: Grilled Open Party Sandwiches

Your browser does not support the video tag.

Video 5.1: This video demonstrates how to prepare and cook 'Grilled Open Party Sandwiches' using the JOYOUNG Air Fryer Toaster Oven. It showcases the baking and air frying functions, highlighting the ease of use for various recipes.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your appliance.

General Cleaning:

1. Always unplug the oven and allow it to cool completely before cleaning.
2. Wipe the exterior with a damp cloth and mild detergent. Do not use abrasive cleaners or scouring pads.
3. Clean the interior with a damp cloth and mild, non-abrasive cleaner. For stubborn stains, a paste of baking soda and water can be used.
4. The crumb tray should be emptied and cleaned regularly to prevent grease buildup.

Accessory Cleaning:

All accessories, including the air fry basket, baking pan, and crumb tray, are dishwasher-safe for convenient cleaning.



Figure 6.1: The oven's accessories, including the air fry basket and baking pan, are designed to be easily cleaned and are dishwasher-safe.

7. Troubleshooting

If you encounter issues with your JOYOUNG Air Fryer Toaster Oven, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; circuit breaker tripped.	Ensure plug is securely in a working outlet. Check household circuit breaker.
Food is not cooking evenly.	Overcrowding the basket; incorrect temperature/time setting.	Avoid overcrowding; cook in smaller batches. Adjust temperature and time as needed. Shake or flip food halfway through cooking.

Problem	Possible Cause	Solution
White smoke coming from the appliance.	Grease residue from previous use; high-fat food.	Clean the appliance and accessories thoroughly after each use. For high-fat foods, drain excess fat from the crumb tray during cooking.
Appliance emits a burning smell.	Food particles or grease buildup on heating elements.	Unplug and allow to cool. Clean the interior, especially around heating elements, ensuring no food debris remains.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

Specification	Detail
Model Name	KX24-V580U
Item Model Number	JY-580
Color	Silver
Capacity	25 Quarts (24 Liters)
Material	Stainless Steel
Output Wattage	1700 Watts
Voltage	120 Volts
Control Method	Touch / Button Control
Min Temperature Setting	100 Degrees Fahrenheit
Max Temperature Setting	450 Degrees Fahrenheit
Product Dimensions	21 x 17 x 19 inches
Item Weight	23.9 pounds
Dishwasher Safe Parts	Yes (Accessories)

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official JOYOUNG website. You may also find additional resources and FAQs on the product support page.
A digital version of the user guide is available for download: User Guide (PDF)

© 2024 JOYOUNG. All rights reserved.