Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LG GBB61PZGCN

LG GBB61PZGCN Combi Refrigerator User Manual

Model: GBB61PZGCN | Brand: LG

1. Important Safety Instructions

Please read all instructions carefully before using your new LG GBB61PZGCN Combi Refrigerator. Keep this manual for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the appliance is properly grounded.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Unplug the refrigerator before cleaning or performing any maintenance.
- Do not damage the refrigerant circuit.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

2. Setup and Installation

2.1 Unpacking

Remove all packaging materials, including tape and protective films. Inspect the refrigerator for any damage. Keep packaging materials out of reach of children.

2.2 Location

Place the refrigerator on a firm, level floor. Ensure there is adequate space around the appliance for proper ventilation (at least 5 cm at the back and sides, and 10 cm at the top). Avoid direct sunlight or heat sources. This model is a freestanding unit, offering flexibility in placement.



This image shows the front view of the LG GBB61PZGCN Combi Refrigerator, highlighting its metallic finish and two-door design with the freezer compartment at the bottom.

2.3 Leveling

Adjust the leveling feet at the bottom front of the refrigerator to ensure it is stable and level. This prevents vibrations and ensures proper door sealing.

2.4 Power Connection

Connect the power cord to a dedicated, properly grounded wall outlet. Do not use extension cords or adapters. Wait at least 2-3 hours before plugging in the refrigerator after moving it to allow the refrigerant to settle.

2.5 Initial Operation

After plugging in, allow the refrigerator to operate for several hours (approximately 4-6 hours) to reach its optimal operating temperature before storing food.

3. Operating Instructions

3.1 Control Panel

The control panel, typically located inside the refrigerator compartment or on the exterior door, allows you to adjust temperature settings and activate special functions. Refer to the specific icons and buttons on your model.

3.2 Temperature Adjustment

This refrigerator features adjustable temperature control. Press the temperature control button to cycle through available settings for both the refrigerator and freezer compartments. Recommended settings are typically 3°C (37°F) for the refrigerator and -18°C (0°F) for the freezer.

3.3 Food Storage Guidelines

- **Refrigerator Compartment:** Store fresh foods, dairy products, and beverages. Ensure food is covered to prevent drying out and odor transfer.

- **Freezer Compartment (Bottom Freezer):** Ideal for long-term storage of frozen foods. Package foods properly to prevent freezer burn.

4. Maintenance

4.1 Cleaning the Interior

Unplug the refrigerator before cleaning. Use a soft cloth with a mild detergent and warm water to clean the interior surfaces, shelves, and drawers. Rinse with clean water and dry thoroughly. Avoid abrasive cleaners or solvents.

4.2 Cleaning the Exterior

Wipe the metallic exterior with a soft, damp cloth. For stainless steel finishes, use a specialized stainless steel cleaner. Clean the door seals regularly to ensure a tight seal and efficient operation.

4.3 Defrosting

This LG Combi Refrigerator is designed with a No Frost system, which automatically prevents ice buildup in the freezer compartment. Manual defrosting is generally not required. If excessive frost accumulates due to frequent door opening or high humidity, ensure the door seals are clean and intact.

5. Troubleshooting

Before contacting service, review the following common issues and solutions:

- **Refrigerator not cooling:** Check if the power cord is securely plugged in. Ensure the temperature setting is correct. Make sure the doors are fully closed.
- **Unusual noises:** Some operating noises (e.g., refrigerant flowing, fan motor) are normal. Ensure the refrigerator is level and not touching a wall or cabinet.
- **Water on the floor:** Check if the drain pan is properly positioned. Ensure the refrigerator is level.
- **Door not closing properly:** Check for obstructions. Clean the door gaskets. Ensure the refrigerator is level.

If problems persist after attempting these solutions, please contact LG customer support.

6. Specifications

Brand	LG
Model Number	GBB61PZGCN
Type	Combi Refrigerator (Bottom Freezer)
Installation Type	Freestanding
Number of Doors	2
Color	Metallic (Inox / Stainless Steel Finish)
Height	1.86 m
Weight	140 kg
Adjustable Temperature Control	Yes
Power Source	Corded Electric

7. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official LG website for your region. You can also contact LG customer service directly for assistance with product registration, technical support, or service requests.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0951JN5G2

More documents and user manuals: **https://manuals.plus/**