Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-X3308-086-QYSY

ALLIMITY Replacement Remote Control User Manual

For MXQ, Pendoo, V88, T95X, X96, T95N, H96 PRO, TX3, R69, T95, T95Z-Plus, T95K-Pro, T95V-Pro, T95U-Pro, T95W-Pro, X88 PRO 10 TV Boxes

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your ALLIMITY Replacement Remote Control. This remote is designed to be a direct replacement for various TV Box models, offering immediate functionality without the need for complex programming.





Image: Front view of the ALLIMITY Replacement Remote Control, showcasing its button layout and ergonomic design.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two new AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery cover securely.

2. Compatibility and First Use

The ALLIMITY Replacement Remote Control is designed for immediate use with the following TV Box models without any programming:

- V88
- T95X
- X96
- T95N
- H96 PRO
- TX3
- R69
- T95
- T95Z-Plus
- T95K-Pro
- T95V-Pro
- T95U-Pro
- T95W-Pro
- X88 PRO 10

Once batteries are installed, point the remote control towards your TV Box and begin operation.

Operating Instructions

The remote control features a standard layout for intuitive navigation and control of your compatible TV Box. Below are the general functions of the buttons:





Image: Angled view of the ALLIMITY Replacement Remote Control, highlighting the central navigation pad and numeric keys.

- **Power Button ( ):** Turns the TV Box on or off.
- **Navigation Pad (Up, Down, Left, Right):** Used to navigate through menus and selections.
- **OK Button:** Confirms selections or opens items.
- **Volume Up/Down (+/–):** Adjusts the volume level.
- **Mute Button:** Mutes or unmutes audio.
- **Home Button (⌂):** Returns to the main home screen of the TV Box.
- **Back Button (↶):** Returns to the previous screen or menu.
- **Menu/Options Button (☰):** Accesses context-sensitive menus or options.
- **Numeric Keypad (0-9):** For direct input of numbers, such as channel selection or passwords.
- **APP/KD Buttons:** Dedicated buttons for specific applications or functions, depending on your TV Box model.

Operating Range

The remote control operates effectively within a maximum range of 10 meters (approximately 33 feet) from the TV Box, provided there are no significant obstructions between the remote and the device's infrared receiver.

Maintenance

Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage, which could damage the remote control. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Remote Control Not Responding

- **Check Batteries:** Ensure batteries are correctly inserted with the correct polarity and are not depleted. Replace with fresh alkaline batteries if necessary.
- **Line of Sight:** Make sure there is a clear path between the remote control and the TV Box's infrared receiver. Remove any obstructions.
- **Distance:** Ensure you are within the effective operating range (up to 10 meters).
- **Infrared Interference:** Bright sunlight or strong artificial light sources can interfere with the infrared signal. Try operating the remote in a different lighting condition.

Buttons Not Functioning Correctly

- **Battery Check:** Even if the remote powers on, low battery power can cause inconsistent button responses. Replace batteries.
- **Clean Remote:** Ensure no dirt or debris is lodged around the buttons, preventing proper contact.

Specifications

Feature	Detail
Brand	ALLIMITY
Model	QYSY-X3308-086-QYSY
Manufacturer	ALLIMITYQYSY
Compatible Devices	Television (specifically various TV Box models listed)
Special Feature	Universal Replacement

Battery Type	Alkaline (AAA, not included)
Connector Type	Infrared
Product Dimensions	4 x 12 x 0.3 cm
Item Weight	40 g
Number of Buttons	25
Maximum Range	10 Metres
Controller Type	Button Control

Warranty and Support

Specific warranty details for this ALLIMITY Replacement Remote Control are not provided in the product information. For warranty claims, technical assistance, or further inquiries, please contact ALLIMITY customer support directly through your purchase platform or the manufacturer's official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B095C7PCXL

More documents and user manuals: **https://manuals.plus/**