Nintiue FL16886

Nintiue Dimmable Floor Lamp Instruction Manual

Model: FL16886

Introduction

Thank you for choosing the Nintiue Dimmable Floor Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read it thoroughly before assembly and operation, and retain it for future reference.

Product Features

The Nintiue Dimmable Floor Lamp is designed with user convenience and modern aesthetics in mind. Key features include:

- **Fully Dimmable (0-100%) with Rotary Switch:** Easily adjust brightness to suit any mood or activity. The 4.1-foot rotary switch offers convenient control.
- **Flexible Design:** The lamp head features 270° horizontal rotation and 90° vertical rotation, allowing you to direct light precisely where needed for reading or working.
- **1000 Lumens LED Edison Bulb Included:** Comes with an E26 base, 2700K (warm white) LED bulb with a 25,000-hour lifetime, saving up to 90% energy. Compatible with other E26 bulbs under 60W.
- **Sturdy and Safe Heavy Base:** Constructed with durable metal and a weighted base (6.6 lbs) to prevent tipping, ensuring stability around children and pets.
- **Long Power Wire:** A 5.9-foot cable provides flexibility in lamp placement.



Figure 1: Stepless dimming functionality from 0% to 100% brightness.



Figure 2: Adjustable lamp head for customized lighting angles.

Package Contents

Please verify that all components are present before beginning assembly:

- Floor Lamp Base
- Lamp Pole Sections (typically 3-4 sections)
- Lamp Head with Arm
- Linen Lampshade
- LED Edison Bulb (E26 base, 2700K, 1000 Lumens)
- User Manual (this document)



Figure 3: All components included in the package.

Assembly Instructions

Assembly is quick and straightforward, requiring no special tools.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Lamp Pole:** Screw the lamp pole sections together clockwise. Ensure each section is securely tightened to prevent wobbling. Remove any protective plastic rings from the threads if present.
3. **Attach Lamp Base:** Thread the assembled lamp pole onto the lamp base and turn clockwise until firmly secured. Ensure the power cord exits through the designated groove in the base.
4. **Attach Lamp Head:** Screw the lamp head arm onto the top of the assembled pole.
5. **Install Lampshade:** Place the linen lampshade onto the lamp head. Secure it by screwing the retaining ring (usually

located on the lamp head) over the shade.

6. **Insert LED Bulb:** Carefully screw the provided LED Edison bulb into the E26 socket on the lamp head. Do not overtighten.
7. **Position Lamp:** Place the lamp in your desired location. Ensure the power cord is not pinched or obstructed.



Figure 4: The Nintiue Dimmable Floor Lamp fully assembled.

Operating Instructions

Using your Nintiue Dimmable Floor Lamp is simple:

- **Power On/Off and Dimming:** Plug the lamp into a standard 120V AC outlet. Locate the rotary switch on the lamp pole. Turn the switch clockwise to turn the lamp on and increase brightness. Turn counter-clockwise to dim the light and turn it off.
- **Adjusting Lamp Head:** To change the direction of light, gently rotate the lamp head horizontally (up to 270°) or vertically

(up to 90°) to your preferred angle.

Maintenance

To ensure the longevity and optimal performance of your lamp:

- **Cleaning:** Disconnect the power before cleaning. Wipe the lamp pole and base with a soft, dry cloth. For the lampshade, use a lint-free cloth or a soft brush to remove dust. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled down before attempting to replace it. Unscrew the old bulb and screw in a new E26 base LED bulb (maximum 60W equivalent).
- **General Care:** Avoid placing the lamp in areas with high humidity or extreme temperatures. Do not hang objects from the lamp or use it as a support.

Troubleshooting

If you encounter issues with your Nintiue Dimmable Floor Lamp, please refer to the following common solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose bulb, faulty switch.	Check if plugged in securely. Test outlet with another device. Tighten bulb. Ensure switch is turned on.
Light flickers or dims unexpectedly.	Loose bulb, incompatible bulb, power fluctuation.	Tighten bulb. Ensure bulb is dimmable and compatible (E26, max 60W). Try a different outlet.
Lamp is unstable or wobbly.	Pole sections not fully tightened, base not secure.	Ensure all pole sections are screwed together tightly. Verify the pole is firmly attached to the base.
Lampshade is crooked.	Shade retaining ring is loose.	Adjust the lampshade and tighten the retaining ring securely.

If the problem persists after trying these solutions, please contact Nintiue customer support.

Specifications

Feature	Detail
Model Number	FL16886
Dimensions (D x W x H)	13"D x 17"W x 10"H
Item Weight	8 Pounds

Feature	Detail
Finish Type	Matte
Base Material	Metal
Shade Material	Metal (Linen Shade)
Bulb Base	E26
Light Source Type	LED
Brightness	1000 Lumens
Color Temperature	2700 Kelvin (Warm White)
Wattage	6 watts
Switch Type	Rotary
Cable Length	5.9 Feet
Voltage	120 Volts
Indoor/Outdoor Usage	Indoor

Warranty and Support

Nintiue offers a **3-year quality warranty** for this product. We stand behind the quality of our products 100%.
If your lamp has any defect or stops working within 3 years of purchase, please contact our customer service team. We will assist you with troubleshooting or arrange for a replacement product.
Customer Service Contact:

For support, please refer to the contact information provided on your purchase receipt or the Nintiue official website.

© 2025 Nintiue. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question