Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jupiter Creations 17001

Robodragon R/C Toy Instruction Manual

Brand: Jupiter Creations | Model: 17001

Introduction

Thank you for purchasing the Jupiter Creations Robodragon R/C toy. This manual provides essential information for the safe and proper setup, operation, and maintenance of your new interactive dinosaur. The Robodragon features full function radio control, 8 LED lights, 5 distinct sounds, and a unique tongue that extends to pick up magnetic meal tokens. Please read these instructions carefully before use.

Safety Information

- **WARNING: CHOKING HAZARD** -- Small parts. Not for children under 3 years.
- Adult supervision is recommended during play.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Ensure battery compartments are securely closed after installation.

Setup

Package Contents:

- 1 x Robodragon R/C Toy
- 1 x Remote Control
- 4 x Magnetic Meal Tokens

Battery Installation:

1. **Robodragon:** Locate the battery compartment on the underside of the Robodragon. Open the compartment cover. Insert 6 AAA batteries (included) according to the polarity indicators (+/-). Close the cover securely.
2. **Remote Control:** Locate the battery compartment on the back of the remote control. Open the compartment cover. Insert 2 AAA batteries (not included, please check product packaging for exact battery type if different from Robodragon) according to the polarity indicators (+/-). Close the cover securely.

Initial Setup:

1. Remove the Robodragon R/C and its accessories from the packaging.
2. Ensure batteries are correctly installed in both the Robodragon and the remote control.
3. Place the 4 magnetic meal tokens on a flat surface, ready for interaction.
4. Turn on the power switch on the Robodragon (usually located on its underside or side).
5. Turn on the power switch on the remote control. The devices should automatically pair.



This image displays the Robodragon R/C toy, its remote control, and the four magnetic meal tokens. The Robodragon is white with green accents and circuit-like patterns, featuring an extending green tongue. The remote control is also white with green accents.

Operating Instructions

Remote Control Functions:

- Use the directional controls on the remote to move the Robodragon forward, backward, left, and right.
- Activate the extending magnetic tongue function to pick up the meal tokens. Position the Robodragon in front of a token and press the designated button on the remote.

- Press other buttons to activate the Robodragon's LED lights and various sound effects. The LED lights will change colors, adding to the interactive experience.

Interactive Features:

- **2.4G Remote Control:** Provides responsive and precise control over the Robodragon.
- **Extending Magnetic Tongue:** The Robodragon's tongue can extend to retrieve the magnetic meal tokens, simulating feeding.
- **LED Lights:** The Robodragon features multiple LED lights that illuminate and change colors during operation, enhancing visual appeal.
- **Sounds:** Enjoy a variety of dinosaur-like sounds and interactive audio cues from the Robodragon.

Product Demonstration Video:

Your browser does not support the video tag.

An official product video demonstrating the Jupiter Creations Robodragon R/C toy in action. The video shows the Robodragon moving, its LED lights changing colors, and its magnetic tongue extending to pick up meal tokens. It also highlights the remote control functionality and interaction with children.

Maintenance

- **Cleaning:** Wipe the Robodragon and remote control with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the toy and its accessories in a cool, dry place, away from direct sunlight and moisture. Remove batteries if the toy will not be used for an extended period to prevent leakage.

Troubleshooting

- **Toy not responding:** Ensure both the Robodragon and remote control are powered on. Check that batteries are correctly installed and not depleted. Replace batteries if necessary.
- **Tongue not extending/retracting:** Check for any obstructions around the tongue mechanism. Ensure batteries have sufficient power.
- **Interference:** If experiencing erratic behavior, move to an area with less electronic interference.

Specifications

Feature	Detail
Brand	Jupiter Creations
Model Name	Robodragon R/C
Model Number	17001
UPC	852675002700
Item Dimensions L x W x H	7.5"L x 9"W x 5"H
Item Weight	1.9 Pounds
Material Type	Plastic

Power Source	Battery Powered
Batteries Required	Yes (6 AAA for Robodragon, 2 AAA for Remote - check packaging)
Age Range Description	Kid (Manufacturer Minimum Age: 36 months)
Additional Features	Interactive Audio, Light, Sound

Warranty Information

This product is covered by a Manufacturer's Warranty. For specific details regarding the warranty period and coverage, please refer to the packaging or contact Jupiter Creations customer support directly.

Customer Support

For further assistance, questions, or to report any issues with your Robodragon R/C toy, please contact Jupiter Creations customer support. Contact information can typically be found on the product packaging or the official Jupiter Creations website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B095PWB58Z

More documents and user manuals: **https://manuals.plus/**