Easyfone Prime-A6

Easyfone Prime-A6 4G Feature Mobile Phone User Manual

Model: Prime-A6

1. Introduction

The Easyfone Prime-A6 is a 4G feature mobile phone designed for ease of use, featuring large buttons, clear sound, and a simplified operating system. It is ideal for individuals seeking a reliable communication device without complex smartphone functionalities. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Prime-A6 phone.

2. Package Contents

Please verify that all items listed below are included in your package:

- Easyfone Prime-A6 Mobile Phone
- Rechargeable Battery
- Charging Dock
- USB Cable
- User Manual (this document)



Figure 2.1: Contents of the Easyfone Prime-A6 package.

3. Setup

3.1. Installing the Battery and SIM Card

Before first use, install the battery and your SIM card(s). The phone supports one standard SIM card and one MicroSD card for expanded storage (not included).

1. Gently remove the back cover of the phone by prying it from the notch at the bottom.
2. Insert your SIM card(s) into the designated slot(s) with the gold contacts facing down, ensuring proper orientation as indicated on the phone.
3. If using, insert a MicroSD card into its slot.
4. Insert the battery into the battery compartment, aligning the gold contacts on the battery with those in the phone.
5. Replace the back cover, pressing firmly until it clicks into place.



Figure 3.1: Battery and SIM card installation area.

3.2. Initial Charging

For optimal battery performance, fully charge the phone before its first use.

1. Connect the USB cable to the charging dock and then to a power adapter (not included) or a USB port.
2. Place the Easyfone Prime-A6 phone into the charging dock, ensuring it sits securely. The phone will begin charging automatically.
3. Alternatively, you can connect the USB cable directly to the phone's charging port.
4. The charging indicator on the screen will show the charging status. A full charge typically takes approximately 2.2 hours.



Figure 3.2: Phone in charging dock.

4. Operating Instructions

4.1. Power On/Off

- **To Power On:** Press and hold the red End Call/Power button (✆) until the screen lights up.

- **To Power Off:** Press and hold the red End Call/Power button (✆) until a power off option appears on the screen, then confirm.

4.2. Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the green Call button (✆).
- **Answering a Call:** When the phone rings, press the green Call button (✆).
- **Ending a Call:** Press the red End Call button (✆).



Figure 4.1: Using the Easyfone Prime-A6 for a call.

4.3. Speed Dial

The Prime-A6 supports 8 speed dial buttons (keys #2 to #9) for quick access to frequently called contacts.

1. **Setting Up Speed Dial:** Navigate to the phone's settings or contacts menu to assign a contact to a speed dial key. Refer to the on-screen instructions for specific steps.
2. **Using Speed Dial:** Press and hold the assigned number key (2-9) to automatically dial the corresponding contact.



Figure 4.2: Speed Dial functionality.

4.4. SOS Emergency Button

The dedicated SOS button provides a quick way to contact pre-set emergency numbers.

1. **Setting Up SOS Contacts:** Access the SOS settings in the phone's menu to add up to five emergency contacts.
2. **Using the SOS Function:** Press and hold the SOS button (located on the back of the phone) for a few seconds. The phone will automatically call and send an emergency SMS to the pre-set contacts in sequence until one answers.

4.5. Other Features

The Easyfone Prime-A6 includes several useful features:

- **FM Radio:** Listen to your favorite radio stations.
- **Alarm Clock:** Set multiple alarms for reminders.
- **Audio Player:** Play audio files stored on a MicroSD card.
- **Bluetooth:** Connect to Bluetooth headsets or other devices.
- **Flashlight:** A built-in torch for convenience.
- **Calendar:** Keep track of dates and events.
- **Calculator:** Perform basic arithmetic.
- **Voice Recorder:** Record voice memos.



Figure 4.3: Overview of phone features.

5. Maintenance

To ensure the longevity and optimal performance of your Easyfone Prime-A6, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid using liquid cleaners or abrasive materials.
- **Battery Care:** Avoid extreme temperatures. Do not expose the battery to direct sunlight or very cold conditions. If the phone will not be used for an extended period, charge the battery to about 50% before storing.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and moisture.
- **Avoid Drops:** While durable, repeated drops can damage internal components. Handle the phone with care.

6. Troubleshooting

If you encounter issues with your Easyfone Prime-A6, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Phone does not power on	Battery is depleted or not installed correctly.	Charge the battery. Ensure the battery is correctly inserted.
No network signal	SIM card not inserted, out of network coverage, or SIM issue.	Check SIM card insertion. Move to an area with better coverage. Contact your network provider.
Cannot hear caller / Low volume	Volume setting is low, or speaker is obstructed.	Increase call volume using the side buttons. Ensure speaker is not covered.
Phone freezes or is unresponsive	Temporary software glitch.	Remove and reinsert the battery to force a restart.

If the problem persists after trying these solutions, please contact Easyfone customer support.

7. Specifications

Key technical specifications for the Easyfone Prime-A6:

Feature	Specification
Model	Prime-A6
Dimensions	11.5 x 5.2 x 1.4 cm
Weight	82 g
Display Size	1.8 Inches
Display Resolution	320 x 240
Operating System	Nucleus OS
Internal Memory	64 MB Flash, 256 MB Digital Storage
Expandable Memory	MicroSD (up to 32GB, not included)
Battery Capacity	1050 mAh Lithium-Ion
Battery Average Life	Up to 8 days standby
Charging Time	Approx. 2.2 hours
Cellular Technology	4G, 2G
Connectivity	Bluetooth, USB

8. Warranty and Support

For warranty information, please refer to the warranty card included with your product or contact Easyfone customer support directly. Easyfone is committed to providing quality products and support.

Customer Support:

For technical assistance, troubleshooting, or general inquiries, please contact Easyfone support:

- **Email:** support@easyfone.com.cn
- **Manufacturer:** Easyfone
- **Place of Business:** Easyfone Canada

© 2025 Easyfone. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question