Dickie Toys 203837016

Dickie Toys Wild Park Ranger Set 203837016 Instruction Manual

Model: 203837016

1. Introduction

This manual provides essential information for the safe and proper use of your Dickie Toys Wild Park Ranger Set, model 203837016. Please read these instructions carefully before use and retain them for future reference.



Figure 1.1: The Dickie Toys Wild Park Ranger Set, model 203837016, as packaged.

2. Safety Information

WARNING: This product contains small parts. It is not suitable for children under 36 months due to choking hazards. Always ensure adult supervision during play.

- Keep all packaging materials away from children to prevent suffocation.
- Do not modify the toy.
- Ensure batteries are inserted correctly according to polarity markings.
- Remove exhausted batteries promptly.
- Do not mix old and new batteries, or different types of batteries.

3. Components List

The Dickie Toys Wild Park Ranger Set includes the following components:

- 1x Ford Raptor Ranger Jeep (camouflage design, free-wheeling, opening doors, rubber tires, roof-mounted headlights)
- 1x Ranger Figure (movable)
- 1x Elephant Figure

- 2x Lion Figures (one adult, one cub)
- 1x Monkey Figure
- 1x Net Cannon (removable, with net)
- 1x Manual Winch (front-mounted)
- 1x Foldable Loading Ramp (rear)



Figure 3.1: All included components: the Ford Raptor jeep, ranger figure, elephant, two lions, and a monkey.

4. Setup

The Dickie Toys Wild Park Ranger Set comes largely pre-assembled. Follow these steps for initial setup:

1. **Unpackaging:** Carefully remove all components from the packaging. Dispose of packaging materials responsibly.
2. **Battery Installation:** The jeep requires batteries for light and sound functions. Locate the battery compartment, typically on the underside of the vehicle. Insert the required batteries (included) ensuring correct polarity. Secure the battery compartment cover.
3. **Net Cannon Attachment:** The net cannon can be placed on the designated mount on the jeep's roof. Ensure it is securely seated.
4. **Figure Placement:** The ranger figure can be placed inside the jeep's cabin or on the cargo bed. Animal figures can be arranged on the cargo bed or around the vehicle for play.



Figure 4.1: The Ranger Jeep with its roof-mounted headlights illuminated, indicating proper battery installation.

5. Operating Instructions

5.1 Ranger Jeep Operation

- **Free-Wheeling:** The jeep features free-wheeling action, allowing it to be pushed manually across various surfaces.
- **Opening Doors:** The jeep's doors can be opened to place the ranger figure inside the cabin.
- **Lights and Sounds:** Press the designated button (usually on the roof or hood) to activate the roof-mounted headlights and safari-themed sounds.

5.2 Net Cannon

The net cannon is designed to simulate animal capture for rescue operations.

1. Load the net into the cannon mechanism.
2. Aim the cannon by rotating it on its mount.
3. Press the trigger to launch the net.



Figure 5.1: The net cannon in action, launching its net.

5.3 Manual Winch

The front-mounted manual winch can be used for simulated towing or pulling operations.

1. Unwind the winch rope by rotating the crank.
2. Attach the hook to the desired object.
3. Rotate the crank in the opposite direction to retract the rope and pull the object.



Figure 5.2: Demonstrating the manual winch mechanism on the front of the jeep.

5.4 Foldable Loading Ramp

The rear loading ramp allows for easy loading and unloading of animal figures or other accessories onto the cargo bed.

- Fold down the ramp from the rear of the jeep.
- Place figures or accessories onto the ramp and slide them onto the cargo bed.
- Fold the ramp back up when not in use.



Figure 5.3: The jeep with its doors open and the rear loading ramp lowered.



Figure 5.4: Animal figures being loaded onto the jeep's cargo bed via the ramp.

---

6. Maintenance

To ensure the longevity and proper functioning of your Dickie Toys Wild Park Ranger Set, follow these maintenance guidelines:

- **Cleaning:** Wipe the toy with a damp cloth to remove dust and dirt. Do not immerse the toy in water. Avoid using harsh chemicals or abrasive cleaners.

- **Storage:** Store the toy in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.
- **Inspection:** Periodically inspect all parts for damage or wear. Discontinue use if any part is broken or damaged.

7. Troubleshooting

- **Lights/Sounds Not Working:** Check battery installation and replace with fresh batteries if necessary. Ensure the battery compartment is securely closed.
- **Net Cannon Not Firing Effectively:** Ensure the net is correctly loaded and the firing mechanism is clear of obstructions. The net cannon is designed for light play and may not have strong propulsion.
- **Winch Rope Not Retracting:** Check for tangles or obstructions in the winch mechanism. Ensure the crank is turned smoothly.
- **Wheels Detaching:** If wheels become loose or detach, inspect the axle connection. If the damage is significant, the toy may require replacement.

8. Specifications

Brand	Dickie Toys
Model Number	203837016
Main Material	Plastic
Number of Pieces	5 (Jeep, Ranger, Elephant, 2 Lions, Monkey)
Recommended Age	36 months - 8 years
Batteries Required	Yes
Batteries Included	Yes
Item Dimensions (L x W x H)	25 x 12 cm (approximately)
Item Weight	590 Grams

9. Warranty and Support

Dickie Toys products are designed for quality and durability. For any questions regarding product operation, missing parts, or potential defects, please contact the retailer or manufacturer's customer support. Please retain your proof of purchase for any warranty claims.