Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gelielim LC-10W-RM

Gelielim CD Player Alarm Clock Radio User Manual

Model: LC-10W-RM

1. Introduction

Thank you for purchasing the Gelielim CD Player Alarm Clock Radio. This versatile device combines multiple functions including a CD player, alarm clock, Bluetooth speaker, FM radio, and a 10W fast wireless charging station. This manual provides detailed instructions to help you set up and operate your new device.

Please read this manual thoroughly before use and keep it for future reference.



Image: The Gelielim CD Player Alarm Clock Radio, a black rectangular unit with a large LED display showing time and radio frequency, a top-loading CD player, and various control buttons. A remote control is shown next to it.

2. What's in the Box

Upon unpacking, please ensure all items listed below are present and in good condition:

- Gelielim CD Player Alarm Clock Combo (Model: LC-10W-RM)
- Remote Control
- AC Power Cord (UL certified for 100V-240V)
- User Manual (this document)

Note: 2 x AAA dry batteries for time running memory backup are NOT INCLUDED.

3. Setup

3.1 Power Connection

1. Connect the supplied AC power cord to the DC IN port on the back of the unit.
2. Plug the other end of the AC power cord into a standard wall outlet (100V-240V).
3. The LED display will light up, indicating the unit is powered on and ready for use.

3.2 Installing Remote Control Batteries

Insert 2 x AAA dry batteries (not included) into the remote control, observing the correct polarity (+/-) as indicated inside the battery compartment.

4. Operating Instructions

4.1 Setting Time and Date

The unit can auto-sync time via Bluetooth when connected to a device. To manually set the time:

1. Press and hold the **SET** button on the unit or remote until the hour digits flash.
2. Use the **|<<** or **>>|** buttons to adjust the hour.
3. Press **SET** again to confirm the hour, and the minute digits will flash.
4. Use the **|<<** or **>>|** buttons to adjust the minutes.
5. Press **SET** again to confirm the minutes.
6. To switch between 12-hour and 24-hour format, press and hold the **SET** button until "12H" or "24H" appears, then use **|<<** or **>>|** to select.

Your browser does not support the video tag.

Video: A user demonstrates how to set the alarm and time on the Gelielim CD Player Alarm Clock Radio. The video shows the display changing as buttons are pressed to adjust hours, minutes, and alarm settings.

4.2 Alarm Settings

The unit features two independent alarms (Alarm 1 and Alarm 2).

1. Press and hold **ALARM 1** or **ALARM 2** button until the alarm time flashes.
2. Use **|<<** or **>>|** buttons to set the desired alarm hour, then press the respective **ALARM** button to confirm.
3. Repeat for minutes.
4. After setting the time, use **|<<** or **>>|** to select the alarm source (Dee Dee, Radio, CD, USB, or Bluetooth). Press the **ALARM** button to confirm.
5. Finally, set the alarm volume using **VOL+** or **VOL-**. Press the **ALARM** button to save.
6. To activate/deactivate an alarm, short press the corresponding **ALARM** button. An alarm icon will appear/disappear on the display.

4.3 Snooze Function

When the alarm sounds, press the **SNOOZE/SLEEP** button to temporarily silence it for 9 minutes. The alarm will sound again after the snooze period.

4.4 Display Dimmer

Press the **DIMMER** button repeatedly to cycle through 4 brightness levels for the LED display, including turning it completely off.



Image: The alarm clock on a bedside table with a phone wirelessly charging on top, next to a sleeping person. Icons below highlight features such as auto time setting, dual alarm, multiple alarm sounds, adjustable brightness, wireless charging, snooze, time format switch, and battery backup.

4.5 CD Player Operation

This unit supports CD, CD-R, CD-RW, MP3, and WMA formats.

1. Press the **MODE** button to select CD mode. "CD" will appear on the display.
2. Press the **OPEN** button on the top right to open the CD compartment.
3. Place a CD onto the spindle with the label side facing up.

4. Close the CD compartment. The unit will begin reading the disc.
5. Use **PLAY/PAUSE** to play or pause playback.
6. Use **|<<** or **>>|** to skip tracks. Press and hold to fast forward/rewind.
7. Adjust volume using **VOL+** or **VOL-**.



Image: A hand is shown holding the remote control, pointing towards the top-loading CD player. The CD compartment is open, revealing a disc being inserted.

4.6 Bluetooth Operation

1. Press the **MODE** button to select Bluetooth mode. "BT" will appear on the display.
2. The unit will automatically enter pairing mode.
3. On your Bluetooth-enabled device, search for "LC-10W" and select it to pair.
4. Once paired, you can stream audio wirelessly from your device.
5. Use the **PLAY/PAUSE**, **|<<**, and **>>|** buttons on the unit or remote to control playback.



Image: A smartphone displaying a music player interface is held next to the Gelielim unit, indicating a Bluetooth connection. Icons for Bluetooth, AUX, and USB drive are shown above.

4.7 FM Radio Operation

1. Press the **MODE** button to select FM Radio mode. The frequency will appear on the display.
2. Extend the telescopic antenna on the back of the unit for optimal reception.
3. To auto-scan and save stations, press and hold the **PLAY/PAUSE** button. The unit will scan and store available FM stations.
4. To manually tune, short press **|<<** or **>>|** to adjust the frequency step by step.
5. To jump to the next strong station, press and hold **|<<** or **>>|**.



Image: A person is comfortably seated on a couch, reading a book, with the Gelielim unit on a table nearby. The unit's display shows the FM frequency, and an antenna is extended. Icons for sleep timer and FM frequency range are displayed.

4.8 AUX/USB Playback

The unit features AUX IN and USB ports for external audio sources.

1. Press the **MODE** button to select AUX or USB mode.
2. For AUX: Connect your audio device to the AUX IN port using a 3.5mm audio cable (not included).
3. For USB: Insert a USB flash drive containing MP3/WMA files into the USB port.
4. Control playback and volume from your connected device or using the unit's controls.



Image: The Gelielim unit is shown with icons representing its various playback modes: CD Player, Bluetooth, FM Radio, USB playback, AUX IN, and Headphone playback.

4.9 Wireless Charging

The unit features a 10W fast wireless charging pad compatible with Qi-enabled phones.

1. Ensure the unit is powered on.
2. Place your Qi-enabled smartphone on the charging pad located on top of the unit.
3. The charging indicator light will illuminate, and your phone should show it is charging.
4. Adjust the phone's position if charging does not start immediately.



Image: A smartphone is placed on the top surface of the Gelielim unit, displaying a charging icon. Text indicates 10W fast charging for Samsung Galaxy S7 to S23 series and iPhone 12 to 14 series, and 7.5W fast charging for iPhone 8 to 11 series.

5. Specifications

Feature	Description
Model Number	LC-10W-RM
Product Dimensions	8.86 x 6.7 x 3.15 inches
Item Weight	2.9 pounds
Connectivity Technology	Bluetooth, Auxiliary, USB

Color	Black
Speaker Type	Stereo
Power Input	100V-240V (UL Certified AC Cord)
Battery Backup	2 x AAA dry batteries (for time memory, not included)
Wireless Charging Output	10W Fast Wireless Charging (Qi-compatible)

6. Troubleshooting

Problem	Possible Cause / Solution
Unit does not power on.	Ensure the AC power cord is securely connected to both the unit and a working wall outlet. Try a different outlet.
CD player not working / Disc not reading.	Ensure the CD is clean and free of scratches. Check if the CD is inserted correctly with the label side facing up. Verify the unit is in CD mode. Some discs (e.g., heavily scratched or non-standard formats) may not be compatible.
Bluetooth pairing issues.	Ensure the unit is in Bluetooth mode. Make sure Bluetooth is enabled on your device and it's within range (approx. 30 feet). Forget "LC-10W" from your device's Bluetooth list and try pairing again. Restart both the unit and your Bluetooth device.
Alarm does not sound.	Ensure the alarm is activated (alarm icon visible on display). Check the alarm time and ensure it is set correctly (AM/PM if applicable). Verify the alarm volume is not set to 0. If using CD/USB/Bluetooth as alarm source, ensure media is available and playable.
Wireless charging not working.	Ensure your phone is Qi-enabled. Remove any thick phone cases that might interfere with charging. Ensure the phone is centered on the charging pad. Check if the unit is powered on.

Your browser does not support the video tag.

Video: A quick demonstration of the Gelielim CD Player Alarm Clock, highlighting its features and basic operation. This video is a shorter overview.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. Do not use liquid cleaners or aerosol sprays.
- **Disc Care:** Handle CDs by their edges. Keep them clean and free of dust or scratches to ensure optimal playback.
- **Storage:** If storing the unit for an extended period, unplug it from the power outlet and remove any batteries from the remote control. Store in a cool, dry place.

8. Warranty and Support

Gelielim products come with a standard manufacturer's warranty. For detailed warranty information, product support, or technical assistance, please refer to the contact information provided on the product packaging or visit the official Gelielim website.

You can also find additional support and FAQs on the Gelielim store page on Amazon:Gelielim Store.

© 2024 Gelielim. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0963X5KR3

More documents and user manuals: **https://manuals.plus/**