Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lasika W-H9003

Lasika W-H9003 Sport Watch User Manual

1. Introduction

Thank you for choosing the Lasika W-H9003 Sport Watch. This manual provides detailed instructions for setting up, operating, and maintaining your new digital sport watch. Please read this manual carefully to ensure proper use and to fully utilize all features of your watch.

2. Product Overview

The Lasika W-H9003 is a digital sport watch designed for men, featuring a clear display and durable construction. Familiarize yourself with the watch components before use.



Figure 1: Front view of the Lasika W-H9003 Sport Watch, showing the digital display and typical button layout.

2.1 Key Features

- Digital Time Display
- Round Watch Shape
- Durable Rubber Band
- 30 millimeters Dial Case Diameter
- Sport Watch Functionality

2.2 Watch Components

While specific button labels may vary, most digital sport watches feature the following common controls:

- **MODE Button:** Used to cycle through different watch modes (Time, Stopwatch, Alarm).
- **LIGHT Button:** Activates the backlight for visibility in low-light conditions.
- **START/STOP Button:** Used to start and stop functions like the stopwatch, or to adjust settings.
- **RESET/ADJUST Button:** Used to reset functions or confirm settings during adjustment.

3. Setup

3.1 Setting Time and Date

1. From the normal time display, press the **MODE** button repeatedly until the time setting mode is activated. Typically, the seconds digits will begin to flash.
2. Press the **RESET/ADJUST** button to select the digit you wish to adjust (e.g., hours, minutes, month, date, day). The selected digit will flash.
3. Use the **START/STOP** button to increase the value of the flashing digit. Hold the button to advance rapidly.
4. Repeat steps 2 and 3 until all desired time and date settings are correct.
5. Press the **MODE** button to exit the setting mode and return to the normal time display.

4. Operating Modes

4.1 Time Mode

This is the default display mode, showing the current time (hours, minutes, seconds), day of the week, and date.

4.2 Stopwatch Mode

1. From Time Mode, press the **MODE** button once to enter Stopwatch Mode. The display will show '00:00:00'.
2. Press the **START/STOP** button to begin timing.
3. Press the **START/STOP** button again to pause timing.
4. Press the **RESET/ADJUST** button to reset the stopwatch to '00:00:00'.
5. Press the **MODE** button to return to Time Mode.

4.3 Alarm Mode

1. From Time Mode, press the **MODE** button twice to enter Alarm Mode.
2. Press the **RESET/ADJUST** button to select the hour or minute digit to set. The selected digit will flash.
3. Use the **START/STOP** button to adjust the flashing digit to the desired alarm time.
4. Press the **MODE** button to confirm the alarm setting and exit.
5. To activate/deactivate the alarm, typically press the **START/STOP** button while in Alarm Mode. An alarm icon will appear/disappear on the display.

4.4 Backlight Function

Press the **LIGHT** button to illuminate the watch display for a few seconds, allowing visibility in dark environments.

5. Maintenance

5.1 Cleaning

Wipe the watch case and band with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the watch's finish or rubber material.

5.2 Water Resistance

The Lasika W-H9003 is designed as a sport watch, implying a degree of water resistance. However, specific water resistance ratings are not provided. It is generally recommended to avoid submerging the watch in water, and to refrain from pressing buttons while the watch is wet to prevent water ingress.

5.3 Battery Replacement

When the display becomes dim or functions become erratic, the battery may need replacement. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance. Opening the watch yourself may void any implied warranty.

6. Troubleshooting

6.1 Display is Blank

- The battery may be depleted. Consider replacing the battery.
- Ensure the watch has not been exposed to extreme temperatures.

6.2 Buttons Not Responding

- Try pressing the buttons firmly.
- If the watch has been exposed to water, ensure it is completely dry.
- A low battery can sometimes affect button responsiveness.

6.3 Time is Inaccurate

- Reset the time according to the instructions in Section 3.1.
- A weak battery can cause timekeeping inaccuracies.

7. Specifications

Item Model Number	W-H9003
Manufacturer	Lasika
Material	Rubber (Band)
Dial Case Diameter Size	30 millimeters
Display Type	Digital
Package Dimensions	8.5 x 7.8 x 7.3 cm
Item Weight	90 g

8. Warranty and Support

For information regarding warranty coverage and customer support, please refer to the documentation provided at

the point of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.

© 2023 Lasika. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0968YRYV6

More documents and user manuals: **https://manuals.plus/**