Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lasika W-H9003

Lasika W-H9003 Women's Digital Watch User Manual

Model: W-H9003

1. Product Overview

The Lasika W-H9003 is a stylish and functional digital watch designed for women. It features a clear digital display, a durable rubber strap, and a reliable quartz movement. This manual provides essential information for setting up, operating, and maintaining your watch.



Figure 1: A close-up view of the Lasika W-H9003 women's digital watch, featuring a round black dial and a black rubber strap.

Key Features:

- **Brand:** Lasika
- **Watch Shape:** Round
- **Dial Diameter Size:** 30 mm
- **Strap Material:** Rubber
- **Display Type:** Digital

- **Target Group:** Women

2. Setup

2.1 Initial Setup

1. **Unpacking:** Carefully remove the watch from its packaging. Inspect for any visible damage.
2. **Time Setting:**
    - Locate the mode button (usually on the bottom left) and the adjust button (usually on the bottom right).
    - Press the mode button repeatedly until the time setting mode is activated (e.g., seconds flashing).
    - Use the adjust button to change the flashing value (seconds, minutes, hours, date).
    - Press the mode button again to cycle through the settings.
    - Once all settings are correct, press the mode button to exit the setting mode.

3. Operating Instructions

3.1 Button Functions

- **Mode Button:** Cycles through different display modes (Time, Date, Alarm, Stopwatch). Also used to confirm settings during adjustment.
- **Adjust Button:** Used to change values when in setting mode. In normal time display, it may activate the backlight or show the date.

3.2 Display Modes

Your watch typically features the following display modes, accessible by pressing the Mode button:

- **Time Display:** Shows current hour, minute, and second.
- **Date Display:** Shows month, day, and day of the week.
- **Alarm Mode:** Allows setting and activating an alarm.
- **Stopwatch Mode:** For measuring elapsed time.

4. Maintenance

- **Cleaning:** Wipe the watch with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly. Avoid harsh chemicals.
- **Water Resistance:** This watch is generally splash-resistant. Avoid submerging it in water or exposing it to high-pressure water jets.
- **Battery Replacement:** When the display dims or stops functioning, the battery may need replacement. This should ideally be done by a qualified watch technician to ensure proper sealing and water resistance.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery.
Time is incorrect.	Time needs adjustment.	Refer to Section 2.1 for time setting instructions.
Buttons are unresponsive.	Watch may be in a locked mode or battery is very low.	Try pressing all buttons to reset. If issue persists, replace battery.

6. Specifications

Feature	Detail
Brand Name	Lasika
Model Name	W-H9003
Item Model Number	W-H9003
Target Group	Women
Display Type	Digital
Movement	Quartz
Case Material Type	Resin
Case Diameter	30 mm
Watch Glass Material Type	Crystal
Band Material Type	Rubber
Band Color	Black
Dial Color	Black
Clasp Type	Buckle
Power Source	Battery Powered
Special Features	Full-featured
Package Dimensions	8 x 7.9 x 7.3 cm; 100 grams

7. Warranty Information

Your Lasika W-H9003 digital watch comes with a manufacturer's warranty. Please refer to the included warranty card for specific terms, conditions, and duration of coverage. Keep your proof of purchase for any warranty claims.

8. Support

For further assistance or inquiries regarding your Lasika W-H9003 watch, please contact the retailer where you purchased the product or visit the official Lasika website for customer support information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0968ZP48S

More documents and user manuals: **https://manuals.plus/**