Lasika 2724984272632.0

Lasika Digital Sports Watch User Manual

Model: 2724984272632.0

1. Introduction

Thank you for purchasing the Lasika Digital Sports Watch. This manual provides detailed instructions for setting up, operating, and maintaining your watch. Please read this manual carefully to ensure proper use and to maximize the lifespan of your product.

This watch features a digital display for time, date, and day, along with an alarm, stopwatch, and backlight function. It is designed for daily use and sports activities, but please note it is **not water resistant**.

2. Product Overview

Familiarize yourself with the watch's buttons and display.



Image 1: Front view of the Lasika Digital Sports Watch. The watch features a black case and strap with blue accents around the digital display. Buttons are labeled "LIGHT", "MODE", "START", and "RESET". The display shows time, day, and date.

- **LIGHT Button:** Activates the backlight.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START Button:** Used to start/stop stopwatch, adjust settings.
- **RESET Button:** Used to reset stopwatch, adjust settings.

3. Setup Instructions

3.1 Setting Time and Date

1. From the normal time display, press the **MODE** button three times to enter time setting mode. The seconds will flash.
2. Press the **RESET** button to select the hour, minute, month, date, or day of the week. The selected item will flash.
3. Press the **START** button to adjust the flashing number.
4. Once all settings are correct, press the **MODE** button to return to normal time display.

3.2 Setting the Alarm

1. From the normal time display, press the **MODE** button twice to enter alarm setting mode. The hour will flash.
2. Press the **RESET** button to select the hour or minute.
3. Press the **START** button to adjust the flashing number.
4. Press the **MODE** button to confirm and exit alarm setting mode.
5. To turn the alarm ON/OFF, press the **START** button while in alarm mode. An alarm icon will appear/disappear on the display.

4. Operating Instructions

4.1 Using the Stopwatch

1. From the normal time display, press the **MODE** button once to enter stopwatch mode.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.
5. Press the **MODE** button to return to normal time display.

4.2 Activating the Backlight

Press the **LIGHT** button at any time to illuminate the display for a few seconds.

5. Maintenance

- **Cleaning:** Wipe the watch with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Water Exposure:** This watch is **not water resistant**. Avoid contact with water, including rain, showers, swimming, or submersion. Exposure to water can damage the internal components.
- **Temperature:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect accuracy and battery life.
- **Impact:** Protect the watch from strong impacts or drops.
- **Battery Replacement:** When the display becomes dim or functions irregularly, the battery may need replacement. This should be done by a qualified technician to avoid damaging the watch.



Image 2: Back view of the Lasika Digital Sports Watch, showing the stainless steel case back. This area typically houses the battery compartment.

6. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery.
Time is incorrect.	Time not set correctly or accidental button press.	Refer to Section 3.1 "Setting Time and Date" to reset the time.
Alarm does not sound.	Alarm is turned off or set incorrectly.	Refer to Section 3.2 "Setting the Alarm" to ensure the alarm is set and activated.
Watch stops working after contact with water.	Water damage (watch is not water resistant).	Discontinue use. Water damage is typically irreversible.

7. Specifications

- **Brand:** Lasika
- **Model:** 2724984272632.0
- **Display Type:** Digital

- **Movement:** Quartz
- **Power Source:** Battery operated
- **Case Material:** Stainless Steel
- **Band Material:** Rubber and Synthetic Leather
- **Clasp Type:** Buckle (Hidden push-button clasp)
- **Case Diameter:** 40 mm
- **Band Width:** 4 cm
- **Band Length:** 15 cm
- **Water Resistance Level:** Not Water Resistant
- **Features:** Time, Date, Day, Alarm, Stopwatch, Backlight

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.
Please note that damage caused by improper use, accidents, or unauthorized repairs may void your warranty. As specified, this watch is **not water resistant**; water damage is not covered under warranty.

© 2023 Lasika. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question