Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lasika W-H9014

Lasika W-H9014 Women's Digital Watch User Manual

Model: W-H9014

1. Introduction

Thank you for choosing the Lasika W-H9014 Women's Digital Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Please read these instructions carefully before using the watch to ensure optimal performance and longevity.

2. Product Overview

The Lasika W-H9014 is a stylish and functional digital watch designed for women. It features a round dial with a clear digital display, a comfortable rubber strap, and a buckle clasp. Its design makes it suitable for formal occasions and everyday wear.



Figure 1: Front view of the Lasika W-H9014 Digital Watch.

Key Features:

- **Brand:** Lasika
- **Watch Shape:** Round
- **Dial Diameter:** 30 mm
- **Strap Material:** Rubber
- **Display Type:** Digital
- **Target Group:** Women

- **Movement Type:** Quartz
- **Power Source:** Battery Powered

3. Setup

3.1 Battery Installation

Your Lasika W-H9014 watch is battery-powered. If the display is blank or dim, the battery may need to be installed or replaced. This watch uses a standard watch battery (type not specified, typically a button cell). It is recommended to have battery replacement performed by a qualified watch technician to avoid damaging the watch's internal components or compromising its water resistance (if applicable).

3.2 Initial Time Setting

Upon first use or after battery replacement, you will need to set the time and date. Digital watches typically have 2-4 buttons for operation. Common button functions include:

- **MODE (M):** Cycles through display modes (Time, Date, Alarm, Stopwatch).
- **SET/ADJUST (S/A):** Enters setting mode and confirms selections.
- **LIGHT (L):** Activates backlight.
- **START/STOP (ST):** Used for stopwatch functions or incrementing values in setting mode.

To set the time:

1. Press the **MODE** button repeatedly until the time display is shown.
2. Press and hold the **SET/ADJUST** button until the seconds begin to flash. This indicates you are in setting mode.
3. Press the **MODE** button to cycle through the settings: seconds, hours, minutes, month, date, year.
4. Use the **START/STOP** button to increase the flashing value.
5. Once all settings are correct, press the **SET/ADJUST** button again to exit setting mode.

4. Operating Instructions

4.1 Display Modes

Press the **MODE** button to cycle through the available display modes:

- **Time Display:** Shows current hour, minute, and second.
- **Date Display:** Shows month, day, and year.
- **Alarm Mode:** Allows setting and activating an alarm.
- **Stopwatch Mode:** For timing events.

4.2 Using the Alarm

1. Press the **MODE** button until you reach the Alarm mode.
2. Press and hold the **SET/ADJUST** button until the alarm hour flashes.
3. Use the **START/STOP** button to set the desired hour.
4. Press **MODE** to move to the minutes, then use **START/STOP** to set the minutes.
5. Press **SET/ADJUST** to confirm and exit.
6. To turn the alarm ON/OFF, press the **START/STOP** button while in Alarm mode (not in setting mode). An alarm icon will appear/disappear.

4.3 Using the Stopwatch

1. Press the **MODE** button until you reach the Stopwatch mode.

2. Press the **START/STOP** button to start timing.
3. Press **START/STOP** again to pause/resume.
4. To reset the stopwatch, press the **SET/ADJUST** button while the stopwatch is paused.

4.4 Backlight

Press the **LIGHT** button (if available) to illuminate the display in low-light conditions. The backlight will typically stay on for a few seconds.

5. Maintenance

5.1 Cleaning

To clean your watch, wipe it gently with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish or components.

5.2 Water Resistance

The water resistance rating for this specific model is not provided. To ensure the longevity of your watch, it is advisable to avoid exposing it to water, moisture, or extreme humidity. Do not wear it while swimming, showering, or engaging in water sports unless explicitly stated otherwise by the manufacturer.

5.3 Storage

When not in use, store your watch in a cool, dry place away from direct sunlight and extreme temperatures. Keeping it in its original packaging or a watch box can help protect it from dust and scratches.

6. Troubleshooting

If you encounter issues with your Lasika W-H9014 watch, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery.	Replace the battery.
Time is incorrect.	Time not set correctly or reset after battery change.	Refer to Section 3.2 to reset the time.
Buttons are unresponsive.	Watch may be in a locked mode or internal issue.	Try pressing all buttons firmly. If still unresponsive, a battery reset (removing and reinserting) might help, but professional service is recommended.
Alarm does not sound.	Alarm is not activated or set incorrectly.	Ensure the alarm is set and the alarm icon is visible on the display. Refer to Section 4.2.

If the problem persists after attempting these solutions, please contact customer support.

7. Specifications

Detailed technical specifications for the Lasika W-H9014 Digital Watch:

- **Brand Name:** Lasika
- **Model Number:** W-H9014
- **Item Model Number:** W-H9014
- **Part Number:** W-H9014
- **Department:** Women

- **Age Range Description:** Adult
- **Item Shape:** Round
- **Case Diameter:** 30 millimeters
- **Display Type:** Digital
- **Movement Type:** Quartz
- **Power Source:** Battery Powered
- **Band Material Type:** Rubber
- **Strap Material:** Rubber
- **Strap Type:** Two-piece strap
- **Strap Color:** Black
- **Dial Color:** Grey
- **Clasp Type:** Buckle
- **Style:** Strap
- **Decoration Feature:** Crystal
- **Sport Type:** Walking
- **Package Dimensions:** 7.6 x 7.5 x 7.3 cm; 100 grams
- **First Available Date:** June 1, 2021

8. Warranty and Support

Specific warranty information for the Lasika W-H9014 watch is not provided in this manual. Please refer to the product packaging or the retailer's website for details regarding warranty coverage and terms.
For technical support, service, or inquiries about your watch, please contact the authorized Lasika dealer or the customer service department of the retailer where you purchased the product. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0969GW48P

More documents and user manuals: **https://manuals.plus/**