Instant Pot 140-6013-01

Instant Pot Pod 3-in-1 Coffee Maker

Instruction Manual

Brand: Instant Pot | Model: 140-6013-01

1. Product Overview

The Instant Pot Pod 3-in-1 Coffee Maker is designed to provide versatile coffee and espresso brewing options. This multifunction machine supports K-Cup pods, Nespresso capsules, and your own ground coffee using the included reusable pod. It offers adjustable brew strength and multiple brew sizes to suit various preferences.





Image: Front view of the Instant Pot Pod 3-in-1 Coffee Maker.

- **3-in-1 Functionality:** Compatible with K-Cup pods, Nespresso capsules, and ground coffee.
- **Adjustable Brew Strength:** Features a BOLD option for a stronger cup.
- **Multiple Brew Sizes:** Offers 8, 10, and 12 oz for K-Cup; 2, 4, and 6 oz for Nespresso.
- **Large Water Reservoir:** 68oz removable water tank for fewer refills.
- **Travel Mug Friendly:** Accommodates up to 7" tall travel mugs.

2. Setup

Before first use, ensure all packaging materials are removed. Place the coffee maker on a stable, level surface.

1. **Fill Water Reservoir:** Remove the 68oz water reservoir from the back of the unit. Fill it with fresh, cold water up to the MAX line. Place it back securely.



Image: Side view showing the large 68oz removable water reservoir.

2. **Initial Rinse Cycle:** Place a large mug or container on the drip tray. Close the lid without any pod inserted. Press the power button to turn on the machine. Select a large brew size (e.g., 12 oz for K-Cup side or 6 oz for Nespresso side) and let the machine run a cycle with just water. This cleans the internal components.
3. **Prepare for Brewing:** The machine is now ready for use. Ensure the drip tray is properly seated.

3. Operating Instructions

The Instant Pot Pod offers intuitive one-touch brewing for various coffee types.



Image: Diagram illustrating the 6 available brew sizes for K-Cup and Nespresso.

1. **Power On:** Press the power button () to turn on the coffee maker. The lights will illuminate.
2. **Insert Pod/Grounds:**
    - **For K-Cup Pods:** Lift the handle, insert a K-Cup pod into the K-Cup holder on the left.
    - **For Nespresso Capsules:** Lift the handle, insert a Nespresso original capsule into the Nespresso holder on the right.
    - **For Ground Coffee:** Place your ground coffee into the reusable pod (included), then insert the reusable pod into the K-Cup holder.



Image: Top view of the coffee maker showing K-Cup and Nespresso pod insertion points.

3. **Select Brew Size:** Choose your desired brew size by pressing the corresponding button (e.g., 8 oz, 10 oz, 12 oz for K-Cup; 2 oz, 4 oz, 6 oz for Nespresso).
4. **Adjust Brew Strength (Optional):** For a bolder flavor, press the 'Bold' button before selecting your brew size.
5. **Brewing:** The machine will begin brewing. Once complete, the selected brew size light will turn off.
6. **Pour Over Iced Coffee:** Fill your glass with ice cubes. Select the 'Bold' feature and then choose an 8, 10, or 12 oz brew size. Optionally, add your choice of milk after brewing for a perfect iced coffee.

4. Maintenance

Regular cleaning ensures optimal performance and longevity of your coffee maker.



Image: Close-up of the control panel showing water and cleaning indicators.

- **Water Indicator:** The 'Water' light will illuminate when the water tank needs refilling.
- **Cleaning Indicator:** The 'Clean' light will flash after approximately 300 brew cycles, indicating it's time for descaling.
- **Empty Used Capsule Container:** For Nespresso capsules, used capsules automatically drop into a removable container located behind the drip tray. Empty this regularly.
- **Clean Drip Tray:** The drip tray is removable for easy rinsing.
- **Descaling:** Follow the descaling instructions in the full user manual (link below) to remove mineral buildup.

5. Troubleshooting

If you encounter issues with your Instant Pot Pod, refer to these common solutions:

- **No Water Dispensing:** Ensure the water reservoir is filled and properly seated. Check for any blockages in the needle or pod holder. Perform a rinse cycle.

- **Weak or Incomplete Brew:** Verify the pod is correctly inserted and not punctured multiple times. Ensure the water reservoir has sufficient water. Try the 'Bold' setting for stronger coffee.
- **Leaking:** Check that the water reservoir is securely in place and not cracked. Ensure the drip tray is correctly positioned.
- **Cleaning Light Flashing:** This indicates the machine needs descaling. Follow the descaling procedure outlined in the full user manual.
- **Machine Not Powering On:** Ensure the power cord is securely plugged into a working outlet.

6. Specifications

Brand	Instant Pot
Model Name	Instant Dual Pod Plus 68oz Coffee Maker
Item Model Number	140-6013-01
UPC	810028586031
Product Dimensions	7"D x 13"W x 14"H
Item Weight	12 ounces
Water Reservoir Capacity	68 oz
Voltage	120 Volts
Operation Mode	Fully Automatic
Human Interface Input	Touchscreen

7. Warranty and Support

For detailed warranty information and customer support, please refer to the official Instant Pot website or contact their customer service directly.

A comprehensive User Manual in PDF format is available for download:Download User Manual (PDF)

For additional recipes and product information, download the free Instant Brands Connect App, available on iOS and Android.

© 2025 Instant Pot. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question