Zuru 25274

Zuru Micro Boats Assorted - Series 3 Instruction Manual

Model: 25274

Introduction

Welcome to the instruction manual for your Zuru Micro Boats Assorted - Series 3. These water-activated toy boats are designed for exciting play in water. Each boat features unique designs and is ready for immediate use. Please read this manual carefully to ensure safe and optimal enjoyment of your Micro Boats.

Safety Information

- **Age Recommendation:** Suitable for ages 36 months to 14 years. Adult supervision is recommended for younger children.
- **Water Use Only:** These boats are designed for use in water. Do not use in sand, dirt, or other non-water environments.
- **Small Parts:** This product may contain small parts. Keep away from children under 3 years to prevent choking hazards.
- **Battery Safety:** The boats come with pre-installed LR44 alkaline batteries. Do not attempt to replace batteries unless specified in a future version of this manual. Dispose of used batteries responsibly.
- **Avoid Submerging:** While water-activated, avoid fully submerging the boat for extended periods or in deep water to prevent damage to internal components.

Product Overview

The Zuru Micro Boats are compact, water-activated toy boats. Each boat features a unique design, often with bold colors and graphics, and is equipped with a mechanism that allows it to move in water upon contact.



Image: An assortment of Zuru Micro Boats, showcasing different colors and graphic designs, including red, blue, green, and orange boats.



Image: A top-down view of several Zuru Micro Boats, highlighting their distinct color schemes and racing numbers.



Image: A single red Zuru Micro Boat with a black and silver cockpit, featuring a "88" graphic and dinosaur-themed decals.

Setup

1. **Unpack the Boat:** Carefully remove the Micro Boat from its packaging. Ensure all packaging materials are discarded safely.



Image: Packaging for a Zuru Micro Boat, featuring an orange boat with "22" graphic and "Wave 3 Dino Racers" branding.

2. **No Assembly Required:** Your Zuru Micro Boat comes pre-assembled and ready for play.
3. **Batteries:** The boat includes pre-installed LR44 batteries. No user battery installation is required for initial use.

Operating Instructions

The Zuru Micro Boats are designed for simple, water-activated operation.

1. **Prepare Water Area:** Find a suitable water container such as a bathtub, sink, or shallow pool. Ensure the water is clean and free of debris.
2. **Place in Water:** Gently place the Micro Boat onto the surface of the water. The boat will automatically activate and

begin to move upon contact with water.

3. **Observe Movement:** The boats are designed for "4 direction racing," meaning they can move in various directions once activated.
4. **Remove from Water:** When play is finished, remove the boat from the water. It will automatically stop once dry.



Image: A single blue Zuru Micro Boat with a green cockpit, featuring a "53" graphic and wave-like decals.

Maintenance

- **Drying:** After each use, thoroughly dry the Micro Boat with a soft cloth. Ensure all water is removed from the exterior to prevent water spots or mineral buildup.
- **Storage:** Store the boat in a dry, cool place away from direct sunlight when not in use.
- **Cleaning:** If necessary, wipe the boat with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Battery Life:** The included batteries are designed for a certain lifespan. When the boat's movement becomes sluggish or stops activating, it indicates the batteries are depleted. Battery replacement is not user-serviceable for this model.

Troubleshooting

Problem	Possible Cause	Solution
Boat does not move in water.	• Batteries are depleted. • Water sensors are obstructed or dirty.	• If batteries are depleted, the boat may need to be replaced as batteries are not user-replaceable. • Gently clean the underside of the boat where it contacts water to ensure sensors are clear.
Boat moves erratically or slowly.	• Low battery power. • Debris in the water or around the propeller.	• Low battery power indicates the boat may need to be replaced. • Ensure the water is clean. Carefully check and remove any debris from the propeller area.

Specifications

Model Number	25274
Brand	Zuru

Manufacturer	United Pacific Designs
Recommended Age	36 months - 14 years
Product Dimensions	14.5 x 7 x 20 cm; 150 g
Batteries Required	No (Batteries included and pre-installed)
Battery Type	3 LR44 Alkaline batteries
Assembly Required	No

Warranty and Support

For information regarding warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or contact United Pacific Designs directly. Specific warranty details are not provided in this manual.

© 2024 United Pacific Designs. All rights reserved.