Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY COV30748175

ALLIMITY COV30748175 Remote Control User Manual

For LG Micro Hi-Fi Systems CM2460, CMS2460F, CM2760, CM2760F

1. Introduction

This manual provides instructions for the ALLIMITY COV30748175 replacement remote control. This remote is designed to be compatible with specific LG Micro Hi-Fi System models, offering direct functionality without complex setup procedures. Please read this manual thoroughly to ensure proper use and to maximize your audio system experience.

Compatible LG Micro Hi-Fi System Models:

- CM2460
- CMS2460F
- CM2760
- CM2760F

2. Setup

2.1 Installing Batteries

The ALLIMITY COV30748175 remote control requires two (2) AAA batteries for operation. No programming or pairing is necessary; simply insert the batteries, and the remote will be ready for use with your compatible LG Micro Hi-Fi System.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Angled view of the remote control. The battery compartment is located on the rear of the device.

3. Operating the Remote Control

This section details the functions of the buttons on your ALLIMITY COV30748175 remote control. Point the remote directly at your LG Micro Hi-Fi System for optimal response.




FUNCTION
VOL
PRESET
FOLDER
PROGRAM
MEMORY
REPEAT
DELETE
SOUND
EFFECT
TUN.-
TUN.+
INFO
DIMMER
SLEEP
CLOCK
ALARM
RDS/SET
USB REC
*
PTY.
COV30748175
CD HOME AUDIO

Image: Front view of the remote control, highlighting the various function buttons.

3.1 Button Functions Overview

Button	Function
Power (Red)	Turns the Micro Hi-Fi System On or Off.
VOL + / -	Adjusts the volume level up or down.
FUNCTION	Cycles through input sources (e.g., CD, USB, FM, Bluetooth).
Mute	Mutes or unmutes the audio output.
PRESET / FOLDER ^ / v	Navigates through preset radio stations or folders on USB/CD.
PROGRAM / MEMORY	Used to program radio stations or create custom play order for tracks.
REPEAT	Repeats the current track, folder, or all tracks.
DELETE	Deletes programmed items or files (functionality depends on system).
SOUND EFFECT	Cycles through various sound equalization modes.
Play / Pause	Plays or pauses media playback.
Stop	Stops media playback.
Skip Back / Forward	Skips to the previous or next track/file.
TUN. - / +	Tunes radio frequency down or up.
INFO	Displays information about the current track, station, or system status.
DIMMER	Adjusts the brightness of the system's display.
SLEEP	Sets a timer for the system to automatically turn off.
CLOCK	Accesses clock settings.
ALARM	Sets or adjusts alarm functions.
RDS/SET	Activates/deactivates RDS (Radio Data System) or confirms settings.
USB REC	Initiates recording to a connected USB device.
PTY	Selects program type for radio stations (e.g., News, Sport, Music).

4. Maintenance

4.1 Cleaning

To maintain the remote control's appearance and functionality, wipe it regularly with a soft, dry cloth. Avoid using liquid cleaners, abrasive materials, or chemical solvents, as these can damage the surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both AAA

batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or malfunction.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent potential leakage and damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you encounter issues with your remote control, please refer to the following common problems and solutions:

- **Remote is not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA batteries.
  - Check for any obstructions between the remote control and the LG Micro Hi-Fi System's infrared sensor.
  - Confirm that the remote control is pointed directly at the system.
- **Some buttons are not working:**
  - This remote is a direct replacement and should work without programming. Verify that your LG Micro Hi-Fi System model is listed under the compatible models in Section 1.
  - Clean the remote control's surface, especially around the unresponsive buttons, to ensure no debris is interfering.
- **System responds intermittently:**
  - Batteries may be low; replace them.
  - Ensure you are within the effective range of the remote control (typically up to 20 feet/6 meters).
  - Minimize strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the infrared signal.

If the issue persists after trying these steps, please contact customer support for further assistance.

6. Specifications

- **Model Number:** COV30748175
- **Brand:** ALLIMITY
- **Compatible Devices:** LG Micro Hi-Fi Systems (CM2460, CMS2460F, CM2760, CM2760F)
- **Power Source:** 2 x AAA Batteries (not included)
- **Dimensions:** Approximately 4 x 1 x 0.5 inches
- **Item Weight:** Approximately 1.02 ounces
- **Special Feature:** No Programming Required

7. Warranty and Support

For any questions regarding the ALLIMITY COV30748175 remote control, or if you experience any issues not covered in this manual, please contact the seller or manufacturer's customer support. Please refer to your purchase documentation for specific warranty details and contact information.
When contacting support, please have your product model number (COV30748175) and details of your LG Micro

Hi-Fi System model readily available.

ALLIMITY COV30748175 Remote Control User Manual

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B096K9SJC8

More documents and user manuals: **https://manuals.plus/**