Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kate and Laurel McCutcheon

Kate and Laurel McCutcheon Midcentury Wood Desk Instruction Manual

Model: McCutcheon (221186)

Brand: Kate and Laurel

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Kate and Laurel McCutcheon Midcentury Wood Desk. Designed with clean lines and a brown finish, this desk offers a functional workspace with a midcentury modern aesthetic. It is crafted from solid mango wood, ensuring durability and a unique woodgrain finish for each piece.



Image 1.1: The McCutcheon desk, showcasing its midcentury design and brown finish, suitable for various room types.

2. Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always follow the assembly instructions carefully.
- Keep tools and small parts out of reach of children during assembly.
- Assemble the desk in a well-lit, stable area to prevent accidents.
- Ensure all fasteners are securely tightened before using the desk.
- Do not overload the desk or its drawer. Refer to specifications for weight limits.
- If you are unsure about any part of the assembly process, consult a professional or contact customer support.

3. Product Specifications

Feature	Detail
Model Name	McCutcheon

Model Number	221186
Dimensions (W x D x H)	42 inches x 22 inches x 30 inches
Drawer Dimensions (W x D x H)	18 inches x 13.5 inches x 4 inches
Material	Solid Mango Wood
Color	Brown
Item Weight	36.8 Pounds
Assembly Required	Yes (2-step assembly)



Image 3.1: Detailed dimensions of the McCutcheon desk.

4. Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Desk Top with integrated drawer
- Desk Legs (4 pieces)
- Assembly Hardware (screws, washers, Allen wrench)
- Instruction Manual

5. Assembly Instructions

The McCutcheon desk features a simple two-step assembly process. It is recommended to have a second person assist with assembly for ease and safety.

1. **Step 1: Attach Legs to Desk Top**

   Carefully unbox all components and place the desk top upside down on a soft, clean surface to prevent scratches. Align each of the four desk legs with the pre-drilled holes on the underside of the desk top. Secure each leg using the provided screws and Allen wrench. Ensure all screws are tightened firmly but do not overtighten.

2. **Step 2: Position the Desk**

   With assistance, carefully turn the assembled desk upright and place it in its desired location. Ensure the desk is stable and level. Adjust as necessary.

Your desk is now ready for use.

6. Operating Instructions

The McCutcheon desk is designed for straightforward use as a writing or home office desk.

6.1 Using the Drawer

The desk includes one pull-out drawer for storage. To open, gently pull the integrated handle. To close, push the drawer back until it is flush with the desk front. Avoid forcing the drawer if it feels stiff; ensure it is properly aligned on its glides.



Image 6.1: The desk's integrated pull-out drawer provides convenient storage for office supplies.

7. Maintenance and Care

To ensure the longevity and appearance of your solid mango wood desk, follow these care guidelines:

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or excessive moisture, which can damage the wood finish.
- **Protection:** Use coasters under drinks and placemats under hot items to prevent water rings and heat damage.
- **Sunlight:** Avoid placing the desk in direct sunlight for prolonged periods, as this can cause fading or cracking of the wood.
- **Humidity:** Maintain a consistent humidity level in the room to prevent wood from expanding or contracting, which can lead to cracks.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners to ensure the desk remains stable.



Image 7.1: The smooth surface of the mango wood desktop, highlighting its natural grain.

8. Troubleshooting

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Desk is wobbly	Loose fasteners or uneven floor.	Check and tighten all assembly screws. Ensure the desk is on a flat surface; use shims if necessary.
Drawer sticks or is difficult to open/close	Misalignment or obstruction.	Ensure the drawer is properly seated on its glides. Check for any objects obstructing the drawer's path.
Scratches on wood surface	Sharp objects or abrasive cleaning.	Minor scratches can sometimes be buffed out with wood polish. For deeper scratches, consult a furniture repair specialist.

9. Official Product Video

Your browser does not support the video tag.

Video 9.1: An official product video showcasing the Kate and Laurel McCutcheon Desk, highlighting its features and design.

10. Warranty and Support

Kate and Laurel products are manufactured with quality and care. For specific warranty information, please refer to the documentation included with your purchase or visit the official Kate and Laurel website.
For customer support, missing parts, or further assistance, please contact Kate and Laurel customer service through

their official channels. When contacting support, please have your model number (221186) and purchase details ready.

Manufacturer: Uniek
Brand: Kate and Laurel
Website: Visit the Kate and Laurel Store on Amazon

© 2023 Kate and Laurel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0977S45RW

More documents and user manuals: **https://manuals.plus/**