Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Westek BL-SCDF-MB2

Westek Battery Operated Wall Sconce with Remote

Model: BL-SCDF-MB2
Brand: Westek

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Westek Battery Operated Wall Sconce with Remote. Designed for convenience and versatility, these sconces offer a practical lighting solution for areas without direct power supply, featuring dimmable LED lights and remote control functionality.

Product Features

- **Battery Powered:** Operates on 6 AA batteries per sconce (not included), eliminating the need for wiring.
- **Dimmable LED Lights:** Features 160 lumens with two brightness settings (full and dim modes).
- **Adjustable Color Temperature:** Offers three color temperature options: 3000K (warm white), 4000K (natural white), and 5000K (cool white).
- **Long Run Time:** Provides up to 70 hours of illumination.
- **Auto Shut-Off:** Includes a 4-hour auto shut-off feature to conserve battery life.
- **Dual Control:** Can be operated via the included remote control or a push button on the device.
- **Easy Installation:** Designed for wireless installation with included mounting hardware and a built-in level.
- **Versatile Design:** Matte Black Finish suitable for various decor styles, ideal for apartments, dorms, bedrooms, bathrooms, hallways, and vanity areas.

Package Contents

- Two (2) Westek Battery Operated Wall Sconces
- One (1) Remote Control
- Mounting Hardware (screws, anchors)
- Instruction Manual (this document)

Note: 6 AA batteries per sconce (total 12 AA batteries for the 2-pack) are required and not included.

Setup and Installation

1. Battery Installation

1. Locate the battery compartment on the back of each sconce.
2. Open the battery compartment cover.
3. Insert 6 AA batteries into each sconce, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2. Mounting the Sconce

The sconces can be installed facing upwards or downwards. They feature a built-in level for simplified installation.

1. Choose a desired location for your sconce. Ensure the surface is clean and dry.
2. Hold the sconce against the wall at the desired height and position. Use the built-in level to ensure it is straight.
3. Mark the positions for the mounting screws through the designated holes on the sconce's back plate.
4. Drill pilot holes at the marked locations. If installing into drywall, insert the provided wall anchors.
5. Align the sconce with the drilled holes and secure it to the wall using the provided screws. Do not overtighten.



Figure 1: Sconce dimensions and built-in level for easy installation. The sconce measures approximately 5 inches wide by 8 inches high, with a depth of 4.4 inches.



Figure 2: Example of a Westek wall sconce installed on a wall, demonstrating its appearance in a home setting.

Operating Instructions

The Westek Wall Sconce can be operated using the push button on the device or the included remote control.

Using the Remote Control



Figure 3: Westek wall sconces and the remote control, highlighting the control options.

- **Power On/Off:** Press the **ON** button to turn the sconce on, and the **OFF** button to turn it off.
- **Brightness Adjustment:** Use the dimming buttons (e.g., 50%, 100%) or the up/down arrows to adjust brightness levels. There are two main brightness settings: full and dim.
- **Color Temperature Selection:** Press the **WARM** (3000K), **WHITE** (4000K), or **COOL** (5000K) buttons to cycle through the three available color temperatures.
- **Timer Function:** Select a timer duration (e.g., 30 minutes, 60 minutes, 2 hours, 4 hours) to automatically turn off the light after the selected period. The 4-hour auto shut-off is a default feature to conserve battery life.

Using the Push Button on the Sconce

- A single press of the push button will turn the light on/off.
- Subsequent presses may cycle through brightness or color temperature settings, depending on the last remote

setting. For full control, use the remote.

Your browser does not support the video tag.

Video 1: An overview of the Westek Battery Operated Wall Sconce, demonstrating its features and functionality, including the three dimmable lighting modes (Warm White, Natural White, Cool White), 70-hour run time, 160 lumens, two brightness levels, and 4-hour auto shut-off. It also shows the convenience of remote control operation and various application settings.

Maintenance

- **Battery Replacement:** When the light dims significantly or stops responding, replace all 6 AA batteries in the sconce. Always replace with new, high-quality alkaline batteries.
- **Cleaning:** Wipe the sconce with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Storage:** If storing the sconce for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity and replace all batteries with new ones.
Remote control not working.	Remote battery is dead or remote is too far from the sconce.	Replace the remote control battery. Ensure you are within effective range (typically 10-15 feet) and there are no obstructions.
Light is dim or flickers.	Low battery power.	Replace all batteries in the sconce.
Sconce falls off the wall.	Improper installation or insufficient anchors.	Re-install using appropriate wall anchors for your wall type. Ensure screws are securely fastened.

Specifications

- **Model:** BL-SCDF-MB2
- **Power Source:** 6 AA Batteries (per sconce, not included)
- **Light Source:** LED
- **Brightness:** 160 Lumens
- **Run Time:** Up to 70 hours
- **Auto Shut-Off:** 4 hours
- **Color Temperatures:** 3000K (Warm White), 4000K (Natural White), 5000K (Cool White)
- **Material:** Plastic
- **Finish:** Matte Black
- **Dimensions:** 12.83"L x 4.65"W x 9.84"H (approximate, as per product dimensions)
- **Weight:** 1.32 Pounds (per sconce, approximate)

Safety Information

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Always insert batteries correctly according to polarity (+ and -).
- Remove exhausted batteries promptly.
- Dispose of batteries properly according to local regulations.
- Do not expose the product to extreme temperatures or direct moisture.
- This product is intended for indoor use only.
- Keep out of reach of children.

Warranty and Support

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service department. Specific warranty details are not provided in this manual.
Manufacturer: Westek
Website: Westek Store on Amazon

© 2024 Westek. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0979P531G

More documents and user manuals: **https://manuals.plus/**