Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC3000E02

ALLIMITY RC3000E02 Replacement Remote Control User Manual

Model: RC3000E02
Brand: ALLIMITY

Introduction

This manual provides comprehensive instructions for the ALLIMITY RC3000E02 replacement remote control. It is designed for use with various TCL TV models and covers essential information regarding setup, operation, maintenance, and troubleshooting to ensure optimal performance.

Setup

Battery Installation

The ALLIMITY RC3000E02 remote control requires two AAA batteries (not included) for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Back of the remote with battery compartment open.

Initial Use

This replacement remote control is designed for immediate use with compatible TCL TV models. No programming or complex setup procedures are required. Once the batteries are correctly installed, the remote is ready to operate your television.

Operating Instructions

Button Functions

The ALLIMITY RC3000E02 remote control features standard buttons for navigating your TCL TV. Refer to the image below for a visual guide to the button layout and their general functions:





Image: Front view of the remote control with button layout.

- **Power (Red Button):** Turns the TV on or off.
- **Source:** Selects input sources (HDMI, AV, etc.).
- **Number Buttons (0-9):** Direct channel selection.
- **ECO:** Accesses power-saving modes.
- **Guide:** Displays the electronic program guide.
- **Menu:** Opens the TV's main menu.
- **Exit:** Closes menus or returns to the previous screen.
- **Navigation (Up/Down/Left/Right) & OK:** Navigates menus and confirms selections.
- **Zoom +/-:** Adjusts screen zoom.
- **Option:** Accesses context-sensitive options.
- **Return:** Goes back to the previous menu or channel.
- **Volume (+/-):** Adjusts the sound volume.
- **Channel (P +/-):** Changes TV channels.
- **Info:** Displays program information.
- **Mute:** Mutes or unmutes the TV sound.
- **TEXT:** Activates teletext.
- **SUBTITLE:** Toggles subtitles.
- **LIST:** Displays a list of channels or media.
- **TV:** Switches to TV mode.
- **Lang:** Changes audio language.
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and context.

Compatible TCL TV Models

This remote control is compatible with a wide range of TCL TV models, including but not limited to:

- L32E3004, L32E3000C, L32F3393, L32E3003, H32E4403
- L55F3300F, L40D2700F, F22B3903, H24E4404R
- L32S4603, L32F3390C, L32D3300C, H32D4026
- L39F3300FC, L40E3003F, F40S3804, F50S3803, F55S3803
- RC3000E01, L39E3000FC, L40E3005F
- Also compatible with models 06-520W37-E002X and RC260JEI1.

Maintenance

Battery Replacement

Replace the batteries when the remote's response becomes inconsistent, the range decreases, or it stops functioning entirely. Always use new AAA alkaline batteries and dispose of old batteries responsibly according to local regulations.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Avoid using liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's finish or internal components.

Troubleshooting

Remote Not Responding

- **Check Batteries:** Ensure the batteries are inserted with the correct polarity (+/-) and are not depleted. Replace with fresh AAA alkaline batteries if necessary.
- **Line of Sight:** Verify there are no obstructions between the remote control and the TV's infrared (IR) sensor. The remote requires a clear line of sight to the TV.
- **Point Directly:** Make sure you are pointing the remote directly at the TV's IR sensor, usually located on the front panel.
- **TV Compatibility:** Confirm that your TCL TV model is listed as compatible with the RC3000E02 remote.

Limited Range

- **Replace Batteries:** Weak batteries can reduce the remote's effective range. Install new AAA batteries.
- **Remove Obstructions:** Ensure no objects (furniture, plants, etc.) are blocking the signal path between the remote and the TV.
- **Interference:** While less common for IR remotes, strong light sources or other electronic devices might cause minor interference. Try using the remote in a different environment if issues persist.

Specifications

Model Number	RC3000E02 (BJKJ-RC3000E02-JKJB)
Product Dimensions	6 x 2 x 0.6 inches
Item Weight	2 ounces
Batteries Required	2 AAA batteries (not included)
Special Feature	No Programming Required
Compatible Devices	Television

Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any product-related inquiries, technical support, or warranty claims, please contact the original seller or the manufacturer, ALLIMITY, directly through their official support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B097BSGKDK

More documents and user manuals: **https://manuals.plus/**